

Portable Bluetooth Speaker

Installation & Operating Instructions - Please keep for future reference



BC-235D

Real Life Technology



Bluetooth®

Important - Please read these instructions fully before installing or operating

These instructions contain important information which will help you get the best from your speaker and ensure safe and correct installation and operation.



Safety Information

Important – Please read these instructions fully before installation

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE ANY COVER. NO USER-SERVICEABLE PARTS INSIDE, REFER ANY SERVICING TO QUALIFIED SERVICE PERSONNEL.

- Please read this owner's guide
- Please take the time to follow the instructions in this owner's guide carefully. It will help you set up and operate your system properly and enjoy all of its advanced features.
- Please save this owner's guide for future reference.
- The product label is located on the back of the product.
- Heed all warnings - on the product and in the owner's guide.
- Do not use this apparatus near water or moisture. Do not use this product near a bathtub, washbowl, kitchen sink, and laundry tub, in a wet basement, near a swimming pool, or anywhere else that water or moisture is present.
- Refer all servicing to qualified service personnel
- Servicing is required when the apparatus has been damaged in any way: such as liquid has been spilled or objects have fallen into the apparatus; the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped - Do not attempt to service this product yourself. Opening or removing covers may expose you to dangerous voltages or other hazards.
- Use proper power sources - Plug the product into a proper power source, as described in the operating instructions or as marked on the product.
- Only use attachments/accessories specified by the manufacturer.



We apologise for any inconvenience caused by any minor inconsistencies in these instructions, which may occur as a result of product improvements and development.

This appliance complies with the following EU directives: 2006/95/EC Low voltage directive / 2004/108/EC EMC directive , 2002/96/EC WEEE directive, 1999/5/EC R&TTE directive.

Disposal Information



The symbol on the product or its packaging indicates that this product may not be treated as household waste. Instead it should be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling this product, please contact your local council office, your household waste disposal service or the shop where the product was purchased.

Contents and Features

Page Contents

Box Contents	2
Features	2
Controls and Indicators	3
Charging your speaker	4
Pairing your speaker - mobiles and tablets	4
Pairing your speaker - iPhone and iPad	4
Pairing your speaker - PC, laptop and Mac	4
Re-connecting to a paired device	5
Hands-free	5
Volume control	5
AUX IN connections	5
Line-out	5
Troubleshooting	6
Warning	6
Warranty	7

Box Contents

- 1 x BC-235D Bluetooth speaker
- 1 x USB A to Micro USB charge cable
- 1 x AUX IN (3.5mm plug to plug) cable
- 1 x User guide

Features and specifications

10m wireless range.

Compatible with most makes and models of smartphone and tablet.

Built-in hands free phone function.

2 x 2W speakers.

Bluetooth specification: Bluetooth V3.0+EDR

Bluetooth output power: Output level 2, maximum connection distance 10m

Rated output: L: 2W, R:2W

Operating frequency range: 2.402GHz ~ 2.480GHz unlicensed ISM band


Supported Profiles: A2DP, AVRCP, GAVDP, AVDTP

Dimension: (L)154x(W)54x(D)56 mm

Weight: approx. 250g (Bluetooth speaker)


Controls and Indicators

Controls and Indicators



1. Microphone 3. Play/Pause/Hands-free

1. Microphone position for hands-free calls
2. Press to reduce volume, hold down to reduce volume fast.
3. In Bluetooth search mode, hold down for 3 seconds to enter pairing mode; in Bluetooth play status, press to pause/play music; when a call comes, press key to answer, press again to hang up.
4. Press to increase volume, hold down to increase the volume fast.



1. LINE OUT - Audio Output socket
2. AUX IN - For external audio input (3.5mm socket)
3. LED Charging indicator light
4. MICRO USB - Charging socket
5. ON/OFF - Power switch

Charging and Pairing

Charging your speaker (3.7V 800mAh rechargeable battery built-in)

Connect the speaker to a computer or 5V USB mains adaptor (not included) with the USB cable supplied. Red LED turns ON during charging, turns OFF when fully charged. Unplug USB cable when fully charged.

Pairing your speaker with Bluetooth enabled mobiles and tablets

1. Place the speaker and mobile/tablet within 3 metres of each other. Turn on the speaker using the power switch (5) on the back of the speaker, the LED will flash blue, the speaker is ready to pair.
2. Select the Bluetooth function on your mobile and search for Bluetooth devices, the speaker will appear as "BC235D" in the Bluetooth device list select and pair.
3. Connection will normally be automatic if a password is required enter (0000). After successful pairing, select "BC235D" in the Bluetooth device list, and press "connect". After successful connection, LED changes to continuous blue.

Please Note:

1. If the pairing is not successful, turn off the speaker and try pairing again.
2. After successful pairing, paired devices will remember each other. Unless pairing information is deleted, pairing should be automatic when both devices are switched on in range of each other.
3. To pair with a new device follow steps 1-3 above after disconnecting the existing pair.

Pairing your speaker with iPhone/iPad

Place the speaker and your iPhone/iPad within 1 metre of each other. Turn on the speaker, the LED will flash blue, the speaker is ready to pair. In iPhone/iPad General menu go to Bluetooth, tap on Bluetooth function, search the Bluetooth devices, tap "BC235D" to connect.

Pairing your speaker with a PC /laptop Mac running OS X 10 or above

To pair to a PC or Mac follow the same procedure as for a phone or tablet. After pairing to a Mac you will need to open System Preferences, click on Sound, click Output and select the Bluetooth speaker. Then click Input and select your speaker. Adjust the Input and Output volume to suit. "Show Bluetooth status in the menu bar" checkbox. During the pairing process, if you are asked for a password enter (0000).

Hands-Free / AUX IN / Line out

Re-connecting to a paired device

Each time the speaker is turned on, there are two possible outcomes. The speaker will connect automatically to the last connected device, just press play for playback. The speaker will be listed on your devices screen of as an available output channel, select the speaker as output channel and play your music.

Hands-free

Press "Hands-free" (key 3) to answer a phone call. Press again to end a call.

Volume control

Volume is controlled by a combination of the volume controls on the speaker and the volume controls on paired (or AUX IN) devices.

AUX IN connections

You can connect any audio output device to the AUX IN port via the AUX cable supplied. When the AUX cable is connected Bluetooth mode is automatically suspended. You can then play music through the speaker from the connected device.

LINE OUT play mode

When the machine is in Bluetooth mode, you can use a 3.5mm audio cable connected to the LINE OUT socket of the machine to output the audio signals from the paired device to the input on another sound system.

Troubleshooting and Warnings

Troubleshooting

Q1 The sound is low or completely silent.

A1 Make sure both your audio device and the speaker are charged.

A2 Make sure the connection (either Bluetooth or AUX) is fully functioning and secure. If you are using the AUX port check the cable is connected properly.

A3 Check the speaker and audio device volume and that an audible music track is playing.

Q2 My device cannot find the speaker

A1 Ensure the Bluetooth is on and not hidden on your audio device and that the speaker is not paired to another device.

Q3 The person on the other end of my call cannot hear me or I cannot hear them.

A1 Make sure the volume is turned up on both the speaker and phone.

A2 Make sure there is no obstruction to the microphone (which is positioned in the front behind the speaker grille)

Warning:

This speaker has a built in lithium battery, it must be used and charged properly. Improper use can cause the battery to catch fire or explode resulting in serious or fatal injury.

Caution:

Do not disassemble or modify the speaker.

Do not place the speaker in direct sunlight, near fires, stoves, or other high temperature locations.

Do not expose the speaker to water or salt water, or allow the speaker to get wet.

If you dispose of the speaker remember it contains a lithium battery and recycle accordingly.



PRODUCT GUARANTEE

This product is guaranteed against manufacturing defects for a period of

A large, bold, dark grey number '1' is centered within a white circle. The circle is positioned to the left of the word 'Year'.

Year

This product is guaranteed for twelve months from the date of original purchase. Any defect that arises due to faulty materials or workmanship will be either replaced, refunded or repaired free for charge where possible during this period by the dealer from whom you purchased the unit.

The guarantee is subject to the following provision:

- The guarantee does not cover accidental damage, misuse, cabinet parts knobs or consumable items.,
- The product must be correctly installed and operated in accordance with the instructions contained in this manual.
- It must be used for domestic purpose.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- Specifications are subject to change without notice.
- The manufacturer disclaims any liability for the incidental or consequential damages.
- The guarantee is in addition to, and does not diminish your statutory or legal rights.

Guarantor: Argos Ltd
489 - 499 Avebury Boulevard
Central Milton Keynes
MK9 2NW

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment..



Waste electrical and electronic products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority for recycling advice.