
Test Setup photographs (PCE)

EUT Position: X-axis



Test Setup photographs (PCE)

EUT Position: Y-axis



Test Setup photographs (PCE)

EUT Position: Z-axis

