Test Setup photographs (DTS & DSS)

EUT Position: X-axis

EUT Position: Y-axis

EUT Position: Z-axis

Test Setup Photo of Radiated Measurement(DTS & DSS)

Test Setup photo of Conducted Emissions (DTS & DSS)