


Antenna Information

■ Antenna and Device Information



Antenna	Mode	Band
①	GSM	GSM850 Tx/Rx
	GSM	GSM900 Tx/Rx
	GSM	DCS(GSM1800) Tx/Rx
	GSM	PCS(GSM1900) Tx/Rx
	WCDMA	B2 Tx/Rx
	WCDMA	B5 Tx/Rx
	WCDMA	B8 Tx/Rx
	LTE	B3 Tx/Rx
②	LTE	B20 Tx/Rx
	WCDMA	B1 Tx/Rx
	WCDMA	B4 Rx
③	LTE	B7 Tx/Rx
	GPS/GNSS	1.574~1.6GHz
④	LTE	B7 Rx
	LTE	B20 DRx
⑤	WIFI	2.4G Tx/Rx
	WIFI	5G Tx/Rx
⑥	WCDMA	B1 DRx
	WCDMA	B2 DRx
	WCDMA	B8 Drx
	LTE	B1 DRx
	LTE	B3 DRx
	LTE	B8 DRx

- * NFC antenna is placed on Battery Cover.
- * Other Antennas are placed on Rear Case.

Note;

1. Per FCC KDB Publication 941225 D06v02, we performed the SAR testing at 0.8 cm and 1.0 cm from the top & bottom surfaces and also from side edges with a transmitting antenna ≤ 2.5 cm from an edge.
*Please see the LG-H955_Antenna distance for further information.
2. This EUT only support GSM, WCDMA, Bluetooth, Wi-Fi and NFC.

SAR Test Setup Photographs

■ Test Setup Photo



■ Test Setup Photo



■ Test Setup Photo



■ Test Setup Photo



■ **Test Setup Photo (All)**




■ **Test Setup Photo (Rear)**




[Distance of 0.8 cm from the EUT]

■ **Test Setup Photo (Front)**




[Distance of 0.8 cm from the EUT]

■ **Test Setup Photo (Left)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Right)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Top)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Bottom)**



[Distance of 1.0 cm from the EUT]