


Antenna and Device Information



Antenna

Antenna	Mode	Band
ANT1	Main LB/HB	LTE B5/7/12/17/41 W5 , GSM850 TX,RX
ANT2	Main MB	LTE B2,4 W2/4 , GSM1900 TX,RX
ANT3	LB/HB MRD	LTE B5/7/12/17/41 W5 , GSM850 RX
ANT4	WiFi/GPS	BT/WiFi(2.4G&5G) GPS
ANT5	MB MRD	LTE B2/4 W2 , GSM1900 RX
ANT6	NFC	-

SAR Test Setup Photographs

■ **Test Setup Photo (Left All)**



■ Test Setup Photo (Left Touch/Tilt)



■ **Test Setup Photo (Right All)**



■ Test Setup Photo (Right Touch/Tilt)



■ **Test Setup Photo (Body All)**



■ **Test Setup Photo (Rear)**



[Distance of 1.0 cm from the EUT]

■ Test Setup Photo (Front)



[Distance of **1.0 cm** from the EUT]

■ **Test Setup Photo (Left)**




[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Right)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo(Top)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo(Bottom)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Rear for Extremity SAR)**



[Distance of **0 cm** from the EUT]

■ **Test Setup Photo (Front for Extremity SAR)**



[Distance of **0 cm** from the EUT]

■ **Test Setup Photo (Right for Extremity SAR)**



[Distance of 0 cm from the EUT]

■ **Test Setup Photo (Top for Extremity SAR)**



[Distance of 0 cm from the EUT]