


Antenna and Device Information

Front



E1_LTE Antenna

Antenna	Mode	Band
ANT1	Main LB	B17/28/20/5/8/7 GSM850/EGSM
ANT2	Main HB	B1/2/3/4 DCS1800/PCS1900
ANT3	GPS	GPS
ANT4	WiFi	WiFi2.4GHz
ANT5	HB MRD	B1/2/3/4/7
ANT6	LB MRD	B5/8/17/20/28

Right

SAR Test Setup Photographs

■ **Test Setup Photo (Left All)**



■ **Test Setup Photo(Left Touch/Tilt)**



■ **Test Setup Photo (Right All)**



■ Test Setup Photo (Right Touch/Tilt)



■ **Test Setup Photo (Body All)**




■ **Test Setup Photo (Rear)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Front)**



[Distance of **1.0 cm** from the EUT]

■ **Test Setup Photo (Left)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo (Right)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo(Top)**



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo(Bottom)**



[Distance of 1.0 cm from the EUT]