


10. SETUP PHOTOS



EUT ORIENTATION



X-AXIS POSITION

Y-AXIS POSITION



Z-AXIS POSITION

END OF REPORT