


---

## Test Setup photographs (DTS)

---

### EUT Position: X-axis





---

## Test Setup photographs (DTS)

---

### EUT Position: Y-axis





---

## Test Setup photographs (DTS)

---

### EUT Position: Z-axis



## Test Setup photographs (DTS)

