

Test Setup photographs(DTS)

EUT Position: X-axis




Test Setup photographs(DTS)

EUT Position: Y-axis



Test Setup photographs(DTS)

EUT Position: Z-axis



Test Setup photographs (DTS)

