

Quick Setup Guide

Amcrest 4MP Bullet wireless Camera

Model: ASH42



How can we help?

We are dedicated to providing the highest quality support to our customers and are available 7 days a week.

Online Video Tutorial & Quick Start Guide
amcrest.com/smartbulletsetup

Need help?
support@amcrest.com
1-888-212-7538

2

01 Setting Up the Camera

The Amcrest Smart Home app connects your Amcrest camera to your Android or iOS mobile device, ensuring you are always connected to what matters most.



To get the app, search for **"Amcrest Smart Home"** in the Google Play or App Store.

Note: In order to add your device on the **Amcrest View Pro** app you must complete setup on the **Amcrest Smart Home** app first. Then follow link below: amcrest.com/usingviewpro


3

Connecting to the SmartHome app

Ensure your device is powered using the included power supply.

Then, open the Amcrest Smart Home app and tap **"Register"** to register an account. After registering an account, log into the app and tap **"Add Device"**.

You will need to allow all notification and location permissions to allow the camera to connect to your mobile device.



4

Scan the QR Code or Manually Enter the S/N

Scan the QR code located on the bottom of your camera.

If you are unable to scan the QR code you can manually enter the serial number by tapping **"Manually enter SN"**.



5

Choose Your Setup Method

Choose between Wi-Fi and Ethernet Setup, then follow the in app instructions to complete setup.


Wi-Fi (Recommended)

This method allows you to connect the device to your network via Wi-Fi using the camera's built-in Wi-Fi hotspot.

Ethernet Only

This method uses an Ethernet connection to connect to your device to the network. This method does not use Wi-Fi. If you wish to enable Wi-Fi you will need to do so after initial setup.

Note: Your camera must be on the same network as your mobile device during either setup method.



6

02

Camera Features



Devices

Displays added devices in the app



Events


Provides quick access to motion events and alerts



Account

Manage account settings and information

The main screen on the Amcrest Smart Home app will be your **Devices** menu. This menu displays all of your added devices.




7



Built-in Microphone

Use the built-in microphone feature to listen to what matters most, anytime, anywhere.




8



SmartHome Cloud Storage

Use the Amcrest Smart Home premium cloud service to view, record and playback events from a secure, off-site location.



9




MicroSD Card Storage

A MicroSD card can also be used to record and playback events locally.



Note:
The MicroSD card must be class 10 or higher and formatted to FAT32.




10



Motion Detection

Motion Detection allows you to receive alerts and automatically record footage anytime your camera detects motion.



11




Smart Notifications

Receive Email and push notifications directly to your smartphone using the Amcrest Smart Home app.



Note:
To learn more about Smart Notifications visit:
amcrest.com/smartnotifications



12