

148.5 mm

- Focus on your safety and that of others if you use the earbuds while engaging in any activity requiring your attention, e.g., while riding a bicycle or walking in or near traffic, a construction site or railroad, etc. Remove the earbuds or adjust your volume to ensure you can hear surrounding sounds, including alarms and warning signals.
- Do NOT use the headphones if they emit any loud unusual noise. If this happens, turn the headphones off.
- Do NOT submerge or expose the earbuds for extended period to water, or wear while participating in water sports, e.g., swimming, waterskiing, surfing, etc.
- Remove erabuds immediately if you experience a warming sensation of loss of audio.
- Do NOT make unauthorized alternations to this product.
- Use this product only with an agency approved power supply which meets local regulatory requirements.
- Do NOT expose products containing batteries to excessive heat.

CAUTION: Choking Hazard. May contains small parts.
Not for Children under 3 years.

CAUTION: To comply with the limits of the Class B digital device, pursuant to Part 15 of the FCC Rules, this device must be installed with computer equipment certified to comply with Class B limits.

All cables used to connect to the computer and peripherals must be shielded and grounded. Operation withnon-certified computers or non-shielded cables may result in interference to radio or television reception.

Federal Communication Commission (FCC) Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Federal Communication Commission (FCC) Interference Statement Notice for USA FCC

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on,

the user is encouraged try to correct the interference by one or more of the following measues:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio / TV technician for help.



The *Bluetooth*® word mark and logos are registered trademarks owned by *Bluetooth*® SIG, Inc. and any use of such marks by Camino International Limited is under license. Other trademarks and trade names are those of their respective owners.

Disney Theme Park Merchandise
Lake Buena Vista, FL 32830
©Disney



Made in China




Product contents

- 1 pc x Bluetooth earbuds
- 1 pc x micro USB charging cable
- 3 pairs x ear bud cushions

Technical specification

Bluetooth Version : V4.1	Controller Dimension : 49.2 x 12 x 9 mm
Built-in Lithium Battery Voltage : 3.7V	Control Panel : 40.3 x 7.5 x 7.0mm
Speaker Dimension : ø10mm	Battery Capacity : 60mAh
Charging Voltage : 5V	SNR : ≥90dB
Charging Current : ≤50mA	Charging Time : approx. 2 hours
Working Time : approx. 3 hours	Earbuds Power : 5mW THD≤10%

Description of Parts



Interface description

1. Power on: at power-off state, long press MFB for 2 seconds, blue LED flashes twice and then it is power-on.
2. Power off: at power-on state, long press MFB for 4 seconds, red LED lasts for 1 second and then it is power-off.
3. Pairing mode: at power-off state, long press MFB for 5 seconds until blue and red LED flash alternately and then it is at pairing mode.
4. Volume up: while on a call or playing music, short press volume up button, it will play voice notification when it reaches max volume.
5. Volume down: while on a call or playing music, short press volume down button, it will be muted when it reaches minimum volume.
6. Answer a call: when you receive an incoming call, it will speak the incoming call's phone number, short press MFB to answer the call.
7. Voice dialing: at connecting standby state, press MFB and Volume up button at the same time, follow the voice prompt (whether to support this function depends on your cellphone).
8. Hang up: while on a call, short press MFB to hang up the call, with voice prompt.
9. Reject call: when a phone call comes up, long press MFB for 2 seconds to reject the call.
10. Sound switch (switch sound of calling from earbuds to cellphone or from cellphone to earbuds): long press Volume Up for 2 seconds.
11. Mic muted: while on a call, long press Volume down for 2 seconds. You will hear voice prompt and the mic is muted (the person on the other side of the phone will not hear you), repeat this operation will cancel the mute state.
12. Re-dial of last call: at standby state, double press MFB, you will hear voice prompt.
13. Switch to an incoming call and end the current call (while three-party conference): short press MFB.
14. Switch to an incoming call and put the current call on-hold (while three-party conference): double press MFB.
15. Switch between current call and on-hold call (while three-party conference): double press MFB.
16. Play Music/Pause: short press MFB
17. Go to the previous song: while playing music, long press Volume down.
18. Skip to the next song: while playing music, long press Volume up.
19. Battery energy measure: short press Volume UP and Volume Down at the same time.
20. Language switch (English and Chinese voice prompt): long press Volume up and Volume Down at the same time for 2 seconds with relevant voice prompt. While switch to Chinese then plays Chinese voice prompt; while switch to English then plays English voice prompt.
21. Delete pairing list: at power-on state, long press MFB and Volume up at the same time for 5 seconds, red and blue LED flashes 3 times, the pairing list are deleted.
22. Auto-reconnect function: Just power on, will auto connect back to device ever paired; auto-reconnect when come back to the valid distance after beyond the broadcast range.

23. Auto-off: While in pairing mode, disconnect for over 2 minutes, the earbuds will quit the pairing mode automatically. Disconnect for over 12 minutes or battery voltage is lower than 3.05V, the earbuds will power off automatically.

Charge

Using a micro USB charging cable, plug in earbuds to charge.

LED Indication

- Power on: Blue LED flashes twice then power on
- Power off: Red LED lights up for 1 second then power off
- Pairing mode: Red and blue LED flash alternately
- Unconnected standby state: Blue LED flashes twice every 5 seconds
- Connected standby state: Blue LED flashes once every 10 seconds
- Calling state: Blue LED flashes once every 10 seconds
- Playing music state: Blue LED flashes once every 10 seconds
- Charging: Red LED is on
- Fully charged: Blue LED is on
- Low power state: Red LED flashes once every 10 seconds

Connecting to Bluetooth®

1. How to pair Bluetooth earbuds first time?
 - 1.1 Long press "MFB" for 5 seconds to see red and blue LED flashes alternately, the Bluetooth earbuds will automatically entering pairing mode.
 - 1.2 Turn on the Bluetooth function of your mobile phone, searching for "Camino earbuds" and click it to pair, after several seconds, a prompt tone will inform you connection is success, accomplishing Blue LED flashes slowly, your mobile phone will also show "Camino earbuds" is connected.
 - 1.3 If you are having problems, please restart the instructions listed above.
2. How to pair with Bluetooth earbuds again?
 - 2.1 Long press "MFB" for 2 seconds then release, the earbuds will be back into auto-connection mode, it will connect with the last connected cellphone automatically.
3. Other functions
While connected with iPhone, remaining battery power of the earbuds can be shown on the phone.

TTS Language

Earbuds status	TTS提示音 (中文)	TTS voice (English)
Power On	開機	Power On
Power Off	關機	Power Off
Pairing status	可配對	Pairing
pairing success	配對成功	Pairing success
Pairing fail	配對失敗	Pairing fail

mm 2.841

TTS Language

Low battery	請充電	Please charging
Last number redial	重撥	Recalling
End	結束	End
Language select	已選擇中文模式	English mode is select
Connected	已連接	Sot connect
Disconnect	已斷開	Sot disconnect
Show battery power	電量剩餘百分之十	Remaining ten percent power
	電量剩餘百分之二十	Remaining twenty percent power
	電量剩餘百分之三十	Remaining thirty percent power
	電量剩餘百分之四十	Remaining forty percent power
	電量剩餘百分之五十	Remaining fifty percent power
	電量剩餘百分之六十	Remaining sixty percent power
	電量剩餘百分之七十	Remaining seventy percent power
	電量剩餘百分之八十	Remaining eighty percent power
	電量剩餘百分之九十	Remaining ninety percent power
	電量剩餘百分之百	Full power

For Models That Use Lithium Batteries

- Lithium batteries can explore or cause burns if disassembled, shorted, recharged, exposed to water, fire, or high temperature and not handled appropriately.
- Do not place loose batteries in a pocket, purse, or other container containing metal objects, do not mix with used or other battery types, or store with hazardous or combustible materials.
- Store in cool, dry, ventilated area.
- Follow applicable laws and regulations for transport and disposal.
- Batteries not replaceable.

Please read and keep all safety and use instructions.

- Do NOT use the earbuds at a high volume for any extended period.
- To avoid hearing damage, use your earbuds at a comfortable, moderate volume level.
- Turn the volume down on your device before placing the earbuds in/on your ears, then turn the volume up gradually until you reach a comfortable, moderate volume level.
- Do not use the earbuds when it is being charged.
- Use caution and follow applicable laws regarding mobile phone and headphone use if using the earbuds for phone calls while driving. Some jurisdictions impose specific limitations, such as single earpiece configuration, on the use of such products while driving. DON'T use the earbuds for any other purpose while driving.

105 mm

105 mm

105 mm

mm 201

mm 201

mm 201