Intelligent Cloud Film Cutting Machine

(Bluetooth version)

User Manual

# Packing list

⑧ ⑨ ⑤ ④ ⑥ ⑩ ⑦ ① ② ③

Blade holder

Blade

Power adaper
(With Magnetic Ring)

Power cable

Warranty card

Auxiliary tools

1

① **Cutter carriage**
Control the knife to cut the film sheet

② **Rubber wheels**
Work with steel axis to keep cutting without slip

③ **Steel axis**
Work with rubber wheels to fix and protect film sheet

④ **Power switch**
Turn on the machine . Press it lightly to turn back the films during stand-by

⑤ **Switch for blade holder installation**
Press lightly to open the cover

⑥ **Film feeding sensor**
Auto feeding the film after detecting it

⑦ **Film pasting guide**
Please paste the films based on the guide

⑧ **Blade holder installatin port**
Open the port to take out or install the blade holder

⑨ **High definition screen**
6 inch touch screen , built in operation system

⑩ **Power connection port**
External 24v power port

一. Blade installation

11 Handle
Press it to get the blade

12 Gear
Adjust the blade tip length

13 Blade handle holder
To be fixed by the hole in cutting head

14 Cutting Blade
Cutting film sheet

Notes：
Ajust the blade：
Twist the gear to adjust the blade tip
Value bigger,tip longer
Value smaller, tip shorter
Factory setting is gear 6
Change blade：
Press handle
take out the old blade
put a new one in it

二. Blade holder installation

Press the button to
open the entrance

Open the fixed handle

Insert the holder
to hole straightly

Fix the handle

5 6 7

4

三. Power on / off

Connect the cable and adapter. 110-240V AC power for the plug connection. The adapter connects the machine. Press the power button, machine power on.

It takes 30s for starting.

5

四. Material installation

Put the material on the table flatly and align left based on the feeding guide

The material will be feed automatically after the cutter detect it. .

（If the film shift, press the switch in 1 second and the film will be returned back automatically）

四. Connect bluetooth

Scan it by browser

Choose the related phone system

Download on the App Store

Get it on Google Play

minicut

APP Installed

Note:Suggest to scan the QR code to download APP by web browser

7

五. Loggin account

Account:　　　　　语言

Password:

Count ∨

Line:1 ∨

LOGIN

REGISTER

Please alow all access persion during installing the APP, otherwise it may abnormal, detailed operation as below:
1. Login App and choose language.
2. Insert the account and password.
3. Choose count / Monethly fee.
4. Default is Line:1 , if the internet not good , please change to Line:2.
5. Click LOGIN.
6. Register (This function only for the user who without account)

Note: Please change the password in "My Account" after the first login.

8

五. Choose Cutting Data

Product

◄

| Mobile | Tablet | Watch | Custom |

Home　Product　Setting　Data　My account

Main categories

《　　　　**Mobile**

search 🔍　　**Record**

热门品牌：　　主要品牌：

Mi　Mi　Mi　　Mi　Mi　Mi　　Mi　Mi

Mi　Mi　Mi　　Mi　Mi　Mi　　Mi　Mi

ABCDEFGHIJKLMNOPQRSTUVWXYZ

Brands

9

Choose a cutting data

Front film | Back film | 防爆膜 | 全屏膜

《 IPHONE 13

search 🔍

Record

IPHONE 13 PRO-A   IPHONE 13 PRO

☐ 180 center cut   ☑ Y mirror

IPHONE 13 PRO

《 IPHONE 13 PRO

search 🔍

Force

- 300 + Test

定制背膜 ⇐ ⇒

Cut

10

Cutting finished

The sheet will be dropped out automatically

after cutting finished, please take out the

finished parts and paste on the phone.

11

六. Parameters and precautions

Parameters	
Connection	wifi or Bluetooth
Internal Power	DC24V 1. 75A
Machine size	420*123*163mm
Machine weight	4. 3kg

Don't touch the knife tip by finger
The finger may be hurt by the knife tip

Don't seep into liquid
This may cause fire or electric shock

Don't use non-original power supply
This may damage the cricuit or electric shock

Don't use in thunderstorm days
This may damage the machine

Don't use the non-standard materials
Please cut the standard size of material to reach the perfect result

Product parameters and precautions

Press power switch for emergency stop during working.

Forbid moving the carriage by hand after connecting the power to avoid machine damage.

Knife is a consumable part, please change to a new one if it is dull.

Press the power switch in 3 seconds continually to turn off the cutter, forbid taking out the power

cable directly to turn off the machine because it will damage the mainboard

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received

including interference that may cause undesired operation.

FCC Warning

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and

if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.