QUICK START GUIDE

Indoor WIFI Pan-Tilt Camera User Manual

SightSys

English

Connection Diagram

1. Insert the Micro SD card into the SightSys IP Camera or Google Play/Apple/Amazon Store/ Download the SightSys app and follow the prompts to complete the registration.

2. Connect the network cable to the IP camera and power on the camera.

Pairing Mode

1. Open the SightSys app, click "Add Device" to enter the pairing mode.

2. Scan the QR code on the device, or manually enter the device UID to add the device.

Pairing Failure

1. Ensure the camera is powered on and connected to the network.

2. Check the network connection and ensure it is stable.

3. Ensure the device UID is correct.

Scan the app QR Code, or visit APP Download Website:

http://www.sightsys.com/app/download.html

Download the app from the App Store or Google Play Store, search for "SightSys", and download it.

Create an account and log in to the app.

Click the "+" button in the app, select the corresponding device type, and follow the prompts to complete the device pairing.

Ensure the camera is powered on and connected to the network.

Ensure the app has permissions for camera, location, and Bluetooth.

Ensure the device UID is correct.

Restart the app and try again.

Ensure the device is within the app's Bluetooth range.

Check the network connection and ensure it is stable