# SW06 Smart Watch
User Manual

Please refer to this manual before using the product.
V1.0

Notes:
 1.The company reserves the right to modify the contents of this manual without any further notification. It is normal that some functions may vary in different software versions.
2.Please charge the smart watch with configured charger for no less than 2 hours before use.
3.Please install and connect to suggested App and set personal information before use. Please refer to below guidance and use the smart watch properly.

01 Wearing method

Please wear the device on your wrist horizontally, about one finger from the carpal and adjust to a comfortable position. Below picture for reference. Note: Please wear the device a bit tighter when making heart rate testing.


power button

workout mode button

02 Download App and Pairing

1.Long press the power button to turn on the device, slide down from main interface, open setting- App Download, and use the mobile phone to scan the code. Or you can also scan below QR

code or search for "GloryFit" in App store.

2. Open the App and BT, search and select the corresponding device on App as guided.

Notes:

1.Please keep BT on during paring to ensure successful connection.

2.Please long press power button 3s to reboot the device if couldn't find the device during paring. Or choose reset on the device and search the device again.

03 Operation

a.Shortcut Setting Page: Swipe down from homepage.

b.Message: Swipe up from homepage.

c.Main Menu: Swipe right from homepage.

d.Function Shortcut Interface: Swipe left from homepage.

e.Watch Dial Setting: Long press dial for 3s and slide left or right to choose.

f.Power ON/OFF: Long press power button for 3s to power on; From home page, long press power button 3s, and tap√ to power off.

g.Return Previous Menu/ Screen On or Off: Press power button.

h.Sports Shortcut key: Press the below side button to quickly switch to training interface.

04 Functions

	Training: 13 sports modes Running, Walking, Cycling, Climbing, Spinning Bike, Yoga, Skipping, Gymnastic, Badminton, Ping-pong, Boating, Sit-ups and Free training. Sports records are visible on the App.
	Pedometer: Record daily steps, distance, and calories. Historical data are visible on the App.
	Heart Rate Monitor: Click and show real-time heart rate. Auto test open on App. Intermittent automatic detection generate histogram, interval unit is 10 minutes. Historical data and analysis are visible on the App.

	Blood Oxygen Monitor: Test the blood pressure. Historical data and analysis are visible on the App. (Data cannot be used for medical purpose)
	Weather: After connected with App, Show daily weather and next 4 days' weather forecast.
	Sleep Monitor: Record daily sleep time and deep or light sleep duration. History records are visible on the App.
	BT Music Control: Remote control the music player of mobile phone, Play/ Pause/ Switch to previous or next song.

09:50 Notice: Venue 5 is scheduled for Friday from 6pm to 8pm. **09:28** Fang Fang: please carry the Alipay healthy green code ...	**Message:** Notifications push sync, show 8 latest messages on watch. Turn on/off SMS reminder and SNS App reminder on App.
Find Phone Stopwatch Timer	**More:** Find Phone, Stopwatch, Timer.
Off Reset Bright	**Settings:** Power off/ Reset/ Brightness /Dial / App download/ About the watch.

05 Other functions

Sedentary reminder, alarm clock reminder, low battery reminder, incoming call reminder, find watch, find hand Machine, online dial/custom dial, 12/24 time system, unit setting, wrist light up

Screen, menstrual cycle reminder, goal achievement reminder.

06 Charging

1. Connect the charging cable to the charging port of the watch and make sure that the metal pins are fully connected. If the charging cable cannot be connected to the magnetic metal contacts of the watch, please turn the charging cable over to reconnect and charge.

2. Please use 5V 1A charging adapter to charge the watch.

Note: If the smart watch cannot be turned on after a long period of non-use, or the smart watch cannot be charged, please check whether the charging metal pins of the watch are blocked by dirt, please clean it up and make sure the connection is good.

07 Warranty

1. When this product is in normal use, if it is caused

by manufacturing, material, design, etc.
Product quality problems from the beginning, from the date of purchase, the motherboard is guaranteed for free within one year.The battery and charger are guaranteed for half a year.
2. The free warranty is not provided for failures caused by the user's personal reasons, as follows:
1). Failure caused by unauthorized disassembly or modification of the watch.
2). Failure caused by accidental fall during use.
3), all man-made damages or due to the third party's fault, misuse (such as: water in the host, external shock Cracks, scratches on peripheral components, etc.) are not covered by the warranty.
3. When the user repairs the product, please contact us for warranty service.
4. All functions of the product are based on physical objects.
Tips:
1. In order to ensure the waterproof performance of the product, please do not remove the screws on the back cover of the watch without authoriza-tion,or soak in hot water, hot tea and other corrosive liquids.
2. This product contains lithium batteries. When recycling the product, please be sure to put it in the designated battery recycling point.

NOTE: This equipment has been tested and found to comply with the limits for a
Class B digital device, pursuant to part 15 of the FCC Rules. These limits are
designed to provide reasonable protection against harmful interference in a
residential installation. This equipment generates uses and can radiate radio
frequency energy and, if not installed and used in accordance with the instructions,
may cause harmful interference to radio communications. However, there is no
guarantee that interference will not occur in a particular installation. If this
equipment does cause harmful interference to radio or television reception, which
can be determined by turning the equipment off and on, the user is encouraged to
try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the
receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved

by the party responsible for compliance could
 void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.
 Operation is subject to the following two
conditions:
 (1)   this device may not cause harmful
interference, and
 (2)   this device must accept any interference
received, including interference that may cause
undesired operation.

FCC ID:2A4QK-SW06

Warranty Certificate

Client Info			
Product Type		Vendor	(Stamp)
Client Name		Contact Info	
Vendor's Contact		Purchase Date	
Product IMEI Code			
Client's Address			
Vendor's Address			

Warranty Record

Date	Problems	Diagnosis	More Info