产品说明书 尺寸:50x75mm 材质:80g布写纸 双面印刷 风琴折

真无线耳机

使用说明书
使用前请阅读使用说明书

产品规格

产品型号:A60
蓝牙版本:V5.4
有效距离:约10米
喇叭直径:φ14.2mm
阻抗:16Ω
频率响应:20Hz-20KHz
麦克风灵敏度:-42dB±1dB
耳机额定输入:5V⎓50mA
充电仓额定输入:5V⎓300mA
充电仓额定输出:5V⎓100mA
耳机电池额定容量:50mAh
充电仓电池额定容量:380mAh
使用时长:约7小时(耳机)
耳机充电时长:约1.5小时
充电仓充电时长:约1.5小时

物品清单

欢迎使用
入耳式TWS蓝牙耳机

取出并配对
第一次使用时,请同时取出左右两侧的耳机。
耳机自打开未蓝灯交替闪烁,耳机将自动配对。

如何正确佩戴耳机



产品说明

触摸操作

使用蓝牙设备连接

打开准备配对的蓝牙设备的蓝牙设置选项,进入选项,找到耳机的蓝牙配对名"A60",
点击配对收希请讨配对。

开机
自动开机:将耳机从充电仓取出,耳机开机,提示音"嘟"四声。
手动开机:耳机关机的状态下(充电仓外),长按耳机多功能触摸键约2秒钟,耳机开机,提示音"嘟"四声。

关机
自动关机:将开机状态下的左右耳机直接放入充电仓,耳机关机,提示音"嘟"四声。
手动关机:长触左子耳机状态下的左右耳机多功能触摸键约6秒钟,耳机关机,提示音"嘟"四声。

注:当耳机开机后,3分钟未与相应蓝牙设备进行配对连接,便会自动关机,若曾经有相连接耳机,未与相应蓝牙设备连接,3分钟后,耳机自动关机,提示音"嘟"四声。

单击

双击

三击

长按

游戏模式与音乐模式切换

*备注1:单耳使用时,无法切换游戏模式和音乐模式
*备注2:出厂设置默认为音乐模式

指示灯说明

-耳机开机:白灯和冰蓝灯交替闪烁。
-耳机关机:白灯闪烁由暗变亮。
-配对成功:主蓝白灯和冰蓝灯交替闪烁,耳机灯灭。
-连接成功:灭灯。

-耳机充电:充电仓指示灯红常亮。
并且耳机白灯常亮,充满电后耳机白灯转为冰蓝灯熄灭,同时充电仓指示灯熄灭。
-充电仓充电:充电仓指示灯冰蓝灯闪烁,充满电后,充电仓指示灯常亮。

清除蓝牙配对历史记录

双耳从充电仓取出后自动开机配对,耳机未与蓝牙设备连接或耳机从蓝牙设备断开连接状态下,分别打开耳机右耳机连续五次多功能键,提示音"嘟"四声后,耳机自动关机后将双耳机放回充电仓,再将双耳机取出,双耳机自动配对,完成后即可连接蓝牙设备使用。
适用于以下情况:
A.双耳无法配对时,单边音时,双配对时。
B.使用单耳机分别连接不同蓝牙设备时。
C.声音连续的所有蓝牙设备时。

特别提示:
当单边耳机出现无声,或者无法配对时,
请按以上恢复重置操作。

产品中有害物质名称及含量

产品中有害物质的名称及含量

部件名称	有害物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
印刷电路组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。
○:表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572 规定的限量要求以下。
×:表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572 规定的限量要求。
表单标记"×"的部件,皆因全球技术发展水平限制而无法实现有害物质的替代。

印刷电路板组件:包括印刷电路板及其零部件。
电子元器件等,根据产品型号不同。
您所购买的产品可能不会含有以上所有部件

产品注意事项

(1)除说明书特殊标示的操作方式以外,请勿尝试拆卸更换产品内的任何零件。
(2)本产品含内置可充电电池,禁止撞击,挤压,刺破,短路等动,若出现温度过高,变形,膨胀,漏液等异常现象,请停止使用,请勿置电池于明火,阳光曝晒,加热器,大功率电源及以及高压环境中,电池浸水后禁止使用,耳机使用后,您的耳机放在潮湿,充满灰尘,油烟,易气,阳光直射等高温高压等环境中,以免造成耳机及电池损坏。
电池可充换电次数有限,最终会老化,电使用异常时可更换新电池,但切勿自行更换电池,如果电池更换不当会有爆炸危险。
只能通过售后服务更换同等类型或者等效类型的电池使用。
(3)产品使用期限后,四年产品的更换件,废弃物处理应严格按照位当地表行政法律,请合理正确的使用此产品。
以免造成一定的伤害和环境破坏。
(4)在耳机使用过程中,由于远距离,中间有障碍物或者有其他无线电信号,蓝牙信号,WIFI信号等一系列的干扰的情况下,耳机在使用时可音乐,看视频,玩游戏等情况下,会出现掉线的现象,请您不用担心或者担心情况。
如出现此情况请重新连接耳机或者必须干扰物。
(5)充电时充电器请使用输出电压为直流DC 5V/1A的充电设备,必须选择正规生产厂家获得CCC安全认证过的充电设备。
请勿使用快充充电器,以免造成电池包裂太大,而产生电池损坏,造成充电时间延长或正常的充电时间,充电时间变慢等,以免造成损坏。

完全没有效使用指南

①电磁干扰:
电子设备:为避免电磁干扰或配配不兼容的影响,请在标书明确指示的场所中使用效宜关闭您的蓝牙设备。
医 院:登机后,请根据乘务人员的提示关闭您的蓝牙耳机。
飞行中严禁使用蓝牙耳机,以免对飞机通信系统产生干扰。
②安全事项:
放 置:请以您在不使用蓝牙耳机时,将其放置在干燥恒压的地方,防压有可能会导致产品的损坏或人身的伤害。
儿 童:不要让儿童玩弄蓝牙耳机,某一些小部件可拆卸,有可能被吞咽而造成危险。

True Wireless Headset

Wireless Earbud
A60 Product Manual

Specification of Product

Model of Product: A60
Version: V5.4
Effective Distance: Approx. 10m
Speaker Diameter: φ14.2mm
Impedance: 16Ω
Frequency Response: 20Hz-20KHz
Microphone Sensitivity: -42dB±1dB
Earphone Input: 5V⎓50mA
Charging Case Input: 5V⎓300mA
Charging Case Output: 5V⎓100mA
Earphone Battery Capacity: 50mAh
Charging Case Battery Capacity: 380mAh
Duration: Approx.7H (Earphone)
Earphone Charging Time: Approx. 1.5H
Charging Time of the Charging Case: Approx. 1.5H

Item list

Welcome to the
In-Ear TWS Bluetooth Headset

Take out and pair it
When using for the first time, take out the left and right earphones at the same time. When the white light and ice blue light of the earphones flash alternately, the earphones will enter the automatic pairing mode.

How to wear headphones correctly





Product Description



Touch Operation

Connect with Bluetooth device

Open the Bluetooth settings option of the Bluetooth device to be paired, enter the options and find the Bluetooth pairing name of the headset "A60". Click the pairing name to pair.

Indicator Light Description

- When the headset is turned on:the white light and the ice blue light flash alternately
- When the headset is turned off: the white light flashes 3 times quickly and then goes out
- Successful pairing: the white and ice blue lights in the primary ear flash alternately, and the light in the secondary ear goes out.
- Connection successful: no light

- Headphone Charging: The charging case indicator light is always white, and the headset white light is always on. After the headset is fully charged, the white light turns to ice blue and then goes out, and the Charging case indicator light goes out at the same time.

- Charging of the Charging case: The ice blue light of the Charging case indicator flashes.After the Charging case is fully charged, the indicator light of the Charging case is always on.



Power On
Auto power on: The Earphone are taken out of the charging case, the Earphone will be powered on, with the prompt sound of "Du".
Manual power-on: Long press for 3 seconds, the Earphone will be powered on, with the prompt sound of "Du".

Power Off
Auto power off: Put the Earphone in the charging case, the Earphone will be powered off, with the prompt sound of "Du".
Manual power off: Long press for 5 seconds, the Earphone will be powered off, with the prompt sound of "Du".

Note: After powering on, if it is not paired with a Bluetooth device for 3 minutes, it will automatically shut down; If it is not connected to a Bluetooth device after 3 minutes, it will automatically power off after 3 minutes, with the prompt sound of "Du".".

Once Press

Double Press

Long Press

Wake up voice assistant
When using both ears, press and hold the left ear multi-function button for 2 seconds to activate the voice assistant.
When using one earphone, press and hold the left (or right) earphone for 2 seconds to activate the voice assistant

Phone mode
Press and hold the left (or right) ear multi-function button for two seconds: call rejection

Triple Press

Switch between game mode and music mode (Mono/Binaural operation)

Note 1: When using one earphone, you cannot switch between game mode and music mode.
Note 2: The factory setting defaults to music mode

Clear Bluetooth pairing history

When both ears cannot be paired, you need to clear all connected devices and click the left and right earphones 5 times at the same time.

Wireless pairing mode

1. When there is no pairing record for the left and right earphones, the left and right earphones will automatically pair after they are turned on. After successful pairing, there will be two beeps.
2. When the left and right earphones have pairing records, they will automatically connect back when they are turned on, and the prompt will sound "beep"

FCC Statement
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has evaluated to meet general RF exposure requirement. The device can be used be in portable exposure without restriction.