封面

TELESIN

MASTER GRIP

大师影像套装

User Guide / 使用指南

封面背面

ReefColor TELESIN

Scan to download ReefColor and access hidden tricks for your Master Grip
扫描下载珊瑚色App，解锁更多隐藏玩法

封底

www.telesin.com

目录

Contents
目录

中文 1
EN 13

中文

简体中文

前言

感谢您购买Telesin产品。

重要提示

- 为您购买产品前，请仔细阅读本手册。
- 请妥善保管本手册，若购他用户需要使用本产品，请随产品一并提供本手册。
- 请注意本用户手册中的所有警告，并遵循所有指示。
- 请勿拆卸或修改本产品，用户应自负责任。请立即停止使用。
- 请将本产品放置在儿童触及不到的地方。

产品介绍

大师影像手柄（移动电源）

1. 操作指示灯
2. 摄像按键
3. 按键键
4. 变焦滑杆
5. 快门键
6. 热启键
7. 指挥指示
8. 1/4"螺纹孔
9. 录像按键
10. 充电开关键
11. 充电指示灯×4
12. USB-C充电孔（输入/输出）
13. 腕带安装位
14. 石墨烯

操作说明

1.首次使用，将手机安装到配套手机夹中。

2. 将腕带长绳穿孔手机背面。

3. 长按拍照键 2秒开机，点击蓝牙名称TELESIN_IP连接，若30分钟未连接则自动关机。

4. iPhone连接蓝牙后可使用拍照键，首次使用其他按键功能，请进行如下操作：
进入设置——辅助功能——触控——指挥区域全屏幕增加>>>打开指挥。

• 打开"指挥"时最后在开启，三指双击屏幕即可恢复，其他设置无需更改。

按键说明

序号	功能	操作	操作指示灯灯显
1	开机	长按拍照键2秒，进入蓝牙配对状态。	指示灯闪烁

序号	功能	操作	操作指示灯灯显
2	关机	开机状态下，长按拍照键3秒可关机，休眠状态下按键30分钟自动关机。开机后，30分钟内无配对则自动关机。	指示灯灯显3下
3	开始/停止拍摄	短按拍照键。	指示灯闪烁1下
4	变焦	向左推变焦杆缩小；向右推变焦杆放大。	/
5	前后摄像头切换	短按拍照键。	/

序号	功能	操作	操作指示灯灯显
6	模式切换	向左或向右按模式按钮。	/
7	拍照按键	在手机处于拍摄状态下，长按2秒拍照按键即可拍照。	/
8	录制过程中拍照	在短摄或延时状态下，短按录制按键即可，拍照中断录制。	/
9	对焦	半按拍照按键	/

进入休眠状态

1.蓝牙配对后，若开机60分钟后无操作，自动进入休眠。

休眠唤醒

休眠状态下，单击任意按键即可唤醒。

1. 休眠唤醒后，如上一次比配对手机蓝牙连打开状态，直接自动连接。

2. 如果上一次比配对的手机蓝牙未连，每次打开相机0秒2分钟后无配对，进入休眠状态，30分钟后关机。

低电量提醒

低电时，所有指示灯状态为红色，电量低于20%，请注意充电。

磁吸充电

1. 将手机放置在磁吸充电处，短按充电开关开始为手机充电，双击充电开关停止为手机充电。

2. 手柄充电原理时，充电电灯显示下：

电量	LED1	LED2	LED3	LED4
手柄充电时				
100%-75%	✓	✓	✓	X
75%-50%	✓	✓	X	X
50%-25%	✓	X	X	X
低于25%	闪烁	X	X	X

电量	LED1	LED2	LED3	LED4
手柄充电时				
低于25%	闪烁	X	X	X
25%-50%	✓	闪烁	X	X
50%-75%	✓	✓	闪烁	X
75%-100%	✓	✓	✓	闪烁
100%充满	✓	✓	✓	✓

磁吸补光灯安装

将补光灯磁吸固定到它在手柄正面引磁环处，磁吸补光灯使用说明请参考镜面补光灯说明书。

*长按数秒不方便操作，如需要滤镜请到TELESIN官方或授权渠道购买。

滤镜安装

将方形滤镜或圆形滤镜按说明，按照顺头方向插入镜头处。

*长按数秒不方便操作，如需要滤镜请到TELESIN官方或授权渠道购买。

产品参数（大师影像手柄 移动电源）

材质：ABS+PC+铝合金
产品尺寸：121 x 63 x 89mm
产品重量：180g
显示屏规格：0.96
锂电池容量：3200mAh
充电规格：Type-C 5V⎓2A
输出规格：Type-C 5V⎓2A
充电周期：1.5W/10W
最高工作温度：25℃

安全声明

1.仅适用在整个操作过程温度，分清楚移动电源的整个使已作用，分清楚自己的设备使用自己类型，电源使用不当，会损坏电池或使用者电源设备。
2.在第一次使用前，必须使用标准的5V⎓的充电器给电源充电，以保证电，本产品出厂电池可以，充满电后不要使用本产品，为保证电芯的使用寿命，最好至少只对本产品进行一次充放电。
3.请勿要非使用电源适配器充电，则会导致发生使用电源适配器安全标准要求的电源适配器或者是保证CCC认证的电源适配器当充电完毕或者不再充时，请拔开与设备的连接并从电源插座上断开电源。
4.请勿使用污损有机燃烧物，如果不正确使用电源，会发生短路，漏液，过热等，使电池永久性损坏，电源内置有安全保护装置。

5.请在所有生成设备的要在加热设备的周围，如周围护理等或散热器等，电池过热可能引起爆炸，请在所解或或某电池以使用或电池漏液，过热，起火或爆裂，如果电池漏液，请不要使其接触眼睛或皮肤，如果发生接触，请用清水冲洗，并到医院进行处理，如果电池漏液或发出异味，请立即停止使用，并将其从火源移开，以免发生爆炸或火灾。
6.请不要将产品放置于高温环境中，高温强烈的太阳光下，不要将产品放置火中或者能将高温环境中不要放置在有火或者火源，或者是放置于动力汽车的发电设备。
7.如果使用电源适配器充电，电源的安全保护参数及指标会低于，使用电源不能正常地使用，从而使用电源无法充电，大只法使用。
8.不能使用重物或者低的物体挤压电源使用安全。
9.如果使用非标准的充电器，或者用非标定的充电器参数，会使电池发生过热，使用时爆炸。
10.使用过程中发生产生异味，变形，破损，剧烈或其它问题，请立即停止使用并联系售后或生产商。
11.请勿将电源放置在儿童或宠物可触及的地方，如果吞咽，用医疗帮助。
12.注意，用户自己的设备使用前请检查，如发现损坏请勿使用，请联系售后。
13.不要用产品直接倒入垃圾桶，请将产品送回专业回收中心。
14.不要自拆或尝试改装修本产品，不要私自更换产品的零配件。

警告

1.仅适用于非热带气候条件下安全使用

2.请水自禁止使用。
3.消费者若使用电源适配器充电,则应购买配套使用获得CCC认证并具有质量更好的电源适配器。

免责声明

请仔细阅读本声明。一旦使用本产品，即视为对本声明的全部认可和接受。每次使用前，请仔细检查产品是否完整、完好、是否使用。使用本产品，即意味着您认可并同意，您将对使用本产品的行为和可能产生的后果负全部责任。您承诺仅会以正当合法的目的使用本产品，切勿解开拆装，对于直接或间接因使用本产品而造成的损害，不利影响，损害，伤害，引起或者其他法律责任，本公司对，不承担任何责任。
请注意，用户自己的设备使用前请检查，如发现损坏请勿使用，请联系售后。
如果您对本声明有疑问，请联系Telesin官网。

本产品保留最终解释权。

英文

English

Preface

Thank you for purchasing Telesin products.

Important Notes

- Read this manual carefully before using the product.
- Keep this manual secure. Provide it to other users when sharing the product.
- Follow all warnings and instructions in this manual.
- Do not disassemble or modify the product. If malfunction or water ingress occurs, stop using immediately.
- Keep the product out of reach of children.

Product Introduction

Pro Shot Imaging Grip

1. Operation Indicator Light
2. Screen Wake-Up Key
3. Capture Key
4. Zoom Lever
5. Mode Switch
6. Fn Key
7. Thumb Rest
8. 1/4" Threaded Mount
9. Wrist Strap Hole
10. Power Switch
11. Charging Indicator Lights ×4
12. USB-C Port (Input/Output)
13. Magnetic Charging Port
14. Magnetic Ring

Operation Instructions

1. First-Time Setup, install the phone into the included phone case.

2. Attach the magnetic handle to the back of the phone.

3. Press and hold the Capture Key for 2 seconds to power on. Connect via Bluetooth (Name: TELESIN_IP).

4. iPhone: Bluetooth enables shutter only. First use of other functions requires enabling Zoom in Settings > Accessibility
Go to Settings>Accessibility>Zoom>ZoomRegion>Full Screen Zoom>Turn on Zoom

• (Double-tap with 3 fingers to restore).

Button Functions

No.	Function	Operation	LED Behavior During Charging/ Discharging
1	Power On/Off	Press and hold Capture Key for 2 seconds.	(Blinking → Solid) → Off after 30 mins

No.	Function	Operation	LED Behavior During Charging/ Discharging
2	Power Off	Press and hold Capture Key for 2 seconds in On/Sleep mode; Auto-off after 30 mins of sleep or 30 mins of no pairing.	Fast flash 3x then off
3	Start/Stop Recording	Short press Capture Key.	Blink once
4	Zoom	Slide Zoom Lever left (zoom out) or right (zoom in).	N/A
5	Camera Switch	Short press Screen Wake-Up Key	N/A

No.	Function	Operation	LED Behavior During Charging/ Discharging
6	Mode Switch	Slide Mode Dial left/right.	N/A
7	Screen Wake-Up	Press and hold Screen Wake-Up Key for 2 seconds in sleep mode.	N/A
8	Capture During Video	Short press Fn Key (pause recording); double-tap Fn Key (pause recording).	N/A
9	Focus	Half-press the capture key.	N/A

Entering Sleep Mode

Auto-Sleep: 60 minutes of inactivity after pairing.

Waking from Sleep Mode

Press any button to wake up.

1. Auto-reconnects if last paired phone's Bluetooth is on.

2. If the previously paired phone's Bluetooth is off and there's no pairing within 0 mins, the device will enter deep mode and turn off after 30 mins.

Low Battery Alert

Red LEDs indicate <20% battery.

Charging

1. Place the phone on the magnetic charging pad. Briefly press the charging switch to start charging the phone. Double-click the charging switch to stop charging.

2. When the handle is charging/discharging, the charging status lights display as follows:

State	LED1	LED2	LED3	LED4
Charging				
100%-75%	✓	✓	✓	X
75%-50%	✓	✓	X	X
50%-25%	✓	X	X	X
<25%	Blink	X	X	X

State	LED1	LED2	LED3	LED4
Charging				
<25%	Blink	X	X	X
25%-50%	✓	Blink	X	X
50%-75%	✓	✓	Blink	X
75%-100%	✓	✓	✓	Blink
Fully Charged	✓	✓	✓	✓

Filter Installation

Place the square or circular filter adapter ring flat and insert it into the lens slot following the arrow indicators.

*Note: Filters are not included in the standard package. Purchase compatible filters through TELESIN official or authorized channels.

Magnetic Fill Light Installation

Attach the magnetic side of the fill light to the magnetic ring on the front of the handle. For detailed usage instructions, refer to the magnetic fill light manual.

*Note: Magnetic fill lights are not included in the standard package. Purchase separately via TELESIN official or authorized channels.

Wrist Strap Installation

In complex environments or high-traffic scenarios, always use a wrist strap. Do not use the product for high-impact sports activities.

Technical Specifications(Pro Shot Imaging Grip)

Material: ABS+PC+Aluminum Alloy
Dimensions: 121 x 63 x 89mm
Weight: 180g
Bluetooth Range: 10 meters
Lithium Battery: 3200mAh
Type-C Charging: 5V⎓2A
Type-C Output: 5V⎓2A
Magnetic Charging: 1.5W/10W
Operating Temp: ±25℃

Safety Declarations

1. Due to sensitivity of components inside the packaging, distinguish the functions of each port on the power bank, and recognize the types of interfaces used by your device. Improper use of the power supply may damage the battery and devices powered by it.
2. When first using the product, after fully charging it, it must be charged with a standard 5V⎓2A charger. For daily maintenance, since this product has very low self-discharge, if it is not used for an extended period, perform a full charge-discharge cycle every 3 months to ensure the service life of the battery cells.
3. This power pack contains organic combustible materials. Improper use of non-standard chargers or improper charging methods may cause short circuits, permanent damage to the battery. The power supply is equipped with built-in safety protection mechanisms.
4. Do not place the battery or device near heating appliances (e.g., microwaves, ovens, or radiators). Overheating of the battery may cause explosions. Do not expose the battery to high temperatures, which may lead to leakage, overheating, fire, or explosion. If the battery leaks, avoid contact between the liquid/liquid and skin or eyes. If exposed, rinse immediately with clean water and seek medical treatment. If abnormal heating or other anomalies occur during use, charging, or storage, cease use immediately. Do not continue using the charger if its power cord is damaged to avoid electrical hazards.
5. Do not place the product in high-temperature environments (including direct sunlight). Do not place it near fire sources or in other high-temperature conditions, and do not use the power supply near open flames, stoves, or in vehicle power generation equipment.
6. If the power supply is submerged in water, its safety protection parameters and indicators will be damaged, rendering it inoperable. Immediately stop charging and dry the device before use.
7. Do not use heavy objects or other items to crush the power supply, as this may cause deformation.
8. Using non-standard chargers or modifying the specified charge parameters may cause the battery to overheat, overload, or explode.
9. If the battery pack or device emits a strange smell, deforms, or exhibits other issues during use, immediately cease use and contact the seller or manufacturer.
10. Do not throw the device into fire, as this may cause the battery to catch fire or explode. Replacing the battery with incorrectly sized batteries poses a fire or explosion risk. Do not disassemble or modify the product. Do not discard the battery pack into fire or heating furnaces, subject it to mechanical crushing or cutting, or expose it to extremely high temperatures or low pressure environments, which may cause explosions. Do not use the battery pack may also explode or flow flammable liquids/gases under extreme conditions.
11. Note: Replacing the battery with incorrectly sized batteries poses an explosion risk. Do not disassemble or modify the product. Do not discard the battery pack into fire or heat furnaces, subject it to local professional recycling centers.
12. Do not disassemble, modify, or attempt to repair it, and do not replace components without authorization.

FCC Caution

15.19 Labeling requirements.
This device complies with part 15 of the
FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
15.21 Information to user.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
15.105 Statement.
The device was evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

15.105 Information to the user.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
TRF warning for Portable device
The device was evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

IC Statement

English
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
French
Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
(1) Cet appareil ne doit pas causer d'interférences.
(2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.
Tout changement ou modification non expressément approuvé par la partie responsable de la conformité pourrait annuler l'autorité de l'utilisateur à utiliser l'équipement.
Declaration d'exposition RF:
L'appareil a été évalué pour répondre aux exigences générales en matière d'exposition aux RF. L'appareil peut être utilisé en condition d'exposition portable sans restriction.

Federation of Conformity

PMN:Pro Shot Imaging Grip
HVIN:RL-MCS-10-V1.1

Disclaimer

Please read this statement carefully. Once you use this product, it is deemed that you fully recognize and accept this statement. Before each use, please carefully check the product. If it is damaged or incomplete, do not use it. When using this product, you acknowledge and agree that you will be fully responsible for the actions and possible consequences of using this product. You promise to use this product for legitimate purposes only. You acknowledge and agree that Telesin Digital Co., Ltd. (hereinafter referred to as "Telesin") will not be liable for any abuse, adverse effects, damages, injuries, legal liabilities, or other consequences arising from or caused by the use of this product. Users should follow the usage precautions mentioned herein and others. Within the scope of national laws and regulations, the right to interpret and modify this commitment belongs to Telesin. The Telesin warranty period starts on the day you receive the goods and enjoys a 6-month warranty service.