56x96mm

Rangland
DO IT OUTDOORS

Golf Cart Speaker

User Manual

Specifications and Parameters

3.94in   2.28in

Model:

|	
Version:	5.0
Range:	≥30m (Open area)
Battery:	1800 mAh
Power:	12W
Power Supply:	USB Type-C 5V/2A
Frequency Range:	80Hz-16KHz
Playtime:	≥8 hours (@50% volume level)
Charging Time:	2 hours
Dimensions:	3.94*3.94*2.28 in
Weight:	398g
Frequency:	2402-2480MHz

Accessories

3.5 mm AUX cable   Type-C cable

Buttons and Functions

① Status Indicator light
② TWS Indicator light
③ Power
④ Volume down /Previous track
⑤ Play/Hang up
⑥ Volume up/Next track
⑦ Type-C charging interface
⑧ TF card slot
⑨ AUX-in port

Operation   Function description

⏻	Short press	1. In the off state, short press it to turn on 2. In the on state, press to switch music playing modes between、 Aux-in and TF card mode
	Long press	In the on state, long press to turn off
	Double click	When both devices are not connected to, double-click one of them to enter the TWS pairing mode
—	Short press	Volume down,total 16 levels
	Long press	Previous track
▷	Short press	1. Music playback state: play, pause function 2. Call state: short press to connect 3. When the call is answered,short press to hang up 4. When the phone's is connected: Double-click quickly to call back the the last call made by the phone
	Long press	1. Call state, long press for 2s to reject the call 2. When the is connected, long press for 2s to disconnect 3. When the is connected, long press for 6s to clear all devices
＋	Short press	Volume up ,total 16 levels
	Long press	Next track

Pairing

When the power is turned on and the blue light on the left side of the speaker is flashing slowly, open the list of the mobile phone and find" BT150 " and select Pair. After the pairing is successful, the blue light will stay on.

LED Indicator

1. On the left side, the blue light flashes slowly during pairing, and stays on when the is connected.
2. On the left side, the blue light is always on when TF card is used, breathing during playback, and always on when it is paused.
3. On the left side, the red light turns on when charging, and goes off when fully charged.
4. On the right side, it is TWS yellow light, the device enters pairing when it is flashing slowly, and enters TWS mode when it is always on.

TF Cable/Aux-in Mode

1. The speaker supports reading up to 64GB TF card, and supports the following music formats: APE/FLAC/WAV/MP3.
2. Insert the TF card into the card slot, and the audio files will be automatically played after being recognized.
3. The play can be started after the AUX or Type-C cable is plugged into the device,if the is connected, press the " ⏻ " key to switch to the audio cable mode.
(Note that when using Type-C cable to connect and play, please use the original cable or a cable that supports audio transmission)

TWS Pairing Instructions

1. Turn on the two speakers (if a device is connected, you must fist disconnect the device)
2. Double-click one of the " ⏻ " keys to enter the TWS pairing mode
3. After the TWS is successfully paired, there will be a beep. At this moment, the yellow indicators of the two speakers stay on, the blue light of the main unit is flashing, waiting for the mobile phone to connect, and the blue light of the auxiliary unit turns off
4. Turn on the function of the mobile phone or other device, find and connect the device named " BT150 "
5. TWS paired successfully,the machine will automatically perform TWS pairing each time after turing on the machine, no need to repeat the operation
6. If the machine has been paired with TWS, please press and hold the " ▷ " key for 6 seconds to reset. After the reset is successful, restart the device, and then refer to the above steps 1~4 to complete the TWS pairing
7. In TWS mode, only the main speaker has hands-free function and the sub-speaker is silent during a call.

FCC warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.