BL-06 INSTRUCTION MANUAL

DO NOT PRINT THIS LAYER

PRINT BACK TO BACK

Folded Size: 3.2” (w) x 3.5” (h)

DIELINE:

FOLDING LINE:

PANTONES:

PANTONE White C	PANTONE Black C	PANTONE 432 C
PANTONE 656 C	PANTONE 2915 C	PANTONE 286 C

FOLDING INSTRUCTIONS



FRONT

iHip

Bluetooth®

True Wireless
EARBUDS

with LED Charging Case

USER MANUAL:
Retain these instructions for future reference.

iHip 19 Progress St. Edison, NJ 08820 www.iHip.com | #iHip | iHip: Portable Entertainment

© 2023 Zeikos, Inc. iHip is a trademark of Zeikos, Inc., Registered in the U.S. and other countries. The illustrated product and specifications may differ slightly from that supplied. Apple, iPod, iPhone, iPad and Siri are registered trademarks of Apple Inc. Android is a trademark of Google LLC. All other trademarks and trade names are those of their respective owners. United States and international patent pending. All Rights Reserved. For ages 12+up. This is not a toy. For warranty information please visit www.ihip.com. Designed by iHip, Manufactured in China.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by "iHip" is under license. Other trademarks and trade names are those of their respective owners.

Limited One-Year Warranty. To activate your product warranty go to our website www.iHip.com and register this product.

Important Information:

Protect the environment by responsibly disposing of your product. The wheelie bin symbol indicates that the product must not be disposed in the domestic waste as it may contain substances that could be harmful to the environment and health. Please use proper recycling facilities when disposing of the item.

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Safety Precautions:

- Keep the earbuds away from dust, oil, and water. Store in a dry and ventilated environment to avoid product performance issues.
- If there is a connection issue or function issue, please do not replace any of the accessories, otherwise the warranty will not be valid.
- Please use the standard charger that is supplied with the product.
- Please fully charge your product before first use.
- High volume use may affect your hearing.
- Do not use while driving or cycling. Take precaution when walking the street.
- Do not put heavy weight or pressure on the earbuds as it may cause damage.

Warning:

1. Electric Shock Hazard: To reduce the risk of fire or electric shock, do not expose the earbuds to rain or moisture.
2. Do not charge the earbuds overnight or leave the product unattended.
3. Do not modify, disassemble, open, drop, crush, puncture or shred the product.

BACK

Features:

- High-quality sound with extra bass
- Connect wirelessly to iOS & Android devices
- Color-changing LED charging case
- Built-in microphone
- Hands-free phone calls
- Ergonomic design for a comfortable fit in your ear

Package Contents:

1 - Pair of Earbuds
1 - Charging Case
1 - Charging Cable
1 - User Manual

Specifications:

iHip Wireless Earbuds
BL-06
Bluetooth Version: 4.0
Bluetooth Distance: 10m
Product Size:
60mm x 45mm x 22mm
Earbuds Size:
32mm x 24mm x 18mm
Speaker Size: ϕ10mm
Charging Time: 2~3 hours
Working Time: 2~3 hours after earbuds are fully charged
Frequency: 2402-2480MHz
Input Voltage: 4.2V
Charging Case Battery: 220mAh
Earbuds Batteries: 30mAh
Sensitivity: 100dB±3dB

Charging Instructions:

CHARGING THE CHARGING CASE:

Please use the provided cable to charge the charging case.

- Put the earbuds in the charging case and connect the cable to the case.
- Then connect the standard USB tip to a USB port in a wall adapter, computer, or similar suitable power source.
- The case will begin charging automatically and you will see a red light flashing.
- The red light will stop flashing when fully charged.

CHARGING THE EARBUDS:

- Place the earbuds into the charging compartment of the charging case to charge.
- The red light indicates the earbuds are charging.
- When the earbuds are fully charged the light will turn off.

LED Lights

The color-changing LED lights on the earbud charging case will automatically activate when the case is open.

Wireless Connection:

1. Open the charging case to automatically activate pairing mode.
2. Take the left and right earbuds out of the charging case. The left and right earbuds will automatically pair with each other.
3. Turn on your phone, tablet, computer, or other Bluetooth® device and activate the Bluetooth function.
4. Search for a Bluetooth device named “**iHip Wireless Earbuds**”
5. Select “**iHip Wireless Earbuds**” to pair the device. A voice prompt will say “connected” when your device is paired.
6. The earbuds automatically shut down after 3 minutes when a device is not paired.

NOTE: The earbuds will automatically reconnect to any device they are already paired with.

Earbud Controls:



MUSIC MODE:

- **Play/Pause -** Tap once on the left or right earbud to play/pause music.
- **Skip Forward -** Double click on the right earbud to skip to the next song.
- **Skip Back -** Double click on the left earbud to skip back to the previous song.
- **Volume Control -** Triple click the left button to increase the volume, and triple click the right earbud button to decrease the volume.

CALL MODE:

- **Accept Call -** When a call is incoming, short press the left or right earbud to answer it.
- **Reject Call -** When a call is incoming, long press the left or right earbud for 2 seconds to reject the call.
- **End Call -** During a phone call, short press the left or right earbud to hang up.

VOICE ASSISTANT MODE: (i.e. Siri®, Google assistant, etc.)

- **Activate Smartphone Voice Assistant -** Long press the left or right earbud for 2 seconds to activate your phone’s voice assistant.

NOTE: This function is only available for devices with voice assistant software.

POWER ON/OFF:

- Long press the left or right earbud for 3 seconds to power on.
- Long press the left or right earbud for 5 seconds to power off.