PBX-101

QFX

WHERE THE PARTY BEGINS™

INSTRUCTION MANUAL

QFX

PBX-101 SAFETY

SAFETY
TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER ON THIS SPEAKER. THERE ARE NO USER-SERVICEABLE PARTS INSIDE, REFER ALL SERVICING TO A QUALIFIED TECHNICIAN.
To prevent fire or electric shock, do not expose this equipment to rain or moisture. Do not store or operate this product near any liquids, heat sources such as radiators, heat registers. Clean only with a dry cloth. Users should exhibit extra safety and follow all precautions as they are stated.

LA SEGURIDAD
PARA REDUCIR EL RIESGO DE DESCARGA ELÉCTRICA, NO QUITE LA CUBIERTA DE ESTE ALTAVOZ. NO HAY PARTES REPARABLES POR EL USUARIO ADENTRO. CONSULTE TODOS LOS SERVICIOS A UN TÉCNICO CALIFICADO.
Para evitar incendios o descargas eléctricas, no exponga este equipo a la lluvia o a la humedad. No almacene ni opere este producto cerca de líquidos, fuentes de calor como radiadores, registros de calor. Limpie solamente con un paño seco. Los usuarios deben exhibir una seguridad adicional y seguir todas las precauciones tal como se indican.

SÉCURITÉ
POUR REDUIRE LE RISQUE D'ÉLECTROCUTION, NE RETIREZ PAS LE COUVERCLE DE CETTE ENCEINTE, IL N'Y A AUCUNE PIÈCE RÉPARABLE PAR L'UTILISATEUR À L'INTÉRIEUR. REFÉREZ TOUTE RÉPARATION À UN TECHNICIEN QUALIFIÉ.
Pour éviter un incendie ou un choc électrique, n'expose pas cet équipement à la pluie ou à l'humidité. Ne stockez pas ou n'utilisez pas ce produit à proximité des liquides, de sources de chaleur telles que des radiateurs, des registres de chaleur. Nettoyez uniquement avec un chiffon sec. Les utilisateurs doivent faire preuve de plus de sécurité et suivre toutes les précautions telles qu'elles sont indiquées.

QFX

PBX-101 GUIDE



FUNCTIONS:
1. USB: USB Port to Play MP3 Music
2. TF CARD: TF Card Slot to Play MP3 Music
3. AUX IN: 3.5mm Aux Input Jack to Connect to External Audio Source
4. TWS BUTTON: Press and hold to establish TWS wireless connection with another speaker. In TWS connection mode, Press TWS button on one speaker only for 3 seconds to establish pairing with a second PBX-101 speaker (sold as pairs).
5. MIC1: Microphone 1 input jack
6. MIC2: Microphone 2
7. MIC3: Microphone 3 input jack
8. Repeat: Repeat playback mode functions
9. Guitar: Guitar input jack
10. Power: DC 12V Charging input
11. Volume: Master Volume OR Show Control Knob
12. Power: ON OFF Power
13. PREV.SW: Press to Select Previous Track or Radio Station
14. REC: Recording and recording playback functions
15. NEXT: Press to Select Next Track or Radio Station
16. ALPS: Microphone priority function
17. LED: Press to Turn Party Light On or Off
18. NEXT: ▶▶: Press to Select Next Track or Radio Station
19. MODE: Press to Select AUX, USB, TF, FM or BT Modes
20. MUSIC: Microphone Volume Control Knob

FUNCIONES:
1. **PANTALLA**: Pantalla LED de funciones clave
2. **RANURA PARA TARJETA TF**: Ranura para tarjeta de memoria micro para reproducir música en formato MP3
3. **ENTRADA DE MICRÓFONO**: Conector de entrada de micrófono de 3.5"
4. **AUX IN**: Conector de entrada auxiliar de 3.5 mm para conectar a una fuente de audio externa
5. **TWS/EN**: Conexión para tarjeta TF para reproducir música MP3
6. **USB**: puerto USB para reproducir música MP3
7. **MODO/LED ENCENDIDO**: presione brevemente para seleccionar los modos AUX, USB TF, FM o BT. Mantenga presionado para encender/apagar las luces LED
8. **ANTERIOR ⏮**: presione para ajustar el volumen o la ubicación de video
9. **Botón JUGAR ⏯ TWS**:
   - Presione brevemente para reproducir/pausar música.
   - Mantenga presionado para conectar una segunda PBX-101 en modo TWS. Para TWS, en el modo Bluetooth, presione el botón TWS en un altavoz solo durante 3 segundos para establecer el emparejamiento con un segundo altavoz PBX-101 (se vende por separado).
   - En modo TWS, presione brevemente para reproducir/pausar música. Mantenga presionado para ajustar el volumen o seleccionar un segundo altavoz PBX-101 (se vende por separado).
10. **SIGUIENTE ⏭**: presione para seleccionar la siguiente pista o estación de radio
11. **PERILLA MAESTRA VOL**: Use la perilla para ajustar el volumen
12. **TONO**: perilla para ajustar el tono de voz
13. **DC IN**: Entrada de carga USB (5VDC / 1A máximo)
14. **LED**: indicador LED de carga de la batería (rojo = cargando, azul/verde = completamente cargado)

LED FUNCTIONS:
1. **APPEAR**: Alternate LED dim functions clear
2. **CONTROLLO DI ILLUMINAZIONE/VOLUME**: Mixed switch set
3. **ALPS**: Microphone priority function (Turn off)
4. **MIC IN**: Pilot of dynamic microphone 1, 2, 3
5. **AUX IN**: pilot of mixed auxiliary 3.5 mm jack or connector to an external audio exterior
6. **CARTE TF**: Illuminate when a card TF jack in deep connection
7. **USB**: card USB jack (for playing music MP3)
8. **MODE/LED ON**: Appoggi brevemente per selezionare le modo AUX, USB TF, FM o BT. Appoggio e mantenuto premuto per allumare o spegnere le luces
9. **PREV**: Appoggio brevemente per ajustare o selezione di video o stazione di radio precedente
10. **Button JOUER ⏯ TWS**:
   - Appoggio brevemente per riprodurre o pausa la musica.
   - Mantenuto premuto per connettere una seconda PBX-101 in modo TWS. Per TWS, in modo Bluetooth, premere il pulsante TWS su un altoparlante solo per 3 secondi per stabilire l'accoppiamento con un secondo altoparlante PBX-101 (venduto separatamente).
   - In modo TWS, appoggio brevemente per riprodurre/pausa musica. Appoggio e mantenuto premuto per ajustare il volume o selezionare un secondo altoparlante PBX-101 (venduto separatamente).
11. **NEXT ⏭**: Appoggio per selezionare la prossima traccia o stazione di radio successiva
12. **MIC VOL**: Bouton de contrôle du volume du microphone
13. **Bouton TONE**: Bouton de contrôle du ton
14. **DC IN 5V**: entrée de charge USB (5VDC / 1A maximum)
15. **LED**: indicateur LED de charge de la batterie (rouge = charge, vert = entièrement chargé)

QFX

PBX-101 OPERATION

POWER SOURCE
1. Charge the unit at least four hours prior to first use and then recharge it as needed in the future.
2. Turn to system on turning the power knob.

CHARGE THE BATTERY
When the Battery is charging, the charge LED indicator will be red and turn off when fully charged.
1. Connect the USB charge cable to the DC5V interface of the speaker firmly.
2. Once the battery is fully charged, disconnect the USB charge cable from the speaker.
3. The speaker functions normally while charging.

FM FUNCTION
1. Show press the MODE/LED ON button to toggle to FM mode.
2. Press the PLAY/PAUSE button on control panel to automatically search and save radio stations.
3. Then press PREV/BACK or NEXT to select and listen to saved radio stations.

BLUETOOTH
1. Long press MODE/LED ON button to toggle to Bluetooth (BT) mode.
2. Open the Bluetooth setting on your phone, tablet or any other Bluetooth-enabled audio device and select "QFX PBX-101".
3. The unit and device will then connected via Bluetooth.

PBX-101 TRUE WIRELESS STEREO (TWS)
True Wireless Stereo (TWS) allows for two speakers of the same model to connect wirelessly in stereo. You will need two PBX-101 speakers in order for TWS operation to function. **To set up TWS:**
1. Turn on both PBX-101 speakers, toggle the MODE button to BLUETOOTH mode on both speakers.
2. To set up TWS operation, press the PLAY ⏯ TWS button on only one speaker for 3 seconds. Then both speakers will connect together.
3. Next, on your phone, tablet or any other Bluetooth-enabled device, search and connect to Bluetooth name "QFX PBX-101".
4. Once the connection has been established, you can play music from your phone and enjoy True Wireless Stereo audio playing through your two PBX-101 speakers.
5. To exit TWS mode, long press the PLAY ⏯ TWS button for 3 seconds to exit TWS.

FUENTE DE ALIMENTACIÓN
1. Cargue la unidad al menos cuatro horas antes de primer uso y luego recárgala según sea necesario en el futuro.
2. Gire al sistema al girar la perilla de encendido.

CARGA LA BATERÍA
Cuando la batería se está cargando, el indicador LED de carga estará rojo y se apagará cuando esté completamente cargado.
1. Conecte firmemente el cable de carga USB a la interfaz DC5V del altavoz.
2. Una vez que la batería esté completamente cargada, desconecte el cable de carga USB del altavoz.
3. El altavoz funciona normalmente mientras se carga.

FUNCIÓN FM
1. Presione brevemente el botón MODE/LED ON para cambiar al modo FM.
2. Presione el botón PLAY/PAUSE en el panel de control para buscar y guardar estaciones de radio automáticamente.
3. Luego presione ANTERIOR o SIGUIENTE para seleccionar y escuchar las estaciones de radio guardadas.

BLUETOOTH
1. Mantenga presionado el botón MODE/LED ON para cambiar al modo Bluetooth (BT).
2. Abra la configuración de Bluetooth en su teléfono, tableta o cualquier otro dispositivo de audio habilitado para Bluetooth y seleccione "QFX PBX-101".
3. La unidad y el dispositivo se conectarán a través de Bluetooth.

QFX

PBX-101 OPERATION

PBX-101 ESTÉREO INALÁMBRICO VERDADERO (TWS)
True Wireless Stereo (TWS) permite que dos altavoces del mismo modelo se conecten de forma inalámbrica en estéreo. Necesitará dos altavoces PBX-101 para que funcione la operación TWS. **Para configurar TWS:**
1. Encienda ambos altavoces PBX-101, cambie el botón MODE al modo BLUETOOTH en ambos altavoces.
2. Para configurar la operación TWS, presione el botón PLAY ⏯ TWS en un solo altavoz durante 3 segundos. Entonces ambos altavoces se conectarán juntos.
3. A continuación, conecte su teléfono con Bluetooth al altavoz. Vaya a la configuración de Bluetooth de su teléfono, busque y conéctese al nombre de Bluetooth "QFX PBX-101".
4. Una vez que se haya establecido la conexión, puede reproducir música desde su teléfono y disfrute de la reproducción de audio True Wireless Stereo a través de sus dos altavoces PBX-101.
5. Para salir del modo TWS, mantenga presionado el botón PLAY ⏯ TWS durante 3 segundos para salir de TWS.

SOURCE D'ÉNERGIE
1. Chargez l'appareil au moins quatre heures avant la première utilisation, puis rechargez-le si nécessaire à l'avenir.
2. Allumez le système en tournant le bouton d'alimentation.

CHARGER LA BATTERIE
Lorsque la batterie est en charge, le voyant LED de charge est rouge et s'éteint lorsqu'il est complètement chargé.
1. Connectez fermement le câble de charge USB à l'interface DC5V du haut-parleur.
2. Une fois la batterie complètement chargée, débranchez le câble de charge USB de l'enceinte.
3. Le haut-parleur fonctionne normalement pendant la charge.

FONCTION FM
1. Appuyez brièvement sur le bouton MODE/LED ON pour basculer en mode FM.
2. Appuyez sur le bouton PLAY/PAUSE du panneau de commande pour rechercher et enregistrer automatiquement les stations de radio.
3. Appuyez ensuite sur PRÉCÉDENT ou NEXT pour sélectionner et écouter les stations de radio enregistrées.

BLUETOOTH
1. Appuyez longuement sur le bouton MODE/LED ON pour basculer en mode Bluetooth (BT).
2. Ouvrez le paramètre Bluetooth sur votre téléphone, tablette ou tout autre appareil audio compatible Bluetooth et sélectionnez "QFX PBX-101".
3. L'appareil et l'appareil seront ensuite connectés via Bluetooth.

PBX-101 VÉRITABLE STÉRÉO SANS FIL (TWS)
True Wireless Stereo (TWS) permet à deux haut-parleurs du même modèle de se connecter sans fil en stéréo. Vous aurez besoin de deux haut-parleurs PBX-101 pour que le fonctionnement TWS fonctionne. **Pour configurer TWS:**
1. Allumez les deux haut-parleurs PBX-101, basculez le bouton MODE sur le mode BLUETOOTH sur les deux haut-parleurs.
2. Pour configurer le fonctionnement TWS, appuyez sur le bouton PLAY ⏯ TWS sur un seul haut-parleur pendant 3 secondes. Ensuite, les deux haut-parleurs se connecteront ensemble.
3. Ensuite, connectez votre téléphone compatible Bluetooth au haut-parleur. Accédez aux paramètres Bluetooth de votre téléphone, recherchez et connectez-vous au nom Bluetooth "QFX PBX-101".
4. Une fois la connexion établie, vous pouvez écouter de la musique à partir de votre téléphone et profiter de l'audio True Wireless Stereo via vos deux haut-parleurs PBX-101.
5. Pour quitter le mode TWS, appuyez longuement sur le bouton PLAY ⏯ TWS pendant 3 secondes pour quitter TWS.

QFX

LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this limited warranty, please (1) read the instruction manual carefully and visit our website at www.qfxusa.com for FAQs and troubleshooting information, (2) contact our Customer Support Department (e.g., Customer Troubleshooting Dudes) (3) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period commences, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the applicable Coverage Period, repair or replace the Product or component with a new or refurbished Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), if either case free of charge to Customer for Parts and for Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below) incurred by or billed to the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX's sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or lightning or other force majeure. In addition, the warranty excludes any Product that has been subjected to improper voltage or other improper electrical current, or any Product on which the serial number has been defaced, modified or removed, improper application, violation of operating instructions for the Product, any other Customer induced damage, or the alteration or removal of any Product serial number. Excess modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX, (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, incorrect wiring, or malfunction of any devices used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) any damage to the Product (or, as applicable, any component thereof) caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or glass acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (Customer is on hot that any data stored on Product will be breached or otherwise compromised, or (ii) the data stored on Product is relied upon for medical or life-saving applications. QFX disclaims any liability for any data stored on Product, and Customer is responsible for backing up any data stored on Product. Customer assumes any and all risk associated with such use of Product, and agrees to indemnify QFX for any damages claimed against QFX for such use.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCT AND PROVIDER "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY OF OWNERSHIP, MERCHANTABILITY, OF FITNESS FOR A PARTICULAR PURPOSE, OR OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY QFX, ITS DEALERS, DISTRIBUTORS, AGENTS OR EMPLOYEES SHALL CREATE ANY OTHER WARRANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY. QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCLUDING WITHOUT LIMITATION, INCIDENTAL OR CONSEQUENTIAL DAMAGES, ARISING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER ARISING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright/Protected 2022 ©

QFX Brands, Inc.
Warranty Fulfillment
Customer Support Department
2855 E. 46th Street | Vernon, CA 90058

support@qfxusa.com
(888) 814-1-09 (2582) or (323) 864-5999
qfxusa.com
Hours of Operation: Monday - Friday, 9am - 5pm PST

RS prices and detail below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and INTERN'L destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model is unlisted, with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instructions.

In order to determine the exact shipping cost that must be re-billed with your product or paid for the product being returned, please refer to the table below. Customer Support Representatives will be able to provide the exact shipping cost and will also provide any return or refund to any customer for merchandise and authority leaves the limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	RS PRICE	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth Speakers	$5.00	1 Year	1 Year
Personal Stereos	$10.00	1 Year	1 Year
Portable Radio/Cassette	$15.00	1 Year	1 Year
Large Portable Radio Cassette	$20.00	1 Year	1 Year
Mobile Audio	$10.00	1 Year	1 Year
Pro Audio DJ Systems	$75.00	1 Year	1 Year
Pro Audio PA Systems	$75.00	1 Year	1 Year
Television	$20.00	1 Year	1 Year
Telephones	$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, IF THESE LAWS APPLY THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. EXCEPT AS PROVIDED IN THIS WARRANTY AND TO THE EXTENT PERMITTED BY LAW, NEITHER QFX NOR ITS DEALERS, DISTRIBUTORS, AGENTS OR EMPLOYEES WILL BE REPONSIBLE FOR ANY EXPRESS OR IMPLIED WARRANTIES, OR DAMAGES, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT. ANOTHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

THE REMEDIES GIVEN TO CUSTOMER FOR THE PRODUCTS COVERED THE ORIGINAL IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are chemicals known to the California State of Health to cause cancer, birth defects, or other reproductive harm. Customer should wash hands after handling the Product. Warranty Service: To receive warranty service, Customer must have a purchase date that is after the Warranty Period specified in the table below that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (4) all of the accessories listed in the table below for return shipping and handling. If the item you are sending back for repair does not include all of the items listed in the table below, the amount specified for the item in the product table below for return shipping and handling. If for the same you cannot provide a money order or voucher, then, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a replaced Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

www.qfxusa.com

1-800-884-2582
Mon-Fri 9AM - 5PM (PST)

support@qfxusa.com
Mon-Fri 9AM - 5PM (PST)

THANK YOU.

Warning:
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesirable operation.
Changes or modifications not expressly approved by the party responsible for compliance would void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
NOTE: The device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

RF exposure:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

QFX Where the Party Begins!
We would love to hear about your PBX-101 journey!
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

PBX-101说明书2023.8.30　尺寸:宽129mmX高204mm