QUICK START GUIDE

Powering the Device Up & Off

Take out earphones from charging case to power up automatically ;
Return the earphones to the case to power off and start charging.

User will hear "Buttons On" when take out earphones from charging case.

Note: Please charge the charging case and earphones before first use.

Pairing

1. When taking your earphones out of the charging case, the earphones issue a voice prompt of "Ready for pairing". This means your earphones have entered pairing mode;

2. Turn on your mobile's Bluetooth, find "BUTTONS POP" in the Bluetooth device list and click "Connect" ;

Available equipment BUTTONS POP

3. The system pops up the "Authorization Bluetooth Pairing Request" dialog box, press the "Pair" button, and the earphones voice prompts "Connected" , indicating that the earphones are successfully connected.

Note: After the first-time connection, the earphones will automatically connect to the last connected device the next time;
The earphones can also be used separately when next connection.

Smart Noise Cancellation

BUTTONS POP Earphones are configured with three modes (**ANC, ambient sound** and **standard**), and you can switch between them as needed.

ANC Mode: The noise reduction is up to 35dB, eliminating most of the noise interference in the low frequency band, bringing a quiet and private listening experience.

Ambient Sound Mode: In this mode, ambient sound is collected and played in the ears to improve the perception of the external environment so that the ambient sound outside the ears can be clearly heard;

Standard Mode: In this mode, the active noise cancellation and ambient sound functions are disabled, and the earphones are used as TWS earphones only.

Mode Switch:

After connecting and wearing both earphones, double -tap the cover disc on the left earphone to switch between ANC / ambient sound / standard modes. x2

Enter ANC Mode: Can hear voice prompt "Noise Cancellation On";

Enter Ambient Sound Mode: Can hear voice prompt "Ambient On" ;

Enter Standard Mode: Can hear voice prompt "Off";

Note: The default mode of the earphones is ANC mode;
Mode switch cannot be performed when only one earphone is used.

Music Control

Play/Pause
Using both earphones: Double-tap the cover disc on the right-side earphone to pause & play music x 2
Using one earphone: Double-tap the cover disc on the earphone to pause & play music II / ▶

Track Switch
Previous: Triple-tap the cover disc on the left earphone x3 ▶▶|
Next: Triple-tap the cover disc on the right earphone x3 |◀◀

Call Control

Answer Calls
Using both earphones: Double-tap the cover disc on the right earphone to answer a call x2
Using one earphone: Double-tap the cover disc on the earphone to answer a call

Reject Calls
To reject a call, triple-tap the cover disc on either earphone x3

End Calls
To end a call, double-tap the cover disc on right earphone during the call x2

Wearing Detection & Power Saving Mode

Wearing Detection:
While music is played, the music will automatically be paused when you take off either one or both earphones and will resume when you put on the earphone(s) again.

During a phone call, the telephone receiver will be enabled when you take off both earphones, and the earphone speakers will be enabled when you put on either or both earphones.

Note: Tap control is not supported if your earphones are detected not be worn.

Power Saving Mode:
Enter Power Saving Mode: The earphones will automatically enter power saving mode if it is taken off and not used for certain duration and doesn't put into charging box;
Exit Power Saving Mode: Wear your earphones or put your earphones back into the charging case, and then take out again to exit power saving mode.

Sleep Mode:
Enter Sleep Mode: The earphones will automatically enter sleep mode in case of failing to pair with a Bluetooth device, being taken off and not used, or being out of Bluetooth range for certain duration;
Exit Sleep Mode: Put your earphones back into the charging case, and then take out again to exit sleep mode.

Pair a new device

Put your earphones into the charging case, and keep the charging case lid opened. Press and hold the pair button in bottom for 3 seconds until the red and white LED blinking. Then take out earphones;

Your earphones will automatically enter pairing mode, and you may pair with a device using the steps described in the "Paring" section.

Charge

Charge earphones:

Put your earphones into the charging case and ensure the two metal contact points are well contacted, the charging box will automatically charge the earphones.



Earphone Low Battery: Voice prompt "Battery is Low"

Charging: LED indicator on charging case turns white and flash slowly

Charging Done: LED indicator on charging case turns off

Charge the charging case:

Charging: LED indicators on the charging case turn white and flash;

Charge complete: LED indicators on the charging case are off;

Charge Fault: LED indicators on the charging case turn red and rapidly flash;

Note: The above light indication only applies to charge the charging case separately;
When the charging case cover is opened, if the LED indicator flash orange color rapidly, it means that the charging box is low battery, need to charge the device;
Please use standard 5V⎓1A charger for this product, as those chargers out of specification may damage the device.



Change Decoration Disc

The decoration disc of Buttons POP is changeable, user can match earbuds with different styles of decoration discs according to personal preference.

Remove Disc:

Take out earbuds, hold the bottom side and turn decoration disc counter-clockwise to remove the disc (same operation on both left and right earbuds).



Install Disc:

Hold the bottom side and turn decoration disc clockwise to install the disc (same operation on both left and right earbuds).

Safety Guide

Warning: Electrical and electronic equipment, parts and batteries marked with this symbol must not be disposed together with normal household waste. They must be collected and disposed separately to protect the environment.
Your BUTTONS retailer will advise you of the correct method of disposal in your country/region.

Warning: Prolonged listening at high volume levels can cause hearing damage.

Warning: Choking Hazard - small parts.

Warning: This product contains magnets

Manufacture: Buttons (Shanghai) Technology Limited
Commissioned Manufacturer: Beijing Techao Weijia Technology Limited
Name: BUTTONS POP
Model: POPBTN10
Charging voltage/current: 5V ⎓ 1A

Frequency: 20~20KHz
Resistance: 16Ohm
Speakers: 11mm biofibre composite element
Noise reduction: up to 35dB (200Hz~1000Hz)
ANC Mic: Analog Mic (×2), -38±1.1 dB at 94dB SPL@1kHz
Digital Mic (×2), -26 +/-1 dBFS at 94dB SPL@1kHz
Call Mic: Digital Mic, -26 +/-1 dBFS at 94dB SPL@1kHz
Battery life: 6h (noise cancellation enabled and medium sound volume)
8h (noise cancellation disabled and medium sound volume)
Earphone Battery: 70mAh*2
Battery of charging case: 480mAh
Bluetooth version: v5.2
Bluetooth range: Over 12meters
Weight: About 7.8g (each earphone) About 60g (charging case)
Warranty period: 1 year

Items in package:
Silicon eartips x3 pairs
USB Type C to Type C charging cable x1
Earbuds with charging box x1
Quick Start Guide x1
Exchangeable disc x2 pairs
Brotch Accessory x1

EU WARNING: Hereby Buttons declares that the radio equipment type [POPBTN10] is in compliance with Directive 2014/53/EU. This device may be operated in all member states of the EU.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2A83-POPBTN10 CMIIT ID: 2022DP16493

开机&关机

耳机从充电盒取出时自动开机；
耳机放入充电盒中时自动关机并开始充电。

当耳机从充电盒中取出时，会播放“Buttons On”提示音，表示耳机已开机

注：首次使用前，请为装有耳机的充电盒进行充电。

配对连接

1、从充电盒中取出耳机，耳机语音提示“Ready for pairing”，此时耳机进入配对模式；

2、打开手机蓝牙开关，在蓝牙设备列表中找到“BUTTONS POP”并点击连接；

可用设备 BUTTONS POP

3、系统弹出“授权蓝牙配对请求”对话框，点击“配对”按钮，耳机语音提示“Connected”，表明耳机连接成功。

注：首次连接成功后，再次连接时耳机会自动连接最近一次连接成功的设备；
再次连接时，也可取出任意一只耳机单独使用。

智能降噪

BUTTONS POP耳机提供降噪、环境音和标准共3种模式，用户可根据使用需求自行切换。

降噪模式：降噪最高达35dB，消除低频段大部分噪音干扰，带来安静私密的聆听体验；

环境音模式：收集环境声音并播放于耳内，提高对外界环境的感知，听清耳外环境音；

标准模式：关闭主动降噪和环境声音的功能，仅作为TWS耳机使用。

模式切换：

双耳连接成功并佩戴好后，双击左耳面板，以实现降噪/环境音/标准3种模式之间的循环切换。 x2

进入降噪模式：听到语音提示“Noise Cancellation On”

进入环境音模式：听到语音提示“Ambient On”；

进入标准模式：听到语音提示“Off”；

注：耳机开机默认进入降噪模式；
使用单只耳机时，无法进行模式切换。

音乐控制

播放/暂停
双耳使用时：双击右侧耳机面板切换暂停&播放 x2
单耳使用时：双击耳机的面板切换暂停&播放 II / ▶

曲目切换
上一曲：三连击左侧耳机面板 x3 ▶▶|
下一曲：三连击侧耳机面板 x3 |◀◀

通话控制

接听来电
双耳使用时：双击右侧耳机面板接听来电 x2
单耳使用时：双击耳机的面板接听来电

拒接来电
三连击任意一侧耳机的面板拒绝该来电 x3

结束通话
通话中，双击右侧耳机的面板挂断电话 x2

佩戴检测和节能模式

佩戴检测
音乐播放过程中，取下一只或两只耳机同时取下后，音乐自动暂停，耳机再次放入耳中后，音乐自动恢复播放。

手机通话过程中，取下两只耳机后，自动切换成手机听筒，佩戴任意一只或两只耳机后，自动切回耳机扬声器。

注：当检测到耳机未佩戴时，耳机将不支持敲击操作。

节能模式：
进入节能模式：耳机如从耳中取下不用超过一定时间，且未放入充电盒中，则自动进入节能模式；
退出节能模式：重新佩戴耳机或将耳机放入充电盒中再取出退出节能模式。

休眠模式：
进入休眠：耳机如出现无法与蓝牙设备配对、或从耳中取下不用、再或脱离蓝牙范围等情况超过一定时间，则自动进入休眠模式；
退出休眠：将耳机放回充电盒，再次取出退出休眠模式。

连接新设备

将左右耳机都放入充电盒中并保持盒盖开启，按住盒底配对按键3秒至充电盒红白灯闪烁，取出耳机。
耳机自动进入配对模式，按“配对连接”中步骤进行连接操作。

设备充电

为耳机充电
将耳机放入充电盒中，确保金属触点良好接触，充电盒自动为耳机充电。



耳机低电：语音提示“Battery is Low”

充电状态：充电盒LED指示灯白色慢闪

充电完成：充电盒LED指示灯熄灭

为充电盒充电：

正在充电：充电盒LED指示灯白色呼吸闪烁；

充电完成：充电盒LED指示灯熄灭；

充电异常：充电盒LED指示灯橙色；
注：上述灯光指示仅适用于单独为充电盒充电时使用；
当打开充电盒盖，如LED指示灯红色快闪，则表明充电盒电量低。
需要对设备进行充电；
当打开充电盒盖，如LED指示灯红色快闪，则表明充电盒电量将耗尽，
充电盒将无法对耳机充电，请马上对设备充电；
请使用正规5V⎓1A充电器为本机充电，超出规格充电器会造成设备损坏。



更换装饰盖

Buttons POP的装饰盖是可更换的，用户可根据喜好为耳机搭配不同风格的装饰盖。

取下装饰盖：
取出耳机前按住耳机底部，逆时针旋转装饰盖以取下装饰盖（左右耳机操作方式相同）。

安装装饰盖：
握住耳机底部，顺时针旋转装饰盖至锁定位置以安装装饰盖（左右耳机操作方式相同）。

安全指南

警告：带有此符号的电气和电子设备、零件以及电池不得与普通生活垃圾一起处理。此类物品必须单独收集和处理，以保保护环境。
您的BUTTONS零售商会告知在您所处国家/地区正确处置此类物品的方法。

警告：长时间高音量状态下倾听可能导致听力受损。

警告：窒息危险-含有小零件。

警告：设备内含磁铁

制造商：上海永加电子科技有限公司
委托制造：北京特斯木加电子科技有限公司
名称：BUTTONS POP
型号：POPBTN10
充电电压/电流：5V ⎓ 1A

频响范围：20 ~ 20KHz; 20 ~ 20KHz
阻抗：16Ohm
扬声器：11mm生物纤维复合单元
降噪量：最大35dB（200Hz~1000Hz）
ANC Mic 模拟Mic（×2），-38±1.1 dBV/Pa at 94dB SPL@1kHz
数字Mic（×2），-26 +/-1 dBFS at 94dB SPL@1kHz
通话Mic：数字Mic，-26 +/-1 dBFS at 94dB SPL@1kHz
电池续航：开启降噪&中时（中等音量）
关闭降噪&中时（中等音量）
耳机电池：70mAh*2
充电盒电池：480mAh
蓝牙版本：v5.2
通信距离：> 12米
设备自重：约7.8克（每只耳机） 约60克（充电盒）
质保时间：1年

内含物
硅耳塞 x3
USB Type C-Type C充电线缆 x1
耳机（内置6颗水加电力）及充电盒 x1
产品手册 x1
可更换面盖 x2
胸针饰品 x1

符合电子信息产品污染控制管理办法的有害物质或元素标识表

部件名称	目标部件	有害物质或元素					
		铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴联苯醚 (PBDE)
电路板组合件	印刷电路板	×	○	○	○	○	○
塑胶件	塑料部件，硅胶耳塞，环境耳塞，音质优良的纤维素复合材料	○	○	○	○	○	○
扬声器	全音频件	○	○	○	○	○	○
线材组件	线材及接杆等	○	○	○	○	○	○
附件	彩盒盒，说明书，卡纸，玻璃等，其他包装	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。
○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。
即《电子信息产品中有害物质的限量要求》规定的限量要求以下。
×：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求
；表中标有“×”的所有部件都符合欧盟RoHS法规。

FCC ID: 2A83-POPBTN10 CMIIT ID: 2022DP16493

保修说明

执行标准：GB 8898-2011 热线电话：400-600-8802 官网：www.bttms.com.cn

POP说明书 14P 2色双面印刷

91*151mm