Smart Designer Light ™

Wi-Fi®

Motion Detection

Mobile Alert

Secure App

For instructional videos and FAQ's please visit
icustomerservice.com to learn more.

Distributed by Trend Makers, LLC • Fort Walton Beach, FL 32547
©2024 Trend Makers, LLC
Made in China

All Rights Reserved.

⚠ **WARNING:** Cancer and Reproductive Harm - www.P65Warnings.ca.gov

By purchasing this product, you accept Trend Makers' terms and conditions including arbitration agreement.
See enclosed for arbitration agreement. See trendmakersinc.com/arbitration-agreement for details.

i_SDL_IB_ENG_V1_240820

Trend Makers®

3 Simple Steps to Set-Up and Protect

Download the HOMEi App

Install Smart Designer Light onto an outside wall.

Connect your Smart Designer Light to the App by fast connect.

NOTE: To ensure proper use of your Smart Designer Light please follow the instructions detailed in this set-up guide.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
  (1) this device may not cause harmful interference, and
  (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF Radiation Exposure Statement Caution:
To maintain compliance with the FCC's RF exposure guidelines, place the product at least 20cm from nearby persons.

FCC ID: 2A88H-0033052282
HVIN:ISBO6
IC:32423-ISBO6

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
This device may not cause interference.
This device must accept any interference, including interference that may cause undesired operation of the device.

L émeteur/récepteur exempt de licence contenu dans le présent apareil est conforme aux CNR d Innovation,sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
1.L' appareil ne doit pas produire de brouillage;
2.L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptilble d'en compromettre le fonctionnement

Step 1: Download the HOMEi App

1. Download the **HOMEi** app in the Apple® App Store, Google® Play Store, or use your phone camera to scan the QR code below to open the app store of your mobile phone.

Apple® App Store or Google® Play Store

Scan Code

Step 1: Download the HOMEi App

1. In order for your Smart Designer Light to work properly, select **Allow** if you see the prompt: **HOMEi** would like to find and connect to devices on your local network.
2. Create your account and select **Continue**.
3. Follow the App prompts to set up your password and register your camera/device. Then **Log In** to your **HOMEi** app.

Passwords must contain numbers and letters, be no less than six digits, and cannot contain special characters.

FORGOT PASSWORD:
In the App click on "**Forgot Password**" and follow the account retrieval process. You will receive an email with a temporary code. Enter the temporary code. You will receive a second email with your password.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or a qualified radio/TV technician for help.

How to Use your Smart Designer Light

To get started, open your **HOMEi** app and follow these easy steps:

1. Choose the device you want to control. (as in Figure 1).
2. Tap the Power switch control light trun ON or OFF (as in Figure 2).
3. Select Brightness to adjust light brighness from 0%-100% (as in Figure 3).
4. Select Timer to setting Timing (as in Figure 4-5).

Fig. 1

Fig. 2   Fig. 3   Fig. 4   Fig. 5

Step 2: Mounting the Smart Designer Light

1. Use the provided screws to secure the mounting plate to a wall.
2. Then use the provided screws secure your Smart Designer Light to the mounting plate.

3. Turn on the switch,your Smart Designer Light will flash.

4. Press the reset button on the front face of your Smart Designer Light for about 3 seconds wait your Smart Desinger Light blink twice quickly means reset successful.

OFF
REST
ON

⚠️ This unit is equipped with lithium batteries.
Make sure that the camera is charged prior to installation

Step 3: Connect Your Smart Designer Light to the App

1. Press the ⊕ **sign** in the App

2. You will discovered the ID number of the device, select "add to".

3. Select or enter your location's WiFi name,enter the Wi-Fi® password. If your WiFi is 5GHz, please set it to be 2.4GHz by tapping Change Wi-Fi®, then press Next Step in the App.

6

Step 3: Connect Your Smart Designer Light to the App

4. The App will countdown until your Smart Designer Light and mobile device are connected to your Wi-Fi® network.

5. Enter a name for your Smart Designer Light, then click Done.

6. Now, you are ready to start using your Smart Designer Light!

7