

CONTENTS:

RADIO OPERATION
WEATHER ALERT
SOS ALARM
READING LAMP
FLASHLIGHT
3 POWER METHODS
BATTERY PROTECTION
POWER THE DEVICE
EARHONE JACK
CARE AND MAINTENANCE
SPECIFICATION
WARRANTY
PACKING LIST

Made in China

Note: Please turn on the power switch(on the back side) to "ON" before using each function.

RADIO OPERATION



- Turn on the radio by pressing the power button, press it again to turn it off.
- Press the left or right buttons to navigate between radio stations.Adjust the volume by pressing the volume buttons.
- The green LED will light up when the radio has found a stable reception/channel.Extend the antenna and adjust the direction to get better signal.
- The blue LED will light up when the batteries are being used

WEATHER ALERT

- When the radio is on, press “WX AL” button to switch to weather alert mode. Once receives bad weather information, "ALERT" will flash on the screen and the device will alarm.
- Press button “WX AL” or “BAND” to exit weather alert mode.

SOS ALARM

- Long press the SOS button for 3s to activate the loud siren and the flashing far beam
- Press the SOS button again to turn it off.

READING LAMP

- Open the solar panel, the reading lamp lights up, and close the solar panel it will light off.



FLASHLIGHT



- The first press on the flashlight button, the far beam lights up.
- The second press on the flashlight button, the dipped beam lights up.
- The third press with both far and dipped beam light up.
- The forth press with both light off.

3 POWER METHODS



Ⓐ USB CHARGING

- The waterproof cover on the side of this product has 2 USB output ports , a USB input port and a earphone jack.
- Connect the supplied USB-C cable to the USB Input port on the unit's right side to charge the built-in lithium battery. Meanwhile, the red charging indicator light will light up.
- **Please have the radio charged at least once every three months.**

Ⓑ HAND CRANK POWER

- The radio can also be charged by turning the handle at the back of the device.

- The charging indicator light will light red when the handle is being turned.
- Rotate the rocker clockwise or counterclockwise, and keep it at a constant speed of 130 rpm for 1 minute, which can be used for far beam or dipped beam for 10 minutes or radio work for 5-6 minutes.

Ⓒ SOLAR POWER

- Place the unit in clear sunlight to let it charge as efficiently as possible.
- The charging indicator will turn red when charging.
- The charging effect depends on the intensity of the sunlight. Stronger sunlight give better effect.
- It is mostly used for maintaining the battery, to prolong the battery life.

BATTERY PROTECTION

- This emergency radio is designed with a feature of shutdown in low voltage. To protect the chip, the power supply will be cut off to protect the battery from damage when there is an overload or a short circuit in this unit.

- It will cut of the power source when the voltage is lower than 2.7V and protects the battery from being over-disacharged and damaged.

POWER THE DEVICE

- Connect the USB device to the USB output port of the unit via USB cable to power the USB device. When the device is used as a power bank (discharge), the power indicator lights will diminish.
- This feature is suggested to use in emergency, do not use it as a normal power bank.



EARPHONE JACK

- Insert the 3.5mm Earphone jack to listen to the radio to enjoy your leisure time.
- If you press the SOS button at this time, you will hear the SOS alarm in the earphone. It will return to the radio function when you turn off the SOS function.

CARE AND MAINTENANCE

- For the first use or when the unit idles over 60 days, please hand crank for 1 minutes to activate the internal battery.
- The device shall not be exposed to dripping or splashing,and objects filled with liquids should no tbe placed on the device.
- Please do not over discharge the unit, so as not to reduce the internal battery life, or even damage the battery.
- Avoid flashlight light directly into the eyes, or it will hurt the eyes.

SPECIFICATION

Frequency range	FM 87~108MHz AM 520~1710KHz WB/ALERT: 1: 162.400 MHz 2: 162.425 MHz 3: 162.450 MHz 4: 162.475 MHz 5: 162.500 MHz 6: 162.525 MHz 7: 162.550 MHz
Dimensions	175x80x98mm
Weight	570g
Power consumption	7w
Working voltage	2.4~4.2V
Power source	10000mAh / 3.7V
Power input	USB-C 5V 2A
Waterproof level	IPX3
LED flashlight	200LM(Max)
Power of flashlight	2W
Power of reading lamp	1.2W

WARRANTY

- The device has a full 12-month warranty against manufacturing defects from the date of purchase.

PACKING LIST

- Radio x 1
- USB-C Cable x 1
- User Manual x 1
- Gift box x 1

User manual

Multi-function Emergency Radio
With LCD Screen

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.