XINOWY

Instruction of S8 PRO motorcycle-based Bluetooth intercom

1. Power On/Off key
(turn on/off the power supply)

2. Multifunctional key

3. Headphone interface and Charging inlet

4. Indicator light

Product functions

S8 PRO is a helmet-based Bluetooth intercom with stable performance. The maximum call distance is 1000m, and the inter-talk distance in the outdoor environment is around 500m to 1000m.

In addition, as a high-performance Bluetooth earphone (with the range of 20m), it has the functions, such as automatic call answer, waterproofing and high-resolution voice. It is designed for the riding motorcycles, with the purpose of ensuring the riding safety.

Product characteristics

Support eight equipment network intercom
It supports the play of MP3/Remix
DSP noise-reduction technology
Second-generation full-range high-quality HD horn
It allows for simultaneous connection of two Bluetooth devices

Intimate voice prompt
Waterproofing and dustproofing
level up to IPX6
General-purpose full helmet type
High endurance of battery
Voice dial/Redial of last number

Remarks

1. Automatic shutdown 25 minutes in case of no connection
2. Function priority: Call > Talk >GPS&FM& music

– 1 –

### Installation steps



① Fix it on the helmet

② Install the intercom on the seat

③ Attach it on the helmet with magic tape, choose the hard/soft microphone as required

④ Sort the disorderly cables inside, place them in the foam of the helmet, for purpose of wearing

– 2 –

1.Power On/Off

Keep pressing the Power key for 2 seconds to start the machine

Voice prompt of Power On +battery power

Blue light flashes once per 4 seconds

Voice prompt of Power Off

Red light is ON for 1S

2.Low-power alarm

When the battery power is below 3.4V, the low-power alarm voice is sent every 3 minutes, and red light flashes.
(with the voice prompt of "insufficient battery power", and red light flashes two times per 3 minutes)

3.Match phones/GPS

Step 1: turn on the state, long press the multi-function key about 5 seconds, the indicator flashing red and blue alternately, voice prompt "Matching" into the matching state;

Step 2: turn on the Bluetooth settings on your phone or GPS and select the Bluetooth name "S8 PRO"

– 3 –

Step 3: Click on the name to connect. Some phones or GPS may ask for a PIN, enter PIN: "0000"

Step 4: make sure the pairing is complete on your phone or GPS (Note: the LED on the S8 PRO device flashes blue light, and the voice says "The device is connected," indicating that the connection is successful, and the blue light flashes twice every 4s)

Network pairing:

in the shutdown or boost state, press the power-on button for about five seconds to indicate "Matching" (blue flash). After hearing the voice number (blue flash) , click the power-on button to indicate "Searching" (purple 4s flashing twice) . Then, the "Intercom connected" (blue slow flashing) and "Intercom on" (blue flashing 1s) will be connected automatically

Clear the pairing record:

In the On status, keep pressing the Power key for 3 seconds to shut down the machine, and then keep pressing it for about 3 seconds.
(with the voice prompt of "beep", and red light flashes for three times per 300ms)

4.Open/close intercom

Turn on the intercom: have been networking equipment, short press the boot button. (voice prompt "intercom connected" , blue light long 1s off 1s)

End of intercom: Intercom status, short press the power-on button. (voice prompt "Intercom disconnected" , blue light flashing twice every 4s)

– 4 –

5.Mobile phone connection (GPS/MP3)

Disconnect: when the mobile phone is in the connected status, disconnect the mobile phone Bluetooth (with the voice prompt of "beep" , and blue light flashes once per 4 seconds)

6.talk reconnection

① In the talk status, the signal, if interrupted, will be subject to automatic reconnection (with the voice prompt of "the talk has been connected" , and blue light flashes for two times per 4 seconds)

② After turning on, it will automatically reconnect (with a long voice prompt of "intercom connected" and a blue light flashing rapidly every 300ms)

7.Mobile phone reconnection

In the On status, it is forced to reconnect the mobile phone being connected in the previous time; In the On status, if the reconnection with the mobile phone is unsuccessful, press the multi-functional key once (with the voice prompt of "mobile phone has been connected" , and blue light flashes for two times per 4 seconds)

8.Music

Press the multi-functional key

Pause/Play

then the blue light flashes for two times per 4 seconds

– 5 –

Turn the multi-functional key clockwise, Volume + (Increase the volume of the "Beep" sound prompt, the maximum volume of the "Beep" sound prompt)

Turn the multi-functional key clockwise, Volume + (Increase the volume of the "Beep" sound prompt, the maximum volume of the "Beep" sound prompt)

In the state of music,Keep turning the multi-functional key clockwise for 2 seconds, for switching to the previous song

2s In the state of music,Keep turning the multi-functional key clockwise for 2 seconds, for switching to the previous song

9.Incoming call

Answer

Refuse

End

Blue light is ON for 1S and then OFF for 1S

Blue light is ON for 4S and flashes for 2 times

Blue light is ON for 4S and flashes for 2 times

Call auto answer: short press multi-function key to answer or 8 seconds after the automatic answer (voice prompt Tones)

Reject incoming calls: call long press multi-function key 2 seconds (voice prompt: "Du")

End of call: in the call press the multi-function key to hang up the phone (voice prompt: "Du")

Blue light is ON for 1S and OFF for 1S

Blue light is ON for 1S and OFF for 1S

Redial last code: connect the phone, standby, double-click the multi-function key. will redial the last broadcast number (voice prompt: "Beep")

Voice Assistant: with Bluetooth connection, press the multi-function key for 1.5 seconds to enter the voice assistant. The voice will beep to wake up the voice assistant Siri or S-Voice

– 6 –

10.Language switching

Double-click the multifunction key

In the pairing status, double-click the multi-functional key. to switch the voice prompt in Chinese and English modes. (Chinese/English format)

11.Battery power

When battery power is above 3.76V, voice prompt displays "sufficient battery power"
When battery power is below 3.76~3.4V, voice prompt displays "medium battery power"
When battery power is below 3.4V, voice prompt displays "insufficient battery power" (red light flashes two times every 3 minutes)

12.Remix

When mixed, the music/navigation volume is automatically reduced to level 6

13.Charging

During the charging, the red light is ON, and when it is fully charged, red light is OFF

14.Product specification

Bluetooth version: V5.3
Mode protocol: Hf, A2DP, AVRCP
Battery type: Lithium battery
Battery capacity: 1000mA
Temperature range: -10~60°C
Charging time: about 2.5 hours (TYPE-C)
Charging voltage: 5V
Power supply voltage: VDD3.7V
Standby time 144hours
Frequency range: 2.402GHZ-2.480GHZ
Wireless transmission range of intercom: 500M-1000M
Music is played for 12 hours
The intercom lasts 9 hours
The mixing time is 8 hours
Charge Current 850MA

– 7 –

15.FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

– 8 –