99.7mm

136mm

A Sonic Technology

# VT FLOW Bluetooth Headset

User Manual

www.vbetglobal.com

## WELCOME

Thank you for using the VT FLOW . We hope you will enjoy it!

**VT FLOW features**

- Unique fold-and-go design
- Comfort ear cushion with ultra-soft perforated foam
- Super wide band speakers and HD voice
- Hybrid Active Noise Cancellation (ANC)
- Advanced Environmental Noise Cancellation technology (ENC)
- Compatible with leading virtual meeting platforms
- Advanced chipset and sensors
- Hideaway boom arm
- Wireless range of up to 30m/100ft
- Fast wireless charging and corded charging



## INCLUDED ACCESSORIES

## OVERVIEW

## HOW TO WEAR

Adjust the headband so that the headset fits your head comfortably.

Pull the microphone boom arm down or up in one smooth motion.

When using the microphone, the tip of the boom arm should be positioned close to your mouth.

## HOW TO CHARGE

The headset can be charged using the wireless charging pad, or via a USB charging cable plugged directly into the headset.

It takes approx. 2 hours to fully charge the battery. The headset battery supports up to 50 hours (music time) and 28 hours (call time) with ANC off. If the headset is out of battery, it can be charged for 30 minutes to get up to 45% of battery life.

**Charge using the wireless charging pad (optional accessory)**

Connect the wireless charging pad to a powered USB port on your computer using the supplied USB charging cable, and then place the left earcup on the wireless charging pad.
The wireless charging pad is for charging only.

**Charge using USB charging cable**

Plug the USB charging cable into the USB-C charging port on the left earcup and any available USB port on your computer.

## WHAT THE LEDS MEAN

**Headset Busylight**

- Stays solid during a call
- Flashes when incoming call
- Flashes once every 8 seconds after connection

**Headset Status LED**

- Stays solid when fully charged
- Lights up for 1 second when powered off
- Lights up for 1 second when powered on
- Flashes to indicate low battery level during charging
- Flash alternately during pairing mode
- Flashes to indicate high battery level during charging
- Flashes to indicate medium battery level during charging

**VT BT200U Status LED**

- Stays solid when paired successfully
- Stays solid when microphone is muted during a call
- Stays solid during a call
- Stays solid when incoming call or during music mode
- Flashes every 2 seconds during searching devices
- Flash alternately during pairing mode
  (Press and hold the Pairing button for 5 seconds)

## HOW TO CONNECT

**Connect to computer**

Plug the supplied VT BT200U into a USB port on your computer. The VT FLOW and the VT BT200U are pre-paired and ready for use out of the box. The Bluetooth range is up to 30 meters or 100 feet.

To hear audio in the headset you may need to select the VT BT200U as the playback device in your operating system's audio settings.

**Pair with a smartphone**

1.If the headset is powered off, press and hold the Power button for 4 seconds until the LED flashes blue and red. Then, you hear a pairing announcement in the headset. If the headset is powered on, press the Power button three times quickly to enter the pairing mode.

2.Go to the Bluetooth menu on your smartphone and select the VT FLOW from the list of available devices

## EAR CUSHION REMOVAL

Using your thumb, slowly pry open the right lower edge of the earmuff, then gently lift it upward to fully open the earmuff. Align the raised inner side of the earmuff with the inherent position of the ear disc, then gently but firmly snap the entire earmuff back into place.




## POWER THE HEADSET ON/OFF

Press the Power button for 3 seconds to power the headset on or for 5 seconds to power off.

## CALLS & MUSIC

| Right earcup | Calls & music | |
|---|---|---|
| | Play/pause music | Press the **Play/pause** button |
| | EQ setting | Press the **Play/pause** button 3s to switch different EQ |
| | Answer call | Press the **Call** button. Alternatively, move the microphone boom arm down to answer an incoming call |
| | End call | Press the **Call** button |
| | Reject call | Double-press the **Call** button |
| | Adjust volume | Press the **Volume up** or **Volume down** button, when listening to music or on a call |
| | Next track | Press and hold (2 sec) the **Volume up** button |
| | Previous track | Press and hold (2 sec) the **Volume down** button |
| | Turn Busylight on/off | Press the **Volume up** and **Volume down** buttons at the same time for 2 sec. |



## CALLS & MUSIC

| Right earcup | Calls & music | |
|---|---|---|
| | Mute/unmute microphone | Press the **Mute** button, when on a call Alternatively, move the microphone boom arm up to mute, or down to unmute |

| Left earcup | Sound modes | |
|---|---|---|
| | Cycle between ANC and HearThrough | Press the **ANC** button |
| | ANC mode | In ANC mode,press the **ANC** button 3s to switch different ANC mode |



## ON-HEAD DETECTION

The VT FLOW has sensors that detect when the headset is lying flat on a table or is being worn.

**THE SENSORS ENABLE THE FOLLOWING CONTROLS:**

*AUTO-PAUSE MUSIC*
When listening to music, taking off the headset will automatically pause the music.

Wearing the headset again will automatically resume the music. To manually resume the music, press the Play/pause button on the headset.



## VOICE ASSISTANT

The VT FLOW enables you to speak to on your smartphone using the Mute button.

| Right earcup | Voice Assistant | |
|---|---|---|
| | Activate Voice Assistant | Press the **Mute** button, when not on a call |

## BUSYLIGHTS

The Busylights on the headset automatically light up red when you are on a call to indicate that you are busy.

To manually switch the Busylights on/off, press the Volume up and Volume down buttons at the same time.

## ACTIVE NOISE CANCELLATION (ANC)

Active Noise Cancellation (ANC) counters noise by detecting and analyzing the pattern of incoming sound and then generating an anti- noise signal to cancel noise out. As a result, you experience a reduced level of surrounding noise during music and calls.

| Left earcup | ANC | |
|---|---|---|
| | Cycle between ANC and HearThrough | Press the **ANC** button |

## HearThrough™

HearThrough utilizes the built-in microphones to enable you to pay attention to your surroundings and engage in conversation without needing to remove the headset.

| Left earcup | HearThrough | |
|---|---|---|
| | Cycle between ANC and HearThrough | Press the **ANC** button |



## MUTE/UNMUTE USING THE MICROPHONE BOOM ARM

The headset microphone can be muted by moving the microphone boom arm up, or unmuted by moving it down.




## ANSWER CALL USING THE MICROPHONE BOOM ARM

## MULTIUSE

The headset can pair with up to eight Bluetooth devices and connect to two Bluetooth devices at once (e.g. the VT BT200U and a Smartphone, or two Bluetooth devices). The headset can accept multiple incoming calls from either device.

To pair with two Bluetooth devices, use the normal pairing process separately for each Bluetooth device.

## MULTIPLE CALL HANDLING

The headset can accept and handle multiple calls at the same time.

| Right earcup | Multiple call handling | |
|---|---|---|
| | End current call and answer incoming call | Press the **Call** button |
| | Put current call on hold and answer incoming call | Hold (2 secs) the **Call** button |
| | Switch between held call and active call | Hold (2 secs) the **Call** button |
| | Reject incoming call, when on a call | Double-press the **Call** button |



## HOW TO RESET

Resetting the headset clears the list of paired devices and resets all settings.

| Right earcup | Reset headset | |
|---|---|---|
| | Reset pairing list and settings | Ensure the headset is powered on and hold (3 secs) the **Call** button and the **Volume up** button simultaneously until the headset is disconnected and power off. The headset will enter the pairing mode automatically when power on again. |



## SOFTWARE AND FIRMWARE

**VT UC Bridge**

VT UC Bridge is a desktop application designed to support, manage and enable optimalfunctionality for VT devices.

Download the latest free version from: www.vbetglobal.com

**Update firmware**

Firmware updates improve performance or add new functionality to VT devices.

The headset firmware can be updated using either VT UC Bridge on your computer or the . Both applications will notify you when a firmware update is available.

The VT BT200U Bluetooth adapter firmware can be updated using VT UC Bridge on your computer.

## SUPPORT

**FAQ**

View the FAQs on https://www.vbetglobal.com/faq/

**How to care for your headset**

- Always store the headset in the supplied pouch.
- To prevent the depletion of the battery lifetime or capacity, avoid storing the headset in hot or cold environments, such as a closed car in summer, or in winter conditions.
- It is recommended to keep the headset between -10°C and 55°C (14°F and 131°F).
- Do not store the headset for extended periods of time without recharging them (max. three months).



**Important Safety Instructions**

To prevent possible hearing damage, do not listen at high volume levels for long periods.

**Product Disposal Treatment and FCC statement**

1. Dispose of in accordance with local regulations on headphones and recyclingregulations. Never treated headset as household waste. Do not dispose of the headset in a fire, this battery may explode. If damaged, the battery may explode.
2. FCC statement:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

**RF Warning Statement:**
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



**Xiamen VBeT Electronics Co.,Ltd**
Add: 9A03, Weiye Building, Xiamen Pioneering Park for Overseas ChineseScholars, PRC
Tel: +86-592-5778728
Fax: +86-592-5778708
E-mail: sales@vbetglobal.com
Web: www.vbetglobal.com