## BUTTONS

- This manual "Buttons" buttons are indicated by using the letters shown in the illustration.

A — Reset / Stop
B — Start
C — Left button
D — Right button

## FACTORY MODE

- LCD default is off before the watch out of factory.
- In the LCD off state, press and hold "D" button for 3 seconds to enter the Factory Troubleshooting Mode.
- You may need to set the watch(See Page16) before use it.

## APP INSTALL

### APP Install For Android System

1. Use mobile phone to visit https://play.google.com/store/search?q=jl+google+fitness&hl=en&gl=US&pli=1 to download "Google Fitness" APP. Or Scanning above QR code to download the APP. Or download APP directly search "Fitnessgenius", then you can install the APP prompt.
2. To install the "Fitnessgenius" APP, pls follow

Click "Google play" search app
Click "Install"
Click "Open"
Click "Allow"
Click "Agree"
Click "Allow"
Click "Allow"
Click "Allow