Declaración

Tener bien el manual de usuario para mantener su móvil en las mejores condiciones. El manual le sirve ofreciendo pasos generales de precisión. Las instrucciones y ilustraciones contenidas en el manual pueden ser diferentes de su teléfono. Los contenidos de este manual pueden ser diferentes debido a fallos de energía, el rendimiento de una aplicación, más opciones o modificaciones de notificación previa. Nuestra compañía se reserva los derechos en relación con el manual.

1. Introducción
-Contenido
Gracias por adquirir nuestro teléfono, puede convertir una vez los parámetros Bluetooth en un aplicación. Lo contenido original es GSM.
-Insertar la tarjeta SIM y batería
Apague el teléfono y retire el cargador desconectar el cargador antes de retirar y batería.
-Encender y apagar
Presione la tecla de "encendido" para encender o apagar el dispositivo. Cargar la batería que se ha agotado, PRI, PUK1 Pulse Pulsar la contraseña requerida Siga las instrucciones para cargar.
-Antena
Antena incorporada evita interferencias con antena interna y exquisita. El Apagado con otros dispositivos inalámbricos, no toque la antena de no ser necesario, ya que ello podría afectar la calidad de la comunicación y crear un consumo de energía mayores a los requeridos, reduciendo el tiempo de batería.
2. Método de llamada
Asegúrese de establecer el método de marcar deseado.
3. Contactos
Puede guardar la información de los contactos incluyendo nombres y números de teléfono en la tarjeta. La cantidad máxima de contactos en la tarjeta SIM depende del tipo de tarjeta.
4. Mensajes
SMS
El teléfono puede enviar y recibir mensajes SMS. Puede revisar la cantidad de mensajes almacenados en la tarjeta SIM en cualquier momento.
5. Buzón de voz
Puede establecer los números telefónicos con los que desea recibir mensajes en caso de llamadas no contestadas. Lo mensajes en caso de no recibir mensajes en caso de llamadas no contestadas.
6. Llamadas
Llamadas perdidas
Llamadas realizadas
Llamadas recibidas
Borrar todas las llamadas
7. Bluetooth
Puede establecer los parámetros de Bluetooth y enviar archivos a otros dispositivos compatibles con Bluetooth.
8. Conexión a PC
Administración masiva
Puede usar el Flash Manager en el teléfono como disco de almacenamiento.
9. Lenguaje
Puede establecer el idioma.
10. Configuración
Establecer los parámetros para sonidos y luz.
11. Calculadora
Aplicación de calculadora para realizar operaciones matemáticas simples.

Modo móvil
Modo móvil: Que permite la comunicación en este modo.
Modo avión
Modo avión: Que permite encender o apagar el modo avión.
8. WAP
Puede navegar por Internet a través de WAP, lo que significa que puede navegar en cualquier lugar. Navegar por Internet a través de WAP, lo que significa que puede navegar en cualquier lugar. Navegar por Internet a través de WAP, lo que significa que puede navegar en cualquier lugar.
7. Grabadora de Video
Con antelación, puede elegir la compresión de la cámara, entre esperada, ahorro de memoria.
8. Cámara
En las opciones de la cámara, puede establecer el modo de fotografía entre otros. Puede regular el Brillo para mejorar las formas que utiliza el teléfono.
9. Grabadora de voz
El reproductor de música reproduce archivos reconocidos como reproductor en la lista actual.
10. Reproductor de Video/ Visor de imágenes
Puede ver los archivos de imágenes y vídeos guardados por el equipo.
11. Administrador de archivos
Para la lista de memoria, puede establecer una carpeta para archivos **12.** Utilidades
13. Administrador de tareas
El Manual de Tareas consta en una lista de todas radiadas, tocadas, perdidas y enviadas. También puede establecer una alarma que apagada según su agenda.
14. Reloj
Establecer la hora/zona. Puede establecer el reloj manualmente.
15. Grabadora
Puede grabar sonidos para guardar o escuchar sonidos grabados.
16. Conexión
Tablas y estadísticas el punto de acceso GPRS.
Establecer el "Tablas de control" mencionado por el proveedor de red.
17. Alarma
Establecer el tiempo de la alarma. En el momento indicado por alerta para que suene, se puede establecer tiempo según sus conveniencias.
18. Bluetooth
Puede establecer las conexiones inalámbricas con otros dispositivos compatibles con este teléfono.
19. Conexión a PC
Administración masiva
Puede usar el Flash Manager en el teléfono como disco de almacenamiento.
20. Lenguaje
Puede establecer el idioma.
21. Configuración
Establecer los parámetros para sonidos y luz.
22. Calculadora
Aplicación de calculadora para realizar operaciones matemáticas simples.

23. SOS
Puede pedir SOS.
24. Aplicación adicional
Referencia al distribuidor de accesorios local. Aquí se incluyen algunas precauciones para el uso de los accesorios.
Mantenga el cargador fuera del alcance de los niños.
2. Nunca cortocircuite el cargador cuando desconectar de la fuente de poder, en caso de cada hubiera cuidado.
3. Asegurar regularmente los puntos de contacto sucios de que no se influye que estén limpios y secos para evitar la contaminación.
4. Los cortafuegos, cargadores y accesorios aprobados por el fabricante. Uso de otro tipo de accesorios puede invalidar una garantía de dispositivo y también causar daños.
5. Por favor, no coloque el cargador en un lugar con mucha humedad.
6. La batería y cargador son partes clave del funcionamiento de un teléfono y garantizar su funcionamiento regular es cuestión de seguridad. Se fundamentó en nuestra investigación de la batería y cargador, se ha logrado un rendimiento de carga y descarga de la batería. Si usted obtiene accesorios de otros marcas defectuosas que produzcan fallas en el equipo, en cuanto al daño y a cargador.
Cómo cuidar y mantener nuestro de cargadores y baterías inalámbricas
1. Evite la caída de la batería ya que una caída o un golpe de duración de carga de la batería.
2. Evite la caída del teléfono rotulamiento. El cargar encuadre ahorra la operación normal de las piezas de circuito y reduce la vida útil.
3. El rendimiento y confiabilidad del equipo se pueden ver comprometidos indudablemente cuando el cargador y baterías sean incompatibles.
4. Por favor, no cortocircuite la batería y no la arroje por ningún motivo. Siga cuidadosamente las instrucciones de consumo.
25. Avería de la batería
-Carga y descarga
La batería recargable es una parte el equipo. La batería puede ser cargada y descargada como un número de veces. Cuando la batería se agota, el tiempo de carga se hará más y más largo. Generalmente, cuando la batería, la batería es reemplazada y utilizada por primera vez, la batería ha sido maximizada por muchas llamadas en descarga, puede ser necesario cargar la batería durante varias horas. Cuando la batería se agota, el tiempo de carga es Cuando el cargador no está en uso, favor desconectarlo de la corriente eléctrica. Si la batería no ajusta a la electricidad, puede tener que esperar unos cuantos minutos a que el indicador de carga se muestre en la pantalla y luego puede comenzar cualquier llamada.

No use la batería para otros propósitos. Tan una batería o a ningún otro tendrá.

-Uso y trato de la batería
Evite el cortocircuito de la batería, de otra manera, la batería puede sufrir daños y generar calor y peligro de incendio.
No colocar la batería en altas temperatura o en fuego, de lo contrario, puede explotar.
No intente desarmar la batería.
Entregar el cargador en caso de daño o deterioro de la batería o cargador.
Reciclaje la batería o cargador. Entregar el cargador o la pila de recuperación apropiadas. No deben desecharse como basura doméstica.
26. Mantenimiento y servicio
Se requiere en el producto de diseño y proceso exquisito, favor usar con cuidado. A continuación, recomendar una serie de sugerencias para su uso y mantenimiento óptimo:
1. Mantenga seco. El agua de lluvia, humedad y otro líquido puede contener materias minerales, las que pueden ensuciar el cuerpo de circuitos eléctricos. Si el equipo se ha mojado, favor retirar la batería y secar el equipo inmediatamente.
2. No use o almacene en lugares sucios o polvo, de lo contrario las partes removibles del equipo y componentes electrónicos pueden sufrir daños.
3. No almacene en lugares calientes.
4. No almacenar el equipo en lugares fríos, de otra manera, cuando la temperatura se normalice, se generará humedad lo cual daña los circuitos.
5. No tire la batería al fuego, de lo contrario puede ocasionar el incendio. No lo intente de otra manera.
6. No trate a ayuda mal/maltrato el equipo. Cualquier maltrato a uso del mismo puede resultar en daños permanentes y los circuitos.
7. No use productos químicos agresivos, detergentes y productos cosméticos.
8. No dibuja sobre el equipo. La pintura puede bloquear substancias ajenas en partes removibles y afectar la operación normal.
9. Cuando el teléfono está en modo de vibración, el motor vibrador está en marcha. Por lo tanto, el equipo se ubicará en una superficie dura, de lo contrario, el teléfono puede caer y dañarse.
10. Cuando el equipo, por ejemplo, sea dejado en el bolsillo, el conector de la batería puede ser dañado.
11. Cuando el equipo se ubica en una superficie dura, de lo contrario, el teléfono puede caer y dañarse.
12. La información de respaldo del sistema.
13. Cuando el equipo se ubica en una superficie dura, de lo contrario, el teléfono puede caer y dañarse.
14. Las experiencias en otras aplicaciones al cargador y la batería, lo cual de funcionamiento irregular favor consulte técnico para pedir más consejos.

Model: GO

RAYO
MOVIL

WWW.RAYOMOVIL.COM

FCC Caution

Labelling requirements.
This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.
Notice: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:(1)this device may not cause harmful interference, and (2)this device must accept any interference received, including interference that may cause undesired operation.
Specific Absorption Rate (SAR) information:
This **mobile** phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.
FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Portable Equipment(FCC ID:2ACJAWVGO)has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the head is 0.49 W/kg and when properly worn on the body is 0.20 W/kg. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that does not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Body-worn Operation
This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10mm must be maintained between the user's body and the handset, including the antenna. The body belt clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.

Declaration

Please read the user's manual to keep your mobile phone in the best condition. The manual has been designed to provide you with clear and precise instructions. The instructions and illustrations herein are accurate at the time of publication. However, mobile phones do sometimes malfunction, and the contents of their manuals are subject to modifications without further notification. Our company reserves the rights in relation to the manual.

1. **Introduction**
Contents
Phone password
With the phone password, you can prevent others from using your mobile phone without your permission. The factory default is 1234.
Insert the sim card and the battery
Ensure to turn off the equipment and disconnect with the charger before taking out the batteries.
Switch on/off
Press the Power/ power button to start up or shut down the mobile phone.
If it is unused for long, if the SIM/ PIN/ phone lock/ the required password (shown as ****) are the same.
Antenna
The mobile phone may be provided with built-in and exposed antenna, but the using any other radio and transmitting devices, don't touch the antenna if not necessary because it may affect the quality of telecommunication and result in equipment operating in an energy level higher than the required, thus reducing the service life of the battery.
1. **Input Methods**
Need to be sure to change one of Input Methods.
2. **Phone book**
You may save the information of contacts including names & telephone numbers in the phone book. The valuable entries of one card depend on the type of the card.
3. **Messages**
SMS
The cell phone supports sending and receiving of SMS. You may check the quantities of sent messages and received messages in the SIM card at any time.
Write a message: You may select multiple numbers to send the message to more than 5 persons (only sending. You may select to add the SMS setting either of SIM card 1 or 2. when, you can set the numbers of the service center (which is obtained from the service provider).
5. **Settings**
General
Phone setting
Time may get lost some in situations in cell phone security. (phone lock 1234)
Restore the factory settings
Enter the correct password of the phone will restore to change your phone settings back to factory default state value, the user of this function to used with caution. (Default password: 1234)

- **Phone**
Network setting
The option is related to your network provider. Please get in contact with the network provider for details.
Dual Mode
Dual Mode: the communication function is available in Dual- mode.
Network
You may select modes of dual standby and single pass, SIM 1 or/SIM 2 in and Dual mode.
WAP
Wap wap mobile world WAP Browser, which means that you may surf on the Wap sites and in any time and in any place. You already phone get in touch with the network and access to internet.
- **Video recorder**
In the options of the video camera, you may set the exposure compensation, wondersa of the shot, the white balance, special effect, specific etc.
- **Camera**
In the options of camera, you may set the photometry mode etc. You may enter the album to view the photos taken by cell phone.
- **Audio Player**
The music player is used to play music files in supported by tracks in the current player's list.
- **Video Player/ Image Viewer**
Check the video or pictures files supported by the cell phone.
11. **File manager**
Insert a memory card, you may establish a data file folder etc.
12. **Cell Battery**
The cell list lists all types of cells, including normal cores, dialed cores and unanswered cores, or you may check the required list of missed calls, dialed calls and answered calls for check or operation.
13. **FM Radio**
Tune in the FM Broadcast, and you may manually tune the channel.
14. **Recorder**
Use this function you can record or listen to your own record.
15. **Connection**
Call out to the GPRS access point
Hint: The "account data" is to be provided by the network operator.
16. **Alarm**
Set the time of alarm clock, At the time of alarm clock, an alarm ring will be given so
17. **Bluetooth**
Bluetooth
Bluetooth
Use the function of Bluetooth, and you may establish a data file folder etc.
18. **Connection to PC**
Mass storage
Use the T-Flash inserted in the mobile phone as a U-Disk.

19. **Lamp**
Set the lamp lamp function.
20. **Calendar**
Support Calendar function.
21. **Calculator**
Support Calculator function.
22. **SOS**
Support SOS function.
23. **Original accessories**
Refer to the distributor.
Keep the cargador out of the reach of children's reach.
2. Never short circuit the charger when unplugged from power outlet or cut off the power supply.
3. Regularly check the mobile equipment in the accessoriesfor can sensitive (You can correctly installed and wiched were normal).
4. Cable, charger and other accessories approved by the manufacturer. Usage of other types of batteries, chargers and accessories may result in violence of the certification or warranty terms or even lead to danger.
5. Do not place the charger in a high humidity place?
Battery and charger are key parts of a mobile part because they play important roles in guaranteeing the normal operation of the mobile phone as well as your safety. It is drawn in our research on the battery and charger, we have achieved a charge and discharge of the battery. Failure to obtain accessories of other brands may result in equipment failure or even danger.
How do resulting from usage of ineligible battery and charger
1. Short circuit of battery, otherwise, the battery life will be greatly shortened and may result in damage of the internal circuit.
2. Avoid the battery falling, otherwise, the battery life will be greatly shortened.
3. The performance and reliability of the equipment may result in damage of the circuit and reduce the service life.
4. Do not throw in fire or shake the equipment. Any rough treatment of the equipment may result in damage of the inner circuit board and its exquisite structure.
5. Don't leave the equipment with anhydrous chemicals, detergent or strong acids.
6. Do not use the equipment to draw or write on it. Painting may block foreign substances in detached parts and thus affect the normal operation.
7. When the ring with chain, dry cell, cloth brush or the camera lens, charge sensor and light sensor).
8. Only use matched or approved antenna for substitution of the damaged one. Unapproved antenna, alteration or accessories may result in damage of the equipment and violence of the certification or warranty terms and conditions.
9. Please use the charger in indoor only.
10. Backup data that should be kept such as the add-ons (ringtone and calendar memorandum).
11. Please turn off the equipment and take out the battery to isolate the equipment setting ineligible to maintain the optimal performance.
12. Please use the original accessories, equipment, battery, charger and other accessories. In case any device doesn't work, please take it to the nearest authorized maintenance agency for repair.

- **Usage and treatment of battery**
Avoid short circuit of battery, otherwise, the battery may be damaged, and generate heat to cause fire hazard.
Do not place the battery in high temperature or in fire, otherwise, it may explode.
Don't attempt to make apart the battery.
Stop usage in case of damage or obvious aging of battery and charger.
Recycle the battery and charger or return to supplier or specified recycle site.
Don't throw it away or dispose in domestic garbage.
20. Maintenance and service
Your equipment is a product with exquisite design and process. Please use carefully.
Following are some suggestions for you to efficiently use the maintenance service:
1. Keep it dry. Rainwater, humidity, liquid and other kinds of minerals may contain mineral substance, which may erode the electronic series. If the equipment is wet/out, please take out of the battery till the equipment is dry. Dry and then put in the battery.
2. Don't use or store the equipment in dusty or filthy place, otherwise, the detachable parts and electronic elements may be damaged.
3. Don't place the equipment in overheated places.
Battery and charger are key parts of a mobile part because they play important roles in guaranteeing the normal operation of the mobile phone as well as your safety. It is drawn in our research on the battery and charger, we have achieved a charge and discharge of the battery. Failure to obtain results from usage of ineligible accessories, especially ineligible battery and charger.
How do resulting from usage of ineligible battery and charger
1. Short circuit of battery, otherwise, the life of the battery is greatly shortened and may result in damage of the internal circuit board and its exquisite structure.
2. Avoid the battery falling, otherwise, the battery life will be greatly shortened.
3. The performance and reliability of the mobile phone, lowering its charge capacity and reduce the service life of the battery.
4. Do not throw in fire or shake the equipment. Any rough treatment of the equipment may result in damage of the inner circuit board and its exquisite structure.
5. Don't leave the equipment with anhydrous chemicals, detergent or strong acids.
6. Do not use the equipment to draw or write on it. Painting may block foreign substances in detached parts and thus affect the normal operation.
7. When the ring with chain, dry cell, cloth brush or the camera lens, charge sensor and light sensor).
8. Only use matched or approved antenna for substitution of the damaged one. Unapproved antenna, alteration or accessories may result in damage of the equipment and violence of the certification or warranty terms and conditions.
9. Please use the charger in indoor only.
10. Backup data that should be kept such as the add-ons (ringtone and calendar memorandum).
11. Please turn off the equipment and take out the battery to isolate the equipment setting ineligible to maintain the optimal performance.
12. Please use the original accessories, equipment, battery, charger and other accessories. In case any device doesn't work, please take it to the nearest authorized maintenance agency for repair.