nubia

TWS T1

Bluetooth Earbuds

Package content

▲This product is made of professional health materials and has passed the strict skin allergy test, has hemo by your body.
▲Due to individual differences, if you feel skin discomfort during wearing, please remove it and consult your doctor.

Product appearance

Earbud wearing

Operation mode

Power on (slow flashing white light)
Take out the earbud from the charging box and turn it on automatically, and the voice prompt "Power on"will appear.

Power off
Put the earbud back into the charging box, and it will automatically turn off and enter the charging state.

Pairing the earbud with the mobile device

1.Charging the earbud: put the earbud into the charging box, and the earbud will automatically turn off and start charging.
2. Pairing the earbud: open the lid of the box for 5 seconds charging. The left-ear Bluetooth, and the right-ear Bluetooth will be paired automatically. 3. Check the battery capacity: Take the earbud out of the charging box and put it back to check the battery capacity.

Factory resetting (clear pairing records)

When the earbud is in the charging box, click the charging box twice quickly and press for 1 s for the second time to clear the pairing record between the earbud and the mobile phone.

Bi-ear touch mode

- **Play / pause music**
  Single click on the earbud (Music playing or pause)
- **Play the next song**
  Double click on the earbud (Music playing)
- **Play the last song**
  Triple click on the earbud (Music playing)
- **Answer / and call**
  Single click on the earbud (Ringing)
- **Refuse to answer a call**
  Triple click on the earbud (Ringing)

Game mode

When the mobile phone is connected, press and hold the touch panel of L/R earbud for 3s to enter the low delay mode. Operate again to switch back to the music mode.

Charging box instructions

Charging status of earbud and charging box:

1.Charging the earbud: put the earbud into the charging box, and the earbud will automatically turn off and start charging.
2. Charging the charging box: open the lid of the charging box. The charging box will be fully charged in 5hrs.
3. Check the battery capacity: Take the earbud out of the charging box and put it back to check the battery capacity.

FAQ

1. Question: Why is there only one earbud with sound?
Answer: Please check if the other earbud is in the charging box and then take it out again to see if the earbuds resume the connection. Regardless of both earbuds, if not record the earbuds to stake the problem.

2. Question: What to do if the earbuds cannot find the connection cannot connect to the mobile phone?
Answer: Delete the pairing record between the phone and the earbuds, and then current open and perform pairing connection again after restarting.

3. Question: Why is there no sound when listening to songs/making calls?
Answer: If it is an accidental error, please click the setting icon on the right to enter the Bluetooth connection record, unpair the two audio options of the earbuds, and then reconnect the earbuds. If it is a mobile phone general audio's function setting, and invalid the automatic option, if not restored, delete the pairing record and try.

4. Question: Why is there a delay in video/game?
Answer: Affected by the environment, network, and mobile phone codec factors, there may be a delay in the game mode. It is recommended to transmit audio data to the earbuds. (Turning on the game mode will increase the power consumption and decrease the use duration. It is recommended to use it when playing games or watching videos. Turn off when the telephone voice function is enabled in the game mode, and the sound clarity of the game will be affected because the current game mode is the low-delay mode, and the call function is not supported.)

5. Question: Why does it pair automatically when it is not paired?
Answer: When using the earbuds, if there are a list of Wi-Fi connections, the Wi-Fi signal is unstable, and the signal is weak, the Wi-Fi signal and the earbuds may be stuck or interrupted. It is recommended to change the environment and try to pair the connection.

Specifications and parameters

Product Model	TWS T1
Product Name	Bluetooth Earbuds
Product Size	24.5mm*24.5mm*24.5mm
Product Weight	4.5g
Charging Interface	Type-C
Charging Time	Charging box: 5hrs Earbud: 1.5hrs
Charging Voltage	5V
Charging Current	200mA
Charging Mode	Charging box Wireless charging box
Battery Capacity	Charging box: 400mAh Earbud: 40mAh
Bluetooth Version	V5.3
Bluetooth Frequency	2.402GHz-2.480GHz
Bluetooth Transmitter Power	3.5dBm
Bluetooth Transmitter Distance	10m
Bluetooth Protocol	A2DP1.2,AVRCP1.5,HFP1.6,HSP1.2
Bluetooth Codec	SBC,AAC
Bluetooth Transmitter Mode	Single Channel
Bluetooth Transmitter Frequency Band	2402MHz-2480MHz
Bluetooth Transmitter Bandwidth	1M
Bluetooth Transmitter Modulation Mode	GFSK
Bluetooth Transmitter Data Rate	1Mbps
Bluetooth Transmitter Channel Number	79
Bluetooth Transmitter Channel Spacing	1MHz
Bluetooth Transmitter Channel Bandwidth	1M
Bluetooth Transmitter Channel Modulation Mode	GFSK
Bluetooth Transmitter Channel