ROWKIN

Ascent Charge+ / Micro Earbud

NAAT10AA-Erabud

Rowkin Ascent

无线立体声蓝牙耳机+移动电源使用手册

True Wireless Bluetooth Headset+Power Bank

每一个耳机都可以单独使用

施立诺勤科技（深圳）有限公司

Ashley Chloe Inc.

感谢您购买ROWKIN Rowkin Ascent无线立体声蓝牙耳机。本手册将帮助您快速开始使用该蓝牙耳机，在使用蓝牙耳机之前，请必须事先了解和熟悉您手机的蓝牙功能，为您充分享用您的耳机，启动您的娱乐功能。

安全规则

1. 为确保安全，请勿拆开此手册中提到的部件，此使用蓝牙耳机之前，务必遵守此说明说明书手册。
2. 请勿重复按照手册的说明，不要改装，重装，配件和拆卸。
   以免出现您可可能的危害。
3. 请不要拆卸，修理此产品，这样可能会导致起火，电子危害等意外或损坏本产品，这些都不在保修之内。
4. 请不要将此产品放在有高温或易爆的环境下使用。
5. 请不要在有危险的地方使用本产品。

配件清单

耳机

左 右

大号 中号 小号

耳塞

移动电源

USB线

Type-C

NAAT10AA-Erabud

使用手册

图示

1. 耳机触控键
2. 耳机指示灯/麦克风
3. 耳塞
4. 移动电源
5. 移动电源状态指示灯
6. USB插入
7. 耳机充电指示灯

耳机充电方式

通过第一次使用前充满耳机和充电盒的充电操作，确保耳机和工作时，充满时间过可能。充满电后灯灭。

充满电后灯灭

注：1. 首次播放前请充电。耳机LED蓝灯慢闪。
2. 耳机充电盒时，耳机灯灭闪烁。

单个耳机使用操作说明

1 开机 / 关机

开机：长按触控键约3秒，蓝灯快闪一下开机，并根据设备

关机：长按触控键约3秒，红灯快闪一下开机，并根据设备

开机 关机

2 设备配对：初次连接使用

打开充电盒，蓝牙耳机充电盒开，耳机进入自动配对模式，红灯交替快速闪烁，此时打开手机蓝牙搜索“WS-TJ”并点击连接，如果需要密码输入“0000”即可。

3. 配对成功后，开启后的手机会自动重连已通过，重复您的音频体验
4. 唤醒：轻触单击，轻触一下触控键键通电话，通话中轻触一下触控键挂断电话
5. 恢复单电：单单单击两下触控键恢复单电
6. 音乐：轻触一下触控键暂停/播放音乐
7. 音量+/音量-：按住音乐时，长按触控键并音量会从最小到最大循环。
8. 下一曲：按住音乐时长按触控键下一曲
9. 上一曲：按住音乐时长按触控键上一曲

双耳模式说明使用说明

1 开机

长按触控键约3秒，蓝灯快闪一下开机，并根据设备

开机

2 关机：只用其一个

开机状态下长按触控键约3秒，长松指示灯红灯快闪一下，同时出现相应的提示音，此时手机蓝牙连接断开相关于手机状态时，只要其余一个耳机，其一个单独设备。

3 设备配对：初次连接使用

1. 打开充电盒，蓝牙耳机充电盒开，耳机进入自动配对模式，两个耳机红蓝灯交替快速闪烁，此时手机上可搜索到两个“NAAT10AA-Erabud”，即表示蓝牙

连接成功

2. 两个耳机将自动互相连接，长松耳机连接上之后，一个耳机蓝灯慢闪，一个耳机红灯常亮闪烁，此耳机常亮为主耳机，此时蓝牙连接上显示一个“NAAT10AA-Erabud”

主耳机（红灯常亮）

4 搜索连接

主耳机蓝灯常亮长时间闪烁，此时手机上只显示一个“NAAT10AA-Erabud”的耳机名称，如果需要密码输入“0000”即可

5 播放音乐

播放音乐：与手机连接成功后一下任一耳机触控键音乐自动播放

音乐暂停：播放中轻触一下触控键音乐暂停

6 音量+/音量-

按住音乐时长按触控键并音乐从最小到最大再从最大到最小循环

7 下一曲

音乐播放时轻触一下触控键下一曲

8 上一曲

音乐播放时三击触控键上一曲

注意：在两个耳机自动互相连接时之前，请不要点击手机上的“NAAT10AA-Erabud”耳机，否则将无法实现立体声功能。

快充功能

根据充电盒可以以耳机可以同时使用同步时的即时时间，以分钟充电或能够在1-5小时的使用时间。

移动电源电量显示

充电状态下，LED指示灯常亮表示电量状态，充满后自动关闭，此时此时，LED指示灯常亮表示电量状态。

电量0%-25%——个LED指示灯亮

电量25%-50%，两个LED指示灯亮

电量50%-75%，三个LED指示灯亮

电量75%-100%，四个LED指示灯亮

闪烁2秒 25% 50% 75% 100%

产品参数

项目	参数
耳机	
电池	锂离电池60mAh
耳机重量	4.7克
蓝牙版本	V5.0
工作电压	3.3V-4.2V
耳机充电电流	≤40±20m
蓝牙传输	3.4-3.48GHZ
蓝牙距离	≤10米
音频传输格式	A2DP HFP HSP AVRCP
移动电源	
充电容量	400 mAh
充电重量	25 grams
DC 输出电压	DC5V
DC 输出电流	1A
DC 充电电压	DC5V
DC 充电电流(MAX)	1A

产品认证：FCC/CE/ROHS/BQB

注意事项

1. 请勿将ROWKIN Rowkin Ascent无线立体声蓝牙耳机和其他无线等离频设备，请在使用前确认耳机的正常工作。
   如遇耳机在一段时间内（约10分钟）用不到耳机时间，则自动关机。

保养

- 必须选用正厂配件产品以防耳机电池，如果产品有异（超出10天）不用，请对耳机。

警告

1. 请在长期将设备置于通过或或过高（计以下或40℃以上）的环境下，确保的温度在导致设备发热，降低设备的性能表现，并相应设备的寿命。
2. 不要设置高天下使用设备，最要可能导致设备出现故障，或大电击的风险。
3. 切勿以任何理由将拆卸设备或耳机，因为可能导致无法生成保修资格，请先将此使用指南阅读并以进行使用。
4. 请勿将设备放置在有高温或以及有易燃物品附近的地方，设备小型配件可能导致窒息产重危害。
5. 请在拆开产品后入水中。

故障排除

故障	原因	解决方法
开机不成功	电量不足	对耳机进行充电
无法进行充电	充电不正确	重新充电
可以通话，但音乐播放不成功	手机与耳机蓝牙连接断开	请检查手机蓝牙设置
单耳工作时，另一耳机无法工作	单耳工作时，另一耳机蓝牙连接断开	检查其他设置并重新连接
耳机未成功连接	手机蓝牙未开启	开启手机蓝牙
耳机充电时	充电时间不足或不稳定	请等待充电至少一个小时
通话音质差	环境干扰或蓝牙信号接收不稳定	换一个安静的地方或关闭其他无线设备
对方声音小	手机音量设置过低	调高手机音量
佩戴不牢固，掉落频繁	耳塞选择不合适	尝试更换不同尺寸的耳塞，或调整耳机位置

联系与支持

更多产品与服务支持，请查阅以下网站 www.rowkin.com

Congratulations, and thank you for choosing NAAT10AA-Erabud Bluetooth headset.

This manual will help you operate the headset, but you should first familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Headset. To enjoy your time with our product.

Safety rules:

1. Please follow the rules described in this manual closely to ensure your safety. Before using this Stereo Headset, we would strongly recommend you read this manual carefully.
2. Be more wary of any edge, uneven surface, metal parts accessories and its packaging so as to prevent any possible injury or damage.
3. Do not modify, repair or dismantle this Bluetooth Stereo Headset. Doing so may result in fires, electric shocks, complete breakdown of this Sport Bluetooth Stereo Headset, etc. All of which, are not covered under warranty.
4. Do not place this headset in volatile or volatile liquid to clean the Sport Bluetooth Stereo Headset.
5. Do not use the Sport Bluetooth Stereo Headset in a hazardous location.

Accessories

Headset

Left Right

Small Medium Large

Ear Tips

Power bank

Type-C

NAAT10AA-Erabud

User manual

USB charging cable

User manual

Graphical Representation

1. Touch control button
2. Microphone and LED indicator
3. Ear Tips
4. Charging case
5. Charging case indicator
6. Micro-USB Charging Port
7. Headset charging status LED indicator

FIT

In order to get best audio performance, Try every earbps (Small, medium and large). The correct seal in your ear to achieve optimal fit and stability.

Charging

Take out the headset and charging cradle must be fully charged for the first time to use.

1 Charge the bluetooth headset:

Magnetic contact recharging, the LED indicator will be solid red when charging, and will turn off when the earbuds fully charged.

Take out

The red indicator light will be off if it's fully charged.

Note:
1. When you playing the music, blue LED light flashed slowly.
2. The red light will flash when the battery is low.

Single headset operation

1 Power on / Power off

Power on: Long press the touch control button for about 3 seconds, the indicator light will flashes blue

Power off: Long press the touch control button for about 3 seconds, the indicator light will flashes red

3 seconds 3 seconds

Power on Power off

2 Pairing: first time to use

Open charging case bluetooth headset is discharged, bluetooth headset enters automatic pairing mode,the indicator light will flashes red and blue alternately, you can search bluetooth device name "WS-TJ" and click connecting, if ask for passkey, pls enter "0000".

3 seconds

Power on

3 Once the headset is successfully paired and connected with your mobile phone,you can use it to make a call and listen music.

4 When receiving a call, the headset automatically prompts to answer the incoming call.Tap the touch control button once to end a call.

5 Reject call: Double-tap the touch control button to reject the coming call

6 Tap the touch control button once to pause music /play music.

7 Volume+/Volume- :when listening music long press touch control button, volume will from low to max.

8 Next Song: When listening music double tap the touch control button to next song.

9 Last Song: When listening music triple tap the touch control button to last song.

Stereo headset operation

1 Power on

Long press the touch control button for about 3 seconds, the indicator light flashes blue and you will hear a warning tone.

3 seconds

Power on

2 Power off: power off one headset only

Press and hold the touch control button for 3 seconds the LED will be flashing red and a notification sound will be heard accordingly. Only need to power off one headset, the other one will power off automatically if two headsets connected.

3 Pairing: first time to use

1. Open charging cap bluetooth headset is discharged, bluetooth headset enters automatic pairing mode, the indicator light will flashes red and blue alternately, you can search bluetooth device name "WS-TJ" and click connecting, if ask for passkey, pls enter "0000".

Connecting

2. Two headsets will pair to each other automatically, after then one headset blue LED flashes slowly, another headset LED flashes red and blue alternately,the one is master headset left channel, at this time you can see only one "NAAT10AA-Erabud" in your phone.

Master headset(Left)

Connected

4 Search and connection

When master headset flashes red and blue alternately, Please wait several seconds until only one "NAAT10AA-Erabud" show in your phone then click to connect, (not the code "0000" if needed.

Master headset

Notice:
Please do not click "NAAT10AA-Erabud" to connect before two headset connected to each other,Otherwise the stereo function is not available.

5 Pairing sucessful

Master headset LED flash blue once every 3 seconds and slaver headset flash blue twice every 3 seconds after paired successfully, you can hear "Pairing sucessful" in your phone and headset. Slaver headset LED flashes blue twice every 3 seconds in the first time it will connect automatically from second time after headset power on.

Master / Left Slaver / Right

6 Calling

Only that Main headset can hear the voice when calling and only the button of it can work.

Tap the button once: Tap the touch control button once to answer the incoming call. Tap the touch control button once to end a call.

Double-tap: Double-tap the touch control button to reject the coming call

7 Play music

Tap the touch control button once to play music.

Tap the touch control button once to pause music.

8 Volume+/Volume-

when listening music long press touch control button,volume will from low to max respectively

9 Next song

When listening music tap the touch control button once to next song.

10 Last song

When listening music triple the touch control button to last song.

Fast Charging

Thanks to a charging case that holds multiple additional charges for more than 3 hours of listening time.Just 10 minutes in the case gives you 1.5 hours of listening time.

Charging Pod battery status

Charging status, the number of blue LED light indicator battery status, the LED indicator will turn blue when the charging Pod is fully charged.

Power off status: LED indicator indicate battery status

Power 0%-25%: one blue LED indicator lights on

Power 25%-50%: two blue LED indicator lights on

Power 50%-75%: three blue LED indicator lights on

Power 75%-100%: four blue LED indicator lights on

every 2 seconds 25% 50% 75% 100%

Specifications

Items	Specifications
Headset	
Battery	Button Cell 60mAh
Earbud Weight	4.7 grams
Bluetooth Version	V5.0
Working voltage	3.3V-4.2V
Microphone sensitivity	-40±2dB
Bluetooth frequency band	3.4-3.48GHZ
Bluetooth range	10M
Audio transmission protocols	A2DP HFP HSP AVRCP
Charging Pod	
Capacity	400 mAh
Weight	25 grams
DC output voltage	DC5V
DC output current(MAX)	1A
DC charging voltage	DC5V
DC charging current(MAX)	1A

Product Certificate： FCC/CE/ROHS/BQB

Notice

1. The mobile can not find the headset if the NAAT10AA-Erabud is not paired. Please ensure the headset is in pairing model before you search it. (red and blue lights flashing alternately)
2. If the headset is not first pairing device for five minutes, it will power off automatically.

Warm Tips

You must select a qualified adapter to charge this product.
You must charge the Bluetooth headset if it has not been used for more than 3 months.

Warning

1. Do not put the product at the environment of too low or too high temperature (-10℃ or 40℃ above) for long time,otherwise reduce the battery capacity, even shorten service lifetime.
2. Do not use the device when the thunderstorm coming, may cause a failure, and increase the risk of shock by lightning.
3. Do not remove or modified headset for any reason, otherwise may cause fire, electric shock, etc. Please send headset to authorized service center for repairs.
4. Place the device and all accessories out of the reach of children and pets, small parts may be swallowed cause suffocation and serious consequences.
5. Do not put the headset into the water.

Troubleshooting

Phenomenon	Reason	Solution
Starting up failure	low battery	charge for the headset
No sound after paired	wrong paired	re-pairing
Pairing successfully but no sound	low battery warning	please charge immediately
Pairing failure	Headset didn't put into the charging cradle well	check the headset if it's well put into
Short talkin time	low battery	charge for the headset
Low volume of the sound	volume is too high or environment is too noisy	adjust volume or change environment
Noise during phone calls	Bluetooth connection of headsets is too far away from device	shorten the distance between headsets and device
Low volume of the caller	wrong seat of headphone	adjust headphone position
Signal is not well, interrupting	environment disturbance or too far away from device	far away from the interference source or shorten the distance between headphone and device

Warranty and Support

For more products and supports, please visit our company website:

www.rowkin.com

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

– Reorient or relocate the receiving antenna.

– Increase the separation between the equipment and receiver.

– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

– Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.