WIFI Thermometer Hygrometer User Manual

● OVERVIEW

Indicator

SET button

ON/OFF

● FUNCTIONS

Indicator:
A. OFF under normal status;
B. blinks when in pairing mode;
C. turns On for 0.5s when pairing completed.

Inspection hole

ON/OFF:
A. ON to turn on battery power.
B. OFF to turn off battery power.

SET button:
press and hold for 5s, pairing starts with the indicator blinking.

● PAIRING

1、Scan the QR code below, or search 'Smart Life' at APP store or Google Play to download the app.

Smart Life

2、Pairing with smartphone
(1)Connect your smartphone to WiFi （2.4GH）and enable Bluetooth.

China Mobile
16:45
Thursday, March 16

WiFi   Bluetooth   Flashlight   Sound   Auto-rotate

Huawei Share   Airplane mode   Mobile data   Location   Screenshot

Auto

(2)Switch ON the detector, press and hold SET button until the LED indicator blinks. Detector enters pairing mode.

• press and hold for 5s，Indicator blinks constantly

SET
ON/OFF

(3)Open'Smart Life' app,, click'Add Device' on the upper right corner.

No devices

Add Device

Home   Scene   Smart   Me

---

(4)When the detector is discovered, click'Add'.

Add Device

Searching for nearby devices. Make sure your device has entered pairing mode.

Discovering devices...

Add

(5)Enter WiFi password, then click'Next'.

Enter Wi-Fi Information
Choose Wi-Fi and enter password

gttc

••••••••

Next

(6)Detector being added.

China Mobile
Add Device

1 device(s) being added

Temperature Humidity...
Added successfully

(7)Click'Done' to complete.

Add Device

1 device(s) added successfully

Temperature and humi...
Added successfully

Done

● APP OPERATION

1、Main Interface.

Temperature and humidit...

Temperature   Humidity
29.1℃   69%

Temperature hot,Air moist

Temperature ℃   Humidity %

2. Historical alarm
(1) Click on 'Record';
(2) You can view "Record" and "Automation record".

Record   Automation Record

16

Record

Smart

Set

Close

3. Linkage settings
(1) Click on "Smart";
(2) Enter the "Smart" interface and click the "+" sign;
(3) Enter the linkage setting interface, set the linkage, and save it.

4. Settings

(1) Click "Set" to enter the set interface.

(2) After entering the "Set" interface, you can view the battery Power, temperature alarm, and humidity alarm status display information.

(3) After entering the "Set" interface, click on "Temperature MAX and MIN " and" Humidity MAX and MIN ", which can To set temperature and humidity alarm values.

(4)Slide down to check the settings for 'Alarm set', all options turned ON by default. Turn it OFF if you don't want any of the alarm notification pushes.

Battery level	middle
Temp alarm	Release temp alarm
Humidity alarm	Release hum alarm
Temperature MAX and MIN	-10.0℃~60.0℃ ›
Humidity MAX and MIN	0%~100% ›
Alarm Set	
Low temperature	●
Low battery	●
High temperature	●
High humidity	●
Low humidity	●

● INSTALLATION

1、Battery installation.
①pry out the back case on the detector with a screwdriver.

②Load the batteries.

1.5V AA dry battery*2

③Battery loaded.   ④Close the back cover.

2、Installation with adhesive tape.
①Peel off one side of the adhesive tape and paste it onto back cover of the detector.
②Peel off the other side of the adhesive tape, and paste the detector onto the installation position.

Attention: Do not apply the foam adhesive backwards to cover the sensor detection port, otherwise the temperature and humidity values detected will be inaccurate.

The detection port cannot be obstructed

① ②

3、Like the following.

● BATTERY REPLACEMENT

①detach the sensor
②pry out the back case with a screwdriver.

detach

③take out the batteries

ON/OFF

detach

● TECHNICAL SPECIFICATIONS

Input Voltage：DC3V
Static Current：<100uA
Alarm Current：<30mA
Low Voltage Threshold：<2.4V
Wi-Fi:802.11/b/g/n
Detection Temperature：-10℃~+60℃
Detection Humidity：0~100%RH
Working Temperature：-10℃~+60℃
Working Humidity：max.90%RH
Product Dimension：76*32*20mm

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received,including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for Compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help important announcement .

Radiation Exposure Statement

To comply with FCC RF exposure compliance requirements, this grant is applicable to only mobile configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.