Back of TV



Main board



Back Board

















frame and grass before screen

Board Position






Antenna


EXT-WIFI
CN6 CN7
CN8807
LED DRIVER
CN8832
CN8821
BB303
BB304
DB302
CB356

U_FPC_68PIN_80MM BH1545 1
(LH41-13430A)