61

120

AIDEAZ

ID1001 wireless charge

User's manual

安全注意事项 Safety precautions:

产品使用前，请仔细阅读产品说明书并保存以便日后查阅。

Please read the instructions carefully before using the product.

- 请勿自行拆解、改装、修理产品，以免发生火灾、爆炸、触电等安全事故。
  Do not disassemble, modify or repair the product by yourself, to avoid fire, explosion, electric shock and other safety accidents.
- 产品使用过程中如出现异常情况（如冒烟、发热、异味、异常噪音等），请立即停止使用，并联系专业人员进行检查。
  If the product is found to be abnormal during use (such as smoke, heat, odor, abnormal noise), please immediately stop using it and contact professionals for inspection.
- 请勿将产品放置在易燃、易爆、潮湿、高温、腐蚀性环境中使用。
  Do not place the product in flammable, explosive, humid, high temperature, corrosive environments.
- 请勿将产品放置在儿童或宠物可接触到的地方。
  Do not place the product where children or pets can reach it.
- 请勿将产品与其他电子设备混用，以免发生干扰或损坏。
  Do not mix the product with other electronic devices, to avoid interference or damage.
- 请勿将产品浸入水中或使其受到剧烈撞击。
  Do not immerse the product in water or subject it to violent impact.
- 产品使用完毕后，请关闭电源开关，并将其妥善保管，避免被儿童误用。
  After using the product, please turn off the power switch and store it properly to prevent children from accidentally using it.
- 请勿擅自更换产品的电池或其他零部件，以免发生安全隐患。
  Do not replace the battery or other components of the product without permission, to avoid safety hazards.
- 请勿将产品与其他电子设备混用，以免干扰其正常工作。
  Do not mix the product with other electronic devices, to avoid interfering with their normal operation.
- 请勿将产品放置在儿童或宠物可接触到的地方。
  Do not place the product where children or pets can reach it