A1

Smart Projector

User Manual

Note: All the pictures in this manual are for reference only.
Subject to actual product.

◆ Safety Warning

- To avoid emergence of illegal operation, read through the following precautions before using this device.

- In order to provide the device with stable power supply, select the power supply device that conforms to the national electricity standard and the power sockets for which protections measures are taken, such grounding.

- Use the type of power supply indicated on the device.

- Do not unpack and disassemble the machine by yourself, otherwise we will not undertake any free warranty service.

- When cleaning, do not look directly at the projector lens when the device is working.

- Do not place the device on any items that may block the ventilation openings, such as cloth, blankets, etc.

- Since this device is not waterproof, avoid water drenching or splashing, and do not place the items containing liquid near to the device, such as the vases, water cups, etc.

- To prevent electric shock, do not expose the device to rain or water.

- Unplug the power cord if the device will not be used for a long time.

- Transport the device with the original foam.

- Do not try to repair by yourself the device with any damage, if any, and contact the dealer.

- Use the product in the environment with temperature in the range of 5-35℃, and do not use it in a place below 2,000 meters above sea level.

◆ Statement

① Statement regarding intellectual property: Both the hardware and software of this product are subject to intellectual property. Reproduction of the product and the contents of the manual without our authorization will base the corresponding legal responsibility.

② Use of the product: Unauthorized use of this product is not subject to the actual functions of the product actually ordered and received by the customer.

③ All pictures herein are for reference only, and shall be subject to the actual product. We reserve the right to improve and change the product appearance and design without prior notice.

◆Accompanying Accessories

Remote control × 1
Adapter × 1
Power cord × 1

◆ Appearance

Before use, you are required to be familiar with the ports and keys of the device.



No.	Description	No.	Description
1	Lens	7	Remote control window
2	Air outlet	8	Earphone
3	DC port	9	Two-channel audio output
4	USB port	10	ON/OFF
5	HDMI port	11	Foot pad × 4
6	Indicator	12	Bracket's screw hole

Note: To avoid damage to the eyes, do not look at the lens directly.

◆ Projection



◆ Remote Control



No.	Name	Description	No.	Name	Description
1		ON/OFF	10		Left/Vol-
2		Hulu button	11		Right/Vol+
3		Up	12		Cast
4		Left			
5		Right			
6		Down			
7	OK	OK			
8		Return			
9		Menu			
10		Main interface			
11		HD			
12		Volume +			
13		Volume -			

This product contains technology subject to certain intellectual property rights of Microsoft. Use or distribution of this technology outside of this product is prohibited without the appropriate license(s) from Microsoft.
Content owners use Microsoft PlayReady™ content access technology to protect their intellectual property, including copyrighted content. This device uses PlayReady technology to access PlayReady-protected content and/or WMDRM-protected content. If the device fails to properly enforce restrictions on content usage, content owners may require Microsoft to revoke the device' s ability to consume PlayReady-protected content. Revocation should not affect unprotected content or content protected by other content access technologies. Content owners may require you to upgrade PlayReady to access their content. If you decline an upgrade, you will not be able to access content that requires the upgrade.
The camera on the device will collect projection screen information when enabled screen mirroring function. Screen mirroring data transmission will be released afterwards. Such information shall not be saved or uploaded.

◆ FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following
two conditions:
(1) It may not cause harmful interference, and
This device may not cause harmful interference, including interference that
may cause undesired operation.
(2) It must accept any interference received, including interference that
may cause undesired operation.
Any changes or modifications not expressly approved by the party
responsible for
compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B
digital device, pursuant to Part 15 of the FCC Rules. These limits are designed
to provide reasonable protection against harmful interference in a residential
installation. This equipment generates, uses and can radiate radio frequency
energy and, if not installed and used in accordance with the instructions, may
cause harmful interference to radio communications. However, there is no
guarantee that interference will not occur in a particular installation. If this
equipment does cause harmful interference to radio or
television reception, which can be determined by turning the equipment off and
on, the user
is encouraged to try to correct the interference by one or more of the
following
measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which
the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

◆ IC STATEMENT

This device complies with Industry Canada licence-exempt RSS standard(s).
Operation is subject to the following two conditions:
(1) This device may not cause interference, and
(2) This device must accept any interference, including interference that
may cause undesired operation of the device.

French:
Le d ́ ̂ ̂ ̂