File Name: 38558-1
Production: Dee Mahaliyanage
Date: 06/02/17
PM: Phil Cascia

NEW ART

Peg holes must be positioned by vendor for the product to hang straight

If peg hole conflicts with art please let designer know.

3cm (L) x 1cm (H)

4-COLOR PROCESS: CYAN, YELLOW, MAGENTA, BLACK

PACKAGE SPECS:

PAPER STOCK: 400G

PAPER COLOR: Clay Coated White Back

BLISTER THICKNESS: 15 MIL

PACKAGE TYPE: FOLD OVER CARD (Trapped Blister)
H- 314.325MM
W-317.5MM

CORNER RADIUS .635CM

JASCO

COMMENTS:

CARD INSERTW

3 Pack

12.375in. / 314.325mm

12.5in. / 317.5mm

Battery Operated
No wiring needed!

38558

2 modes
Wireless remote & manual ON/OFF
Encendido/apagado manual y con control remoto inalámbrico

50ft.
Signal range up to 50 feet away*
Alcance de la señal hasta una distancia de 15.24 m*

Screws, anchors & double-sided tape included for easy mounting
Para una instalación fácil se incluyen tornillos y cinta adhesiva de doble cara



Wireless Remote: 38558T

Wireless Remote and Bar Lights mount in any location with simple keyhole mount.

El control remoto y las luces de barra se instalan en cualquier ubicación, contando con un orificio sencillo para tal propósito.

Battery Installation:
Lights require 6 AA batteries each, 18 total (not included). Remote requires 2 CR2032 batteries (included).
Lights: For each light, remove the battery compartment on the back of the light and insert 6 AA size batteries noting polarity. Replace back.
Light Bars Installation: Mounting template provided on front of the card. Under the product.
To mount light: Remove battery cover and mount in desired location using screws and included mounting template or double-sided tape. Reattach light to mounted battery cover. Anchors included for mounting screws in sheetrock.
Remote: To replace exhausted batteries, open the battery compartment on the back of the remote. Insert 2 CR2032 batteries noting polarity. Replace cover.
IMPORTANT: Different types of batteries or new and used batteries should not be mixed. Exhausted batteries should be removed from the fixture and disposed of properly.
*Range rated in open air

Operation
Light bars can be turned on with the remote or by manually switching on and off.
Manual Operation: On the light bar slide control switch to on or off position for manual use.
Remote Operation: Before using the remote for the first time, remove the clear plastic tab inside the remote control battery compartment. Slide the switch to the RF (radio frequency) position. On the light bar push the remote switch to turn lights on and off. "I" means on and "O" means off.

Funcionamiento: los barras de luces se pueden encender o apagar con el control remoto o de manera manual.
Funcionamiento manual: en la barra de luces deslice el interruptor de control a la posición de encendido o apagado.
Funcionamiento a control remoto: antes de usar el control por primera vez, retire la pestaña de plástico transparente que está dentro del compartimento de las pilas del control remoto. Deslice el interruptor a la posición RF (radiofrecuencia). En la barra de luces presione el interruptor de control remoto para encender o apagar las luces. "I" significa encender y "O" significa apagar.

Instalación de las pilas:
Las luces llevan 6 pilas "AA" cada una, 18 en total (no incluidas). El control remoto funciona con 2 pilas CR2032 (incluidas).
Luces: para cada luz, retire el compartimento de las pilas situado en la parte posterior de la luz y coloque 6 pilas "AA" teniendo en cuenta la polaridad. Vuelva a colocar la tapa posterior.
Instalación de las barras de las luces: en la parte anterior de la tarjeta, debajo del producto, se incluye una plantilla para la instalación.
Para instalar la luz: retire la tapa del compartimento de las pilas e instálela en la ubicación seleccionada con tornillos y la plantilla de instalación incluida o con la cinta adhesiva de doble cara. Vuelva a colocar la luz en la tapa instalada del compartimento de las pilas. Se incluyen anclajes para la instalación en pared de yeso.
Control remoto: para cambiar las pilas, abra el compartimento de estas situado en la parte posterior del control. Coloque 2 pilas CR2032 teniendo en cuenta el sentido de la polaridad. Vuelva a colocar la tapa.
IMPORTANTE: No se deben mezclar distintos tipos de pilas ni tampoco las nuevas con las usadas. Las pilas agotadas se deben sacar del aparato y deben desecharse de manera adecuada.
*Alcance nominal al aire libre

CAUTION
BATTERIES MAY LEAK HARMFUL LIQUIDS OR IGNITABLE MATERIALS OR EXPLODE CAUSING INJURY OR PRODUCT DAMAGE.
• DO NOT MIX OLD AND NEW OR OTHER BATTERY TYPES
• REPLACE ALL BATTERIES AT THE SAME TIME
• REPLACE FULLY DISCHARGED BATTERIES IMMEDIATELY
• REMOVE BATTERIES IF PRODUCT IS TO BE UNUSED FOR EXTENDED PERIOD OF TIME
• NOT FOR USE IN WET OR DAMP LOCATIONS

PRECAUCION
LAS BATERÍAS PUEDEN DERRAMAR LÍQUIDOS NOCIVOS O MATERIALES INFLAMABLES O ESTALLAR CAUSANDO LESIONES Y DAÑOS AL PRODUCTO.
• NO MEZCLE BATERÍAS VIEJAS Y NUEVAS NI TAMPOCO DISTINTOS TIPOS DE BATERÍAS.
• REEMPLACE TODAS LAS BATERÍAS AL MISMO TIEMPO.
• REEMPLACE LAS BATERÍAS TOTALMENTE DESCARGADAS INMEDIATAMENTE
• QUITE LAS BATERÍAS SI EL DISPOSITIVO NO VA A SER UTILIZADO POR UN TIEMPO LARGO.
• NO PARA USO EN LUGARES HÚMEDOS O MOJADOS YA A SER UTILIZADO POR UN TIEMPO LARGO.

FCC ID: 2AMB5-38558T

MADE IN CHINA / HECHO EN CHINA
GE is a trademark of General Electric Company and is under license by Jasco Products Company LLC, 10 E. Memorial Rd., Oklahoma City, OK 73114.
This Jasco product comes with a limited-lifetime warranty.
Visit www.byjasco.com for warranty details.
Questions? Contact us at 1-800-654-8483 between 7:00AM-8:00PM CST.

38558-1 ©JASCO 2017 GTIN#00030878385589

FCC STATEMENT:
This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

FCC Declaración
Este dispositivo cumple con la Parte 15 de las Normas de la FCC. La operación está sujeta a las siguientes dos condiciones: (1) este dispositivo no puede causar interferencias perjudiciales y (2) este dispositivo debe aceptar cualquier interferencia recibida, incluidas las interferencias que puedan provocar una operación indeseable.

FCC NOTA: Los cambios o modificaciones o esta unidad que no hayan sido expresamente aprobados por la parte responsable del cumplimiento de las reglas, pueden anular la autoridad del usuario para poder operar el equipo.

NOTA: Este equipo ha sido probado y cumple con los límites para un dispositivo digital de Clase B, conformidad con la Parte 15 de las Normas de la FCC. Estos límites están diseñados para proporcionar una protección razonable contra interferencias en una instalación residencial. Este equipo genera, utiliza y puede irradiar energía de radiofrecuencia y, si no se instala y utiliza de acuerdo con las instrucciones, puede causar interferencia dañina a la comunicación por radio. Sin embargo, no hay ninguna garantía que no ocurra interferencia en una instalación en particular. Si este equipo causa interferencias perjudiciales a la recepción de radio o televisión, esto se puede determinar apagando y encendiendo el equipo repetidamente, se le sugiere al usuario tratar de remediar la interferencia tomando uno o más de las siguientes medidas.
• Reorientar o reubicar o ponga la antena de recepción
• Aumentar la separación entre el equipo y el receptor
• Conectar el equipo a un tomacorriente en un circuito distinto de aquel al que está conectado el receptor
• Consultar el distribuidor o a un técnico de radio / TV para obtener ayuda.

print on inside of card