刀模线

压线





Safari Truck

DisneyParks

This rugged Safari Truck takes Guests on an adventurous trek through the Harambe Wildlife Reserve. Around the trail, animal species are waiting to be discovered. Spot the shy hippopotamus lounging beneath a still pond. Behold the regal lion sunbathing on a rocky perch. Drive past gentle giraffes grazing on a tall tree or wave hello to majestic elephants.

Every safari expedition is an unforgettable experience!

Batteries not included.
2 AA (1.5V) and 2 AAA (1.5V) batteries required.

Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Remove batteries when not in use or discharged.

This device complies with part 15 of the FCC Rules Operation and is subject to the following two conditions:
1. This device may not cause harmful interference.
2. This device must accept any interference received including interference that may cause undesired operation.

CAUTION: Choking hazard. May contain small parts. Not for children under 3 years of age.

Battery Replacement
1. Remove the screw to access the battery compartment.
2. Open battery door.
3. Extracted batteries are to be removed.
4. Requires 2 AA (1.5V) and 2 AAA (1.5V) batteries. Batteries not included.
5. Carefully note the directions of the (+) and (−) symbols on the batteries.
6. Replace the battery door and secure with screw.

To replace batteries in the Remote Control:

Requires 2 AA (1.5V) batteries. Batteries not included.

To replace batteries in the Safari Truck:

Requires 2 AAA (1.5V) batteries. Batteries not included.

www.Disney.com
Disney Theme Park Merchandise
Lake Buena Vista, FL 32830
Sobeny
Made in China
FAC-023193-1XXX

Radio Control Vehicle

Requires 2 AA (1.5V) and 2 AAA (1.5V) batteries. Batteries not included.

Safari Truck