USER MANUAL

Device Description

- Built-in battery.

- Support DC 5V/2A power supply.

- The device has two working modes: AP hotspot mode and Wi-Fi remote mode.

- How to factory reset: When the camera is turned on, press and hold the reset button for about 5 seconds until the blue light and the green light flash alternately.

Indicator Status

Yellow light (Red light): charging——always bright

fully charged——off.

Blue light: waiting for Wi-Fi connection——flash slowly;during Wi-Fi connection——flash quickly, Wi-Fi connection successfully——always bright.

Factory reset: The blue light and the green light flash alternately.

Low-power alarm: The blue light and the green light flash at the same time.

— 1 —

Step 1: Pre-Setup

- ☐ Turn on the camera.
- ☐ Restore the camera to the factory settings.
- ☐ Please place the camera within 2 meters range of the router when connecting to Wi-Fi.
- ☐ Connect your phone to Wi-Fi and clear the Wi-Fi password.

Step 2: APP Download and Registration

❶ Search for "O-KAM Pro" in APP Store or Google Play, or scan the QR code above to download the APP.

Step 3: Add Devices to the APP

Method One: Scan QR code to add camera

— 2 —

❷ Click "Register now" and register your account according to the prompts.

— 3 —

❸ Click "Add", then scan the QR code on the camera, or directly select "Wireless Camera". Please select "I got it" when prompting Bluetooth permissions.

— 4 —

❹ Turn on the camera and restore it to the factory settings.

❺ Confirm the Wi-Fi you want to connect and enter the correct password.

— 5 —


❻ Scan the QR code generated by the APP with the camera lens until the camera emits a beep or the blue light flashes quickly.

— 6 —

❼ Wait for the camera to bind to the APP.

— 7 —

❽ Click "Get started" in turn.

Method Two: AP Connection

❶ Click the icon in the upper right corner and select "Hotspot Configuration".

❷ Click "To connect".

— 8 —

❸ Enter the network settings of your phone, select the signal of "@ OK - ***" and connect.

❹ Back to the APP to automatically add the device, click the play button to watch.

— 9 —

Wi-Fi Configuration

❶ Click "Settings".

❷ Select "Device Settings".

— 10 —

❸ Click "Wi-Fi network".

❹ Select the Wi-Fi you want to connect and enter the correct password.

— 11 —