封面

SIZE：85X63MM
材质：128g双铜双面4C印刷，
中间打一颗钉

AirFly Pro

owner's guide

twelve south

FRONT COVER

Pairing AirFly Pro with AirPods (TX)	2
Pairing AirFly Pro with Wireless Headphones (TX)	6
Pairing AirFly Pro with a Second Set of Wireless Headphones (TX)	10
Reconnecting Headphones to iPhone (TX)	11
Using AirFly Pro with an AUX-IN Port (RX)	12
Tips & Tricks	15
Charging	16
Turning AirFly Pro On & Off	17
Status Light Guide	18

To Begin, Select Transmit or Receive Mode

Transmit Mode: to connect AirPods or wireless headphones to any headphone jack

Transmit Mode (TX) is used to send audio from a wired headphone jack, such as an airplane TV or treadmill at the gym, to your AirPods or wireless headphones.

Receive Mode: to wirelessly connect phone to AUX-IN

Receive Mode (RX) is used to receive Bluetooth audio from a device (such as a smartphone or tablet) and send it to the AUX-IN port of a connected stereo (such as in a car, boat, etc).

Switch AirFly Mode

1

Sound Mode (TX)

Pairing AirFly Pro with AirPods

(Transmit Mode)

Press and hold the Power Button for 4 seconds to turn on AirFly Pro. AirFly flashes amber and white to indicate that it is in pairing mode.*

0:00:04

* If AirFly does not flash amber and white, press the Reset Button on the right side to reset to factory settings.

AirFly Pro — Pairing AirPods

2

To enter Pairing Mode on AirPods, **first place AirPods inside charging case.** With the lid open, press and hold the button on the back of the Charging Case until the light flashes white.

Wireless Charging Case

0:00:05

Standard Charging Case

Connecting AirPods

3

Once successfully connected,* the light on your charging case will turn green, and AirFly Pro will illuminate in white and remain on for 10 seconds.

* This can take up to 90 seconds for initial pairing, but AirFly Pro will remember your AirPods when re-connecting in the future.

AirFly Pro — Connecting AirPods

4

Connecting AirFly Pro to Headphone Jack

(Transmit Mode)

Plug AirFly Pro into the headphone jack of your preferred entertainment system.

AirFly Pro — Connecting Headphones

5

Sound Mode (TX)

Pairing AirFly Pro with Wireless Headphones

(Transmit Mode)

Press and hold the Power Button for 4 seconds to turn on AirFly Pro. AirFly flashes amber and white to indicate that it is in pairing mode.*

0:00:04

* If AirFly does not flash amber and white, press the Reset Button on the right side to reset to factory settings.

AirFly Pro — Wireless Headphones

6

Put your headphones into Bluetooth Pairing Mode (refer to your headphone's owner's manual for more details).

AirFly Pro — Wireless Headphones

7

Sound Mode (TX)

Once successfully connected,* AirFly Pro will illuminate in white and remain on for 10 seconds.

*This can take up to 90 seconds for initial pairing, but AirFly Pro will remember your headphones when re-connecting in the future.

AirFly Pro — Wireless Headphones

8

Connecting AirFly Pro to Headphone Jack

(Transmit Mode)

Plug AirFly Pro into the headphone jack of your preferred entertainment system.

AirFly Pro — Wireless Headphones

9

Sound Mode (TX)

Pairing with a Second Set of Wireless Headphones

With one set of headphones paired and active, you can then pair a second set of headphones to AirFly Pro. Double press the Power Button to enter Pairing Mode (Note: AirFly must already be on to pair.)

Once successfully connected,* AirFly Pro will illuminate in white and remain on for 10 seconds.

AirFly Pro — Wireless Headphones

10

Reconnecting AirPods / Headphones to iPhone

Once paired, AirFly Pro will remember your AirPods / Headphones and switch to them when the unit is turned on. To switch back to using your AirPods / Headphones with your iPhone, first turn off AirFly Pro.

On your iPhone, open Bluetooth Settings, and select your headphones from the list. Status will change from Not Connected to Connected once headphones are successfully paired with your iPhone.

Select AirPods / Headphones

AirFly Pro — Reconnecting

11

Receive Mode (RX)

Using AirFly Pro with an AUX-IN Port

(Receive Mode)

Toggle AirFly Pro to Receive Mode (RX). Press and hold the Power Button to turn on AirFly (If it is not already powered on), and AirFly will begin to blink amber and white once in Pairing Mode.

AirFly Pro — AUX-IN Port

12

With AirFly Pro in Pairing Mode, open up the Bluetooth settings on your smartphone.

Select AirFly Pro from "other devices" to complete pairing.

Settings — Bluetooth — Bluetooth — Now discoverable as "John Doe's iPhone" — MY DEVICES — John's Car — Connected — Apple Watch — Connected — OTHER DEVICES — AirFlyPro

AirFly Pro — AUX-IN Port

13

Receive Mode (RX)

Once your phone is connected, plug AirFly Pro into the AUX-IN port of the desired source.

AirFly Pro — AUX-IN Port

14

Tips & Tricks

1. If only one AirPod seems to be playing audio, turn AirFly Pro off and back on. This will re-sync AirFly Pro and should reconnect both AirPods.
2. If you're having trouble pairing your headphones, make sure that AirFly Pro is switched to Transmit (TX) mode.
3. If you want to pair a new set of headphones to AirFly Pro, or clear the pairing list to factory settings, reset AirFly by pressing and holding the Reset button on the side of AirFly for 4 seconds. Once reset, AirFly will blink amber 6 times, and then will go into Pairing Mode.

0:00:04

Tips & Tricks

15

Charging AirFly Pro

To recharge, simply **plug the Included USB-C to USB-A charging cable into AirFly Pro, and then into any powered USB port.** AirFly Pro is fully charged within 2 hours.

The internal battery of AirFly Pro lasts over 25 hours. We recommend fully charging AirFly Pro before using it for the first time. If your AirFly Pro is low on power, it will flash amber 3 times to alert you that it will need to be charged soon.

While charging, the AirFly Pro will illuminate in amber and stay on. Once fully charged, the amber light will turn off.

Charging

16

Turning AirFly Pro On & Off

To turn on AirFly Pro, hold down the Power Button for up to 3 seconds until AirFly Pro lights up.

To turn off AirFly Pro, hold down the Power Button for 5 seconds. AirFly Pro will blink amber twice and then power off.

0:00:05

Turning AirFly Pro On & Off

17

Status Light Guide

Power On	White LED flashes twice
Pairing Mode	White & Amber LED flashes alternately
Unconnected Standby Mode	White LED flashes twice every 5 seconds
Connected Standby Mode	Solid White LED
Low Power	Amber LED flashes 3 times
Charging	Solid Amber
Fully Charged	Amber LED turns off

Status Light Guide

18

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ISED Statement

This device contains licence-exempt transmitter that comply with Innovation Science and Economic Development Canada licence-exempt RSS(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage; (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible de compromettre le fonctionnement.

Safety Statement

- Do not expose the battery to heat sources or heat zones, or electrically short-circuit or subject to crushing, puncturing or incineration.
- Leaving a battery in an extremely high temperature surrounding environment could result in an explosion or the leakage of flammable liquids or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquids or gas.

WEEE Statement

Waste Electrical and Electronic equipment conforms to the requirements of the European Recast Directive 2012/19/EU.

REACH

Twelve South Brands LLC, ensures that the substances/parts listed, Model: AirFly Pro — is in compliance with Regulation (EC) 1907/2006 (REACH) and it is declared as of conformity is available upon request. Contact us at support@twelvesouth.com.

Product Model: AirFly — AirFly Pro
Substance Name: 1,2-Dichloroethane, CAS 107-06-2

RF Exposure Statement

Caution: To maintain the compliance with RF exposure guideline, place the unit at least 20cm from nearby persons.

Attention: Lors maintenant la conformité avec les directives d'exposition RF, placez l'appareil à au moins 20 cm des personnes à proximité.

BACK COVER

This device must not be co-located or operating in conjunction with any other antenna or transmitter.
Cet appareil ne doit pas être co-localisé ou fonctionner en conjonction avec une autre antenne ou émetteur.

Avoids to use battery in following conditions:

- High low extreme temperatures that a battery can be subjected to during use, storage or transportation.
- Low air pressure at high altitude.
- Replacement of a battery with an incorrect type that can defeat a safeguard.
- The applied nameplate is located at bottom of the product.

Use only power supply with output rating 5V DC 3A max. of PS1, 15W

Have questions?

Visit twelvesouth.com or contact support@twelvesouth.com

© 2022 Twelve South, LLC. All rights reserved.

1505 King St, Charleston, SC 29405 - USA

twelvesouth.com/recycle

Recycle Electronic Equipment at Designated Collection Points

Recycle Batteries and Accumulators at Designated Collection Points

Recycle Packaging at Designated Collection Points

UK CA CE

Design in Charleston, SC USA and assembled in China

封底