1MORE SonoFlow Mini Hearing Protection Study Headphones HQ20 User Guide

万魔听力保护学习耳机 SonoFlow Mini HQ20 用户指南

HQ20

www.1more.com

This product supports hearing conservation and earphone monitoring (speech perception), which can be set through the 1MORE APP.
Hearing conservation:
Low volume: Maximum volume does not exceed 74 decibels, indicated by a single light flashing for 2 seconds.
Medium volume: Maximum volume does not exceed 85 decibels, indicated by a yellow light flashing for 2 seconds; automatically switches to low volume after 2 hours of continuous use.
High volume: Maximum volume does not exceed 94 decibels, indicated by a red light flashing for 2 seconds; automatically switches to medium volume after 0.5 hours of listening.

Note:
1) In hearing conservation mode, the earphones limit high volume usage to no more than 0.5 hours and medium volume usage to no more than 2 hours per 24 hours. If the user wishes to exceed these limits, it is strongly recommended by the HCA (Hearing Conservation Alliance). The tone resets after manually switching volume levels.
2) When using the low, medium and high volumes, the volume will automatically decrease to the next level to protect your hearing.
Earphone monitoring (Speech perception)
Levels Low, medium, high, allowing you to experience different decibel levels of speech perception effects.

Extra Functions:
1. Pairing: Press and hold "+" and "−" buttons for 5 seconds, the headphones will switch to automatic discovery mode.
2. Security pairing: If the pairing phone has Bluetooth prior to 3.0, please use the default security code "0000".
3. Battery/Volume display: Currently supports iOS/Android only, may not support some models of mobile phones.
4. Out of wireless connection range: The headphones will try to reconnect for 3 minutes. Then they will turn off automatically if not connected to any device.
5. Low battery reminder.
6. Do not disturb: Only supported via the 1MORE app. When the headphones are connected to each other with at least 10% battery.
7. Function in the 1MORE APP may vary with different devices or operating systems. For more details, please contact our customer service.

1MORE (1) Year Limited Warranty

1MORE warrants to the original retail purchaser that this product is to be free from defective materials and workmanship for a period of one year from the date of purchase if it is properly used and maintained. If this product proves defective in material or workmanship within the warranty period, 1MORE will at the product with new or refurbished parts, or (2) replace the product with an equivalent new or refurbished product, at no charge for parts or labor. If the product or any component part thereof cannot be repaired effectively or replaced with an equivalent product, 1MORE at its sole option may replace the unit with a product of equal value. Any replacement part or component used to the mounting surface may be required where a new model is substituted.
1MORE assumes no responsibility or liability for such modification. TO OBTAIN WARRANTY SERVICE, CONTACT 1MORE AT THE ADDRESS OR PHONE NUMBER BELOW FOR THE ORIGINAL DEALER FIRST AND THE ORIGINAL DEALER SHALL REPAIR THE PRODUCT WITH NEW OR REFURBISHED PARTS OR REPLACE THE PRODUCT WITH AN EQUIVALENT NEW OR REFURBISHED PRODUCT.
You will be required to submit a proof of purchasing details, including but not limited to a receipt or sales invoice.
Return shipping for exchanges/repairs is the sole responsibility of the original retail purchaser.

Limitations:
1. This limited warranty does not cover the failure of the product resulting from improper installation, misuse, abuse, accident, tampering, mishandling, or wear from ordinary use or environmental deterioration.
2. 1MORE shall not be liable for any incidental or consequential damage, including but not limited to any damage to other components or premises which may result for any reason from the failure of the product.
3. This limited warranty is null and void for products not used in accordance with 1MORE's instructions.
4. This limited warranty is null and void for products with altered or missing serial numbers and for products not purchased from an AUTHORIZED dealer.
5. This limited warranty terminates if you sell or otherwise transfer this product to another party.

产品型号保修说明

产品型号保修声明适用于中国大陆和港澳地区。您可以按照本规定享受保修，服务，维修的权利。
1. 保修期限：自产品出厂日期起，为期一年。
2. 保修范围：
2.1 在保修期内，因产品质量问题，或因产品设计、制造、工艺等原因，导致产品出现故障，或产品性能不符合产品说明书中所述的性能指标的情况，可享受保修服务。
2.2 因使用不当，自行拆机，改装，或因不可抗力因素造成产品损坏，或产品性能不符合产品说明书中所述的性能指标的情况，不在保修范围内。
2.3 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.4 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.5 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.6 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.7 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.8 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.9 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.10 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.11 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.12 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.13 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.14 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.15 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.16 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.17 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.18 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.19 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.20 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.21 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.22 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.23 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.24 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.25 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.26 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.27 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.28 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。
2.29 因产品外观磨损，或因使用时间超过产品说明书中所述的使用寿命，或因使用时间超过产品保修期限，不在保修范围内。