标识	版本号	处数	修改内容	日期
1				
2				
3				

①

840mm

01 Pro Tips

- **Each time you change the label**, please run the automatic label identification.
- Press the feed button on the printer to **skip a blank label.**
- Double click the feed button.
- **Avoid poor quality labels** as they can damage the printer.
- Regularly **clean the print head.**
- **If the paper is jammed and the blue light is flashing slowly,** run the automatic label identification.
- Insert Label Printer into the **same USB port** on your computer every time. This will avoid creating duplicate copies of the printer in your operating system.

02 FAQ

Please visit our official website to check FAQ file.

1

03 LED STATUS LIGHT

Light	Printer Status
Solid blue	Standby and Ready
Blue flashing	Pause printing
Solid red	Cover is not closed
Red flashing	Label jams or label detection error
Purple flashing	Print head overheating
Solid purple	Printing

04 FEED BUTTON

Desired Action	Execution
Skip a label	When the printer is standby and ready (not in the middle of printing), press the feed button once.
Print test page	Insert the label, ensure it is straight and smooth. When the printer is standby, Double click the feed button.

2

Desired Action	Execution
Run the automatic label identification	Insert the label, ensure it is straight and smooth. When the printer is standby, **press and hold the feed button for about 3 seconds.** Then release the feed button.
Pause printing	When the printer is printing, press the feed button once.
Resume printing	When the printer pauses printing, press the feed button once to resume printing.
Restore factory setting	Insert the label, ensure it is straight and smooth. Turn off the printer. Press and hold the feed button, and turn on the printer at the same time. After **the red light flashes 5 times,**then release the feed button.
Sensor calibration (for labels with black marks)	Insert the label, ensure it is straight and smooth. Turn off the printer. Press and hold the feed button, and turn on the printer at the same time. Wait **until the red light changes to blue**, then release the Feed Button immediately.
Sensor calibration (for labels with gaps)	Insert the label,ensure it is straight and smooth.Restart the printer when the printer is standby. When the light will be solid blue,press and hold the Feed Button for about 3 seconds.Wait **until the light changes to purple**,release the Feed Button immediately.

3

05 Specifications

Method	Direct Thermal
Resolution	203 dpi
Max Printing Speed	150 mm/s
Paper Width	20-116mm
Paper Thickness	0.06-0.19mm
Power Adapter	24V⎓2.5A
Printing Life	TPH 50KM
Operating Environment	Temperature: 5-40°C Relative Humidity: 25-85% (Non-condensing)
Storage Environment	Temperature: (-40)-40°C Relative Humidity: 10-90% (Non-condensing)

4

06 Safety Notices

- The print head may be very hot after printing labels. Do not touch the print head.
- Do not bend the power cord excessively or place objects on the cord.
- Do not use the printer if you find any irregularities as these could result in fire or electric shock.
- Keep the printer out of reach of children.
- Use only approved accessories and do not try to disassemble, repair the unit by yourself.
- Keep the printer away from water and other objects that could penetrate the components.
- Please unplug the printer when it is not in use for a long time.

5

07 Warranty Card

☐ Return ☐ Exchange ☐ Repair

Our Info	Name:	Gender:	Phone:
	Address:		
Product Info	Purchase date:		
	Product order number:		
	Product Serial Number:		
Requirement of return / exchange / repair	Reason description:		
Maintenance records	Failure condition:		Maintenance person:
	Handling situation:		Delivery date:
	Maintenance ticket number:		Delivery date:

6

English **IC Warning statement:**
This device contains licence-exempt transmitter(s) /receiver(s) that comply with Innovation, Science and Economic Development Canada' s licence-exempt RSS(s). Operation is subject to the following two conditions:
1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

7

French **Déclaration d'avertissement IC:**
L' émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L' exploitation est autorisée aux deux conditions suivantes:
1. L' appareil ne doit pas produire de brouillage;
2. L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement.

English **RF exposure statement:**
The equipment complies with IC Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

French **Déclaration d'exposition RF:**
L'équipement est conforme à la limite d'exposition aux radiations de la IC établie pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

7

08 FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:
The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum 20cm distance between the radiator and your body.

8

01 Hinweise für Vorbereitung

- Jedes Mal, wenn Sie das Etikett wechseln, lassen Sie bitte die automatische Etikettenerkennung laufen.
- Drücken Sie die Einzugstaste am Drucker, um ein leeres Etikett zu überspringen.
- Klicken Sie zweimal auf die Vorschubtaste.
- Bitte vermeiden Sie, unqualifizierte Etiketten zu verwenden, die den Drucker beschädigen können.
- Reinigen Sie den Druckkopf regelmäßig.
- Wenn das Papier gestaut ist und das blaue Licht langsam blinkt, führen Sie die automatische Etikettenerkennung durch.
- Schließen Sie den Drucker immer an denselbem USB-Anschluss Ihres Computers an, um zu vermieden, dass der Drucker doppelte Kopien erstellt.

02 FAQ

Besuchen Sie bitte unsere offizielle Website, um die FAQ-Datei zu lesen.

9

03 LED-STATUSLICHT

Licht	Druckerstatus
Dauerhaft blau	Standby und Bereit
Blau blinkend	Druckpause
Dauerhaft rot	Abdeckung ist nicht geschlossen
Rot blinkend	Stau von Etiketten oder Fehler bei der Etikettenerkennung
Violett blinkend	Druckkopf Überhitzt
Dauerhaft violett	Druck läuft

04 VORSCHUBTASTE

Gewünschte Aktion	Ausführung
Ein Etikett überspringen	Wenn sich der Drucker im Standby-Modus befindet und bereit ist (nicht mitten im Druckvorgang), drücken Sie einmal die Vorschubtaste.
Testseite drucken	Legen Sie das Etikett ein und achten Sie darauf, dass es gerade und glatt ist. Wenn der Drucker im Standby-Modus ist, klicken Sie zweimal auf die Vorschubtaste.

10

Gewünschte Aktion	Ausführung
Automatische Etikettenerkennung ausführen	Legen Sie das Etikett ein und achten Sie darauf, dass es gerade und glatt ist. Wenn der Drucker im Standby-Modus sich befindet, **halten Sie die Vorschubtaste etwa 3 Sekunden lang gedrückt.** Lassen Sie dann die Vorschubtaste los.
Druckvorgang unterbrechen	Wenn der Drucker druckt, drücken Sie die Vorschubtaste einmal.
Druckvorgang fortsetzen	Wenn der Drucker den Druckvorgang unterbricht, drücken Sie die Vorschubtaste einmal,um den Druckvorgang fortzusetzen.
Werkseinstellung wiederherstellen	Legen Sie das Etikett ein und achten Sie darauf, dass es gerade und glatt ist. Schalten Sie den Drucker aus. Halten Sie die Vorschubtaste gedrückt, und schalten Sie den Drucker ein. Warten Sie, **bis das rote Licht 5 Mal blinkt.** lassen Sie die Vorschubtaste los.
Sensorkalibrierung (für Etiketten mit schwarzen Markierungen)	Legen Sie das Etikett ein, stellen Sie sicher, dass es gerade und glatt ist. Schalten Sie den Drucker aus. Drücken und halten Sie die Einzugstaste und schalten Sie Einschaltig den Drucker ein. Warten Sie, **bis die rote Leuchte blau wird**, und lassen Sie die Einzugstaste sofort los.
Sensorkalibrierung (für Etiketten mit Lücken)	Legen Sie das Etikett ein, stellen Sie sicher, dass es gerade und glatt ist,Starten Sie den Drucker neu.wenn der Drucker im Bereitschaftsmodus ist (Die Anzeige sollte durchgehend blau leuchten),Drücken und halten Sie die Zufuhr-Taste etwa 3 Sekunden lang. Warten Sie, **bis die Anzeige violett wird**, und lassen Sie die Zufuhr-Taste sofort los.

11

05 Spezifikationen

Methode	Direct Thermal
Auflösung	203 dpi
Max Druckgeschwindigkeit	150 mm/s
Papierbreite	20-116mm
Papierdicke	0.06-0.19mm
Spannungsadapter	24V⎓2.5A
Lebensdauer	TPH 50KM
Betriebsumgebung	Temperatur: 5 bis 40 °C Luftfeuchtigkeit: 25-85% (nicht kondensierend)
Speicherumgebung	Temperatur: -40 bis 60 °C Luftfeuchtigkeit: 10-90% (nicht kondensierend)

12

06 Sicherheitshinweise

- Berühren Sie den Druckkopf nicht. Nach dem Drucken kann der Druckkopf erhitzt werden.
- Bitte vermeiden Sie, das Netzkabel zu biegen oder Gegenstände auf dem Kabel zu legen.
- Verwenden Sie den Drucker nicht, wenn Sie Unregelmäßigkeiten bemerken, die zu Bränden oder Stromschlägen führen können.
- Halten Sie den Drucker außerhalb der Reichweite von Kindern.
- Verwenden Sie nur zugelassenes Zubehör. Versuchen Sie nicht, der Drucker selbst zu zerlegen oder zu reparieren.
- Halten Sie den Drucker von Wasser und anderen.
- Ziehen Sie den Netzstecker aus der Steckdose, wenn der Drucker längere Zeit nicht benutzt wird.

13

07 Garantiekarte

☐ Zurückgeben ☐ Umtauschen ☐ Reparieren

Benutzerdaten	Name:	Geschlecht:	Telefon:
	Adresse:		
Info zum Produkt	Kaufdatum:		
	Bestellnummer des Produkts:		
	Seriennummer des Produkts:		
Informationen zur Rückgabe / Ersatz / Reparatur	Beschreibung des Grundes:		
Aufzeichnungen zur Wartung	Störungsbeseitigung:	Wahrungsamon:	
	Handhabungssituation:	Lieferdatum:	
	Wartungsschemnummer:	Datum der Lieferung:	

14

封面(105mm)

SAFETY GUIDE

Label Printer

封面(148mm)

②

单色印刷

色值:

	Pantone (参考)	C(%)	M(%)	Y(%)	K(%)
	-	0	0	0	85
	-	0	0	0	50
	-	0	0	0	18

材质:80g书写纸

工艺:双面印刷/折页

单页尺寸:105×148mm

展开尺寸:840×148mm

折叠要求:封面在上



除非另有说明，否则公差按下表：				产品型号					
尺寸标注	CLASS A	CLASS B	CLASS C	2410-BT&2411-BT			QUIN ENJOY PRINTING 珠海趣印科技有限公司 Zhuhai Quin Technology Co., Ltd.		
<6.0	±0.5	±1	±2						
6.0~30.0	±0.5	±1	±2						
30~120	±0.5	±1	±2						
120~400	±0.5	±1	±2						
400~1000	±0.5	±1	±2	名称	售后卡		材料	80g书写纸	
设计	王雪20241203			料号	30401500003		颜色		
确认	严欣梅20241203			版本号	A0	比例 1:1	单位	mm	图幅
审核	彭理艳20241203			第三角度投影			第 1 张 共 1 张		