120 mm

120 mm

Wishinkle

Wireless Charger

Model: TX10

PRODUCT GUIDE

Basic Specification

- Input: QC 5V/2A, 9V/1.67A
- Output: DC 5V/1A, 9V/1.1A
- Power: 10W
- FCC ID: 2AT58-TX10

Charging Instruction

- Connect the wireless charger to the wall charger or USB port by its charging cable.
- Put the mobile device on the wireless charger, make sure your device is centered on the wireless charger.
- Unplug all connections after use.

Caution

- Always keep the unit dry and avoid exposure to even light moisture.
- Keep away from fire, direct sunlight and extreme heat.
- Do not disassemble or reassemble the charger.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Store the product out the reach of children and in a dry and dust-protected ambience when not in use.

Note: This product is RoHS compliant.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/ TV technician for help.
Use of an attachment not recommended or sold by the battery charger manufacturer may result in a risk of fire, electric shock, or injury to persons.