版本	ECO编号	变更日期	变更描述	设计者
B01	NA	2022.03.18	初版发行	李烜

QUICK START GUIDE

Lockin Smart Lock Y1
Lockin Keypad P1
Lockin Wifi Bridge G1

Product Specifications

Model	Lockin Smart Lock Y1	Lockin Keypad P1	Lockin Wifi Bridge G1
Power Supply	4 pc Alkaline Batteries	2 Pc Alkaline Batteries	USB Type-C Port 5V/1A(Recommended)
Working Environment	0-50C, 40%-85% Humidity (Recommended)	-20-70C, 20%-85%	0-40C, 20%-85% Humidity (Recommended)



1: Indicator Light
2: Knob
3: Button

Ⅰ. Product Overview

Lockin Smart Lock Y1

1: USB Type-C port
2: Button

Lockin Wifi Bridge G1

Lockin Keypad P1/P1-Pro



1: Numerical Password Keypad
2: Indicator Light
3: Fingerprint (only available in P1-Pro)

Ⅱ. Pairing Guide

1. Download the Lockin Home App and sign in or create an account.
A) Scan the QR Code Below to download

Download on the App Store
GET IT ON Google Play

*The Apple logo and App Store are trademarks of Apple Inc., registered in the U.S. and other countries and regions.

*Google Assistant, Google Home, Google Play, and the Google Play logo are trademarks of Google LLC.

B) Search for the Lockin Home in Apple App Store or Google Play

*Developed by: FUNDING INTERNATIONAL PTE. LTD.

2. Follow the instructions below to pair your mobile device and Lockin Smart Lock.

2.1. Remove the battery cover, install four alkaline dry batteries, remove the insulation strip, and then close the battery cover.

*1. One 1.5-Volt alkaline batteries only. Do not mix new and old batteries.
*2. Do not use rechargeable batteries.

2.2. Long press the button of Lockin Smart Lock for about 3 seconds until you hear a "beep" sound, and you will see the green light blinks, which indicates that the device is in the pairing mode.



2.3. Open the Lockin Home App and follow the steps below to complete the pairing.
1) Tap the "+" button in the upper right corner
2) Tap Add Manually
3) Tap Lock Y1
4) Follow the prompts on the app to complete the pairing
*Make sure that your mobile phone's Bluetooth is enabled, and the Lockin Home App is allowed to access your mobile phone's Bluetooth services.

2.4. Follow the prompts on the app to calibrate the Lockin Home App. If you have skipped the calibration or there are calibration errors, you may follow the steps below to complete the recalibration.
a) Tap Lock Y1 on the app homepage to enter the Lock Y1 page
b) Tap Settings
c) Tap Initial Setup Guide

3.1. Open the Lockin Home App and follow the steps below to complete the Keypad pairing.
a) Tap the "+" button in the upper right corner
b) Tap Add Manually
c) Tap Keypad P1/P1-Pro
d) Follow the prompts on the app to complete the pairing
*Make sure that your mobile phone's Bluetooth is enabled, and the Lockin Home App is allowed to access your mobile phone's Bluetooth services.

3.2. Long press the unlock button of Lockin Keypad for about 3 seconds until you hear a "beep" sound, and you will see the green lights blinking, which indicates that the device is in the pairing mode.

3.3. Follow the instructions below to pair your mobile device and the Lockin Keypad.

3.3.1. Remove the battery cover, install two alkaline dry batteries, and close the battery cover.

3.3.2. Long press the unlock button of Lockin Keypad for about 3 seconds until you hear a "beep" sound, and you will see the green lights blinking, which indicates that the device is in the pairing mode.

3.3.3. Open the Lockin Home App and follow the steps below to complete the Keypad pairing.
a) Tap the "+" button in the upper right corner
b) Tap Add Manually
c) Tap Keypad P1/P1-Pro
d) Follow the prompts on the app to complete the pairing
*Make sure that your mobile phone's Bluetooth is enabled, and the Lockin Home App is allowed to access your mobile phone's Bluetooth services.

4. Follow the instructions below to pair the lock and the Keypad.
a) Tap Lock Y1 on the app homepage to enter the Lock Y1 page
b) Tap the bottom of the Lock Y1 page, wait for about 5s to complete the Bluetooth connection

c) Return to the app homepage and tap Keypad P1

a) Tap the middle of the Keypad P1/P1-Pro page, and wait for about 5s to complete the Bluetooth connection

d) Tap the "Image" icon at the bottom of the Keypad P1 page

e) Tap Add
f) Select the lock
g) Tap Start Binding
h) Wait for about 20s to pair the lock and the Keypad

5. Follow the instructions below to pair the lock/Keypad and Wifi Bridge.
5.1. Power on the Lockin Wifi Bridge with a USB Type-C cable (with your own adapter).

Image: Wifi Bridge is powered via cable and adapter.
*Note: Please make sure the Wifi Bridge is powered on the back of the Lockin Wifi Bridge and stick it wherever you want on a desktop.
5.3. Open the Lockin Home App and follow the steps below to complete the pairing.
a) Tap the "+" button in the upper right corner
b) Tap Add Manually
c) Tap Wifi Bridge G1
d) Enter a Wi-Fi name and password
e) Wait for a few minutes for the Wifi Bridge to connect to the network, and then complete the pairing
*Only 2.4GHz Wi-Fi is supported, and 5GHz Wi-Fi is not supported.
*Note: Capitalization and special symbols when entering a Wi-Fi name and password.

6. Follow the instructions below to pair the lock/Keypad and Wifi Bridge to the app and the app homepage to enter the Wifi Bridge G1 page:
a) Tap Add existing
c) Select Lock Y1 and Keypad P1
d) Tap Confirm
e) Wait for about 20s to pair the lock/Keypad and the Wifi Bridge
f) Tap Finish
7. At this point, all pairing for the devices has been completed.

Ⅲ. Unlock Methods

Note:
1. When your phone is connected to Lock Y1, for security reasons, the door can only be unlocked via the app, and unlocking via Keypad is not allowed.
2. When your phone is not connected to Lock Y1, you can operate the app for 10s, the door can be used to unlock the door again.
3. If you cease to operate the app for 10s, the Bluetooth connection between the lock and your phone will be automatically severed. It is normal for a Bluetooth reconnection prompt to appear on the app.

Type	How to Set	Descriptions
Keypad Password	1. Tap Keypad Icon on the App Homepage 2. Tap Keypad Icon 3. Tap Keypad Icon 4. Tap Keypad Icon 5. Tap Keypad Icon 6. Tap Keypad Icon 7. Tap Keypad Icon 8. Tap Keypad Icon 9. Tap Keypad Icon 10. Tap Keypad Icon 11. Tap Keypad Icon 12. Tap Keypad Icon 13. Tap Keypad Icon 14. Tap Keypad Icon 15. Tap Keypad Icon 16. Tap Keypad Icon 17. Tap Keypad Icon 18. Tap Keypad Icon 19. Tap Keypad Icon 20. Tap Keypad Icon	1. When the password is generated, it can be used on the keypad to unlock the door within 24 hours. 2. The password can be used only once. 3. The password can be used only once.
Offline Keypad Temp Code	1. Tap Keypad Icon on the App Homepage 2. Tap Keypad Icon 3. Tap Keypad Icon 4. Tap Keypad Icon 5. Tap Keypad Icon 6. Tap Keypad Icon 7. Tap Keypad Icon 8. Tap Keypad Icon 9. Tap Keypad Icon 10. Tap Keypad Icon 11. Tap Keypad Icon 12. Tap Keypad Icon 13. Tap Keypad Icon 14. Tap Keypad Icon 15. Tap Keypad Icon 16. Tap Keypad Icon 17. Tap Keypad Icon 18. Tap Keypad Icon 19. Tap Keypad Icon 20. Tap Keypad Icon	1. When the password is generated, it can be used on the keypad to unlock the door within 6 hours. 2. The password can be used multiple times within the effective time. 3. The password can be used multiple times within the effective time.
Offline Keypad Cycle Code	1. Tap Keypad Icon on the App Homepage 2. Tap Keypad Icon 3. Tap Keypad Icon 4. Tap Keypad Icon 5. Tap Keypad Icon 6. Tap Keypad Icon 7. Tap Keypad Icon 8. Tap Keypad Icon 9. Tap Keypad Icon 10. Tap Keypad Icon 11. Tap Keypad Icon 12. Tap Keypad Icon 13. Tap Keypad Icon 14. Tap Keypad Icon 15. Tap Keypad Icon 16. Tap Keypad Icon 17. Tap Keypad Icon 18. Tap Keypad Icon 19. Tap Keypad Icon 20. Tap Keypad Icon	1. When the password is generated, it can be used on the keypad to unlock the door within 6 hours. 2. The password can be used multiple times within the effective time. 3. The password can be used multiple times within the effective time.
Remote Unlock	1. Tap Keypad Icon on the App Homepage 2. Tap Keypad Icon 3. Tap Keypad Icon 4. Tap Keypad Icon 5. Tap Keypad Icon 6. Tap Keypad Icon 7. Tap Keypad Icon 8. Tap Keypad Icon 9. Tap Keypad Icon 10. Tap Keypad Icon 11. Tap Keypad Icon 12. Tap Keypad Icon 13. Tap Keypad Icon 14. Tap Keypad Icon 15. Tap Keypad Icon 16. Tap Keypad Icon 17. Tap Keypad Icon 18. Tap Keypad Icon 19. Tap Keypad Icon 20. Tap Keypad Icon	1. When the Lockin App is connected to the Lock Y1, for security reasons, the door can only be unlocked via the app. 2. When the Lockin App is connected to the Lock Y1, you can operate the app for 10s, the door can be used to unlock the door again. 3. If you cease to operate the app for 10s, the Bluetooth connection between the lock and your phone will be automatically severed. It is normal for a Bluetooth reconnection prompt to appear on the app.
Temporary Unlock	1. Tap Keypad Icon on the App Homepage 2. Tap Keypad Icon 3. Tap Keypad Icon 4. Tap Keypad Icon 5. Tap Keypad Icon 6. Tap Keypad Icon 7. Tap Keypad Icon 8. Tap Keypad Icon 9. Tap Keypad Icon 10. Tap Keypad Icon 11. Tap Keypad Icon 12. Tap Keypad Icon 13. Tap Keypad Icon 14. Tap Keypad Icon 15. Tap Keypad Icon 16. Tap Keypad Icon 17. Tap Keypad Icon 18. Tap Keypad Icon 19. Tap Keypad Icon 20. Tap Keypad Icon	1. When the Lockin App is connected to the Lock Y1, for security reasons, the door can only be unlocked via the app. 2. When the Lockin App is connected to the Lock Y1, you can operate the app for 10s, the door can be used to unlock the door again. 3. If you cease to operate the app for 10s, the Bluetooth connection between the lock and your phone will be automatically severed. It is normal for a Bluetooth reconnection prompt to appear on the app.
Fingerprint Unlock (only available in P1-Pro)	1. Tap Keypad Icon on the App Homepage 2. Tap Keypad Icon 3. Tap Keypad Icon 4. Tap Keypad Icon 5. Tap Keypad Icon 6. Tap Keypad Icon 7. Tap Keypad Icon 8. Tap Keypad Icon 9. Tap Keypad Icon 10. Tap Keypad Icon 11. Tap Keypad Icon 12. Tap Keypad Icon 13. Tap Keypad Icon 14. Tap Keypad Icon 15. Tap Keypad Icon 16. Tap Keypad Icon 17. Tap Keypad Icon 18. Tap Keypad Icon 19. Tap Keypad Icon 20. Tap Keypad Icon	1. When the fingerprint is generated, it can be used on the keypad to unlock the door within 24 hours. 2. The fingerprint can be used multiple times within the effective time. 3. The fingerprint can be used multiple times within the effective time.

Ⅳ. Light Indication

1. Lockin Smart Lock Y1
Solid green: unlocked/locked successfully
Blinking green: pairing mode
Solid red: unlock failure/lock failure
Blinking red: low battery warning/locked rotor warning

2. Lockin Wifi Bridge G1
Blinking pink and blue alternately: unpaired
Solid pink: paired and connected to the network
Solid blue: paired but not connected to the network

3. Lockin Keypad P1/P1-Pro
The indicator light is blinking red: low battery warning
The numeric keypad is blinking green: pairing mode
The numeric keypad is in solid green: correct password/press the close button
The numeric keypad is in solid red: wrong password

Ⅴ. Installation Instructions

1. Keypad P1/P1-Pro
1. Drill holes or tie the Keypad bottom plate to the wall with adhesive

2. Fix the Keypad on the bottom plate

Ⅱ. Wifi Bridge G1
Remove the release liner of the adhesive tape on the Wifi Bridge back and stick it wherever you want.

Ⅵ. FAQs and Solutions

1. What should I do when the device cannot be bound?
Reinstall the Lockin Home App; make sure that your mobile phone's Bluetooth is enabled and that the Lockin Home App is allowed to access your mobile phone's Bluetooth service, power on the device again and bind it with your mobile phone on the Lockin Home App.
2. What should I do when the Wifi Bridge cannot connect to the network (offline)?
A) Long press the Wifi Bridge button for about 10s until the indicator light is off for about 1s, and then the Wifi Bridge will be restored and reset.
B) Follow the pairing instructions above to re-pair the Wifi Bridge
1. How to restore to factory settings?
Lockin Smart Lock Y1: The device is restored to factory settings when it is unbound. There is no restore to factory settings button.
Lockin Keypad P1/P1-Pro: The device is restored to factory settings when it is unbound. You can long press the Wifi Bridge button for about 10s until the indicator light is off for about 1s to restore the device.
*The device will be unbound automatically and restored to factory settings when the following two conditions are met:
**The device has been unbound on the Lockin Home App.
***Lockin Home App is able to communicate with the device via Bluetooth.

3. What should I do when the device cannot be unlocked via the app?
Please take out the batteries to power off the device for about 2 minutes, and then install new AA alkaline dry batteries. Do not mix new and old batteries, or use rechargeable batteries.
4. What can I do when the door cannot be unlocked via the Keypad?
(1) Check whether the password is correct or whether it has expired.
(2) Check whether the door can be unlocked via the app. If it is unlocked, ensure that the distance between the Keypad and the lock should not exceed 3m.
(3) When your phone is connected to Lock Y1, for security reasons, the door can only be unlocked via the app, and unlocking via Keypad is not allowed. When your phone is not connected to Lock Y1, you can operate the app for 10s, the Keypad can be used to unlock the door again.
6. What can I do when the app asks for Bluetooth reconnection?
If you cease to operate the app for 10s, the Bluetooth connection between the lock and your phone will be automatically severed. It is normal for a Bluetooth reconnection prompt to appear on the app.

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

□Reorient or relocate the receiving antenna.
□Increase the separation between the equipment and receiver.
□Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
□Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:
If any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
FOR MOBILE DEVICE USAGE (>20cm/low power)
Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Déclaration d'exposition aux radiations:
Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

CAUTION
Risk of explosion if the battery is replaced an incorrect
disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

WEEE Information
All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.

□This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Radiation Exposure Statement:
This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Déclaration d'exposition aux radiations:
Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

Industry Canada statement
□This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:
(1)this device may not cause interference, and
(2)this device must accept any interference, including interference that may cause undesired operation of the device.
□Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
(1)l'appareil ne doit pas produire de brouillage, et
(2)l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

一、制品概要

**可装: 制品的产品名称、产品型号、产品代号、产品尺寸、产品颜色、产品重量、产品电压、产品电流、产品功率、产品工作温度、产品工作湿度、产品工作海拔、产品工作方式、产品工作频率、产品工作电压、产品工作电流、产品工作