BOOMS BASS

使用说明书

M4202＋

MM　WLM　TWS　PORT

详细参数

方案:	蓝讯
版本:	5.4
功能:	TF, FM, USB. BT, AUX TWS, MIC
电池:	18650.3600mAh
颜色:	黑.棕.橙.绿.粉
喇叭直径:	105mm*2+40mm
喇叭功率：	4Ω 10W*2+5W
电压:	Type-C DC 5V
充电时间：	about 5h
工作时间:	3-8h
单机净重:	2423g
产品尺寸:	294*157*203mm

面板按键说明

DC/5V　VOLUME　ON　OFF　10　0
AUX　DC/5V
USB　USB
TF　TF
ECHO

开机/加大音量
下一曲
智停/播放/对联
上一曲
模式/切换
话筒混响

按键功能

- "VOLUME"顺时针为开机/加大音量，逆时针为关机/减小音量。
- "ECHO"话筒混响调节键，顺时针为加大音量，逆时针为减小音量。
- 在音乐模式下短按"◄◄"上一曲，在音乐模式下短按"►►"上一曲。
- 短按"►❙❙"暂停/播放，当两台设备相同的情况下，短按3秒对联（TWS），当听到提示音，连接成功。
- 短按" M "播放音源切换模式（TF, FM, USB. BT, AUX）。

- " ◉ " AUX音频输入
- " ▭ " TF卡 卡槽 插入自动解码切换模式播放音乐。
- " ▭ " U盘插入自动解码切换播放音乐。
- " ▭ " 充电插口，DV 5V插入充电。

话筒按键说明

显示屏
开/关

DC 5V 充电口

使用说明

通过蓝牙连接手机唱歌
1.打开音箱电源 : 长按开关键开机,电源指示灯会开始闪烁。
2.蓝牙连接 : 打开手机蓝牙并扫描,搜索到"型号"后,点击进行配对连接。连接成功时音箱会发出提示音,电源指示灯变为常亮。
3.打开麦克风 : 长按麦克风上的电源键打开麦克风,克风开机后会自动和音箱连接,音箱上对应的指示灯会亮起。
4.调整音效 : 调节好音箱和麦克风的音量,并选择合适的音效。

播放音乐:打开手机里的音乐APP,选择喜欢的歌曲或伴奏开始播放。音乐的音量也可通过手机调节。

如何充电
1.当电池电量过低,产品会自动关机。
2.使用DC5V充电器,连接音箱或麦克风的充电口进行充电。充电时充电指示灯会亮红色,充满后指示灯会熄灭。
3.麦克风充满电约2小时。充电后可连续使用约1小时。

⚠ 请使用相匹配的充电线及电压，否则会有危险及设备损坏.


BOOMS BASS

User Manual

M4202＋

MM　WLM　TWS　PORT

detailed parameters

Chip:	Lanxun
Version:	5.4
Function:	TF, FM, USB. BT, AUX TWS, MIC
Battery:	18650.3600mAh
Color:	Black, Brown,Orange, Green, Pink
Horn size:	105mm*2+40mm
Horn lmpedance：	4Ω 10W*2+5W
Voltage for Cherging:	Type-C DC 5V
Cherging time：	about 5h
Working time:	3-8h
Product N.W:	2423g
Product size:	294*157*203mm

Panel Key Description

DC/5V　VOLUME　ON　OFF　10　0
AUX　DC/5V
USB　USB
TF　TF
ECHO

ON/OFF/VOL+/-　NEXT
PAUSE PLAY TWS　PREV
Mode　M
MIC COL+/-

Key functions

- "VOLUME" Clockwise for turning on/increasing volume, counterclockwise for turning off/decreasing volume.
- " ECHO " Microphone reverb adjustment button, clockwise for increasing volume and counterclockwise for decreasing volume Volume.
- Short press " ◄◄ " in music mode for the previous song, and short press " ►► " in music mode Previous song.
- Short press " ►❙❙ " to pause/play. When two devices are the same, short press for 3 seconds to connect. When a prompt tone is heard, the connection is successful.
- Short press " M " to play the audio source switching mode (TF, FM, USB. BT, AUX).

- " ◉ " AUX audio input
- " ▭ " TF card slot insertion automatic decoding switching mode for playing music。
- " ▭ " nsert the USB flash drive to automatically decode and switch to playing music.
- " ▭ " Charging port, DV 5V plug for charging.

Microphone Button Description

DISPLAY
ON/OFF

DC 5V

instructions

Sing to your phone through Bluetooth connection
1. Turn on the speaker power: Press and hold the power button to turn on the speaker, and the power indicator light will start flashing.
2. Bluetooth connection: Open the phone's Bluetooth and scan. After searching for "model", click Make pairing connections. When the connection is successful, the speaker will emit a beep and the power indicator light will change It is always on.
3. Turn on the microphone: Press and hold the power button on the microphone to turn on the microphone and turn it onThe rear of the machine will automatically connect to the speaker, and the corresponding indicator light on the speaker will light up.
4. Adjust the sound effect: Adjust the volume of the speaker and microphone, and select the appropriate sound Effective.

Play music: Open the music app on your phone, select your favorite song or accompaniment to startPlay. The volume of music can also be adjusted through your phone.

How to charge
1.When the battery level is too low, the product will automatically shut down.
2. Use a DC5V charger to connect to the charging port of the speaker or microphone for charging.The charging indicator light will turn red when charging, and will turn off when fully charged.
3. Fully charge the microphone for about 2 hours. After charging, it can be used continuously for about 1 hour.

⚠ Please use a matching charging line and voltage, otherwise there may be danger And equipment damage。

FCC Caution：

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used exposure condition without restriction.