KMOUK True Wireless Earbuds
KM-HTW001 User Guide

English P3-P18
日本語 P19~P34

Contents

Important Safety Instructions	4
What's in the Box	5
Product Overview	6
How to Wear	7
How to Use	8
Operations and Functions -Left	11
Operations and Functions -Right	12
How to Charge	13
How to Clean	14
Troubleshooting	15
Compliance	16
Specification	17
Customer Service	18

Important Safety Instructions

Please read the user guide thoroughly before using this product and retain it for future reference.

- Place the earbuds back into the charging case or turn on airplane mode when not in use to avoid the product away from children to avoid choking hazard.
- This product is not recommended when using near children. Not recommended for children under age three.
- This product contains magnetic material. Consult your physician to ascertain if this might affect your implantable medical device.
- Do not attempt to open or change any part of the product.
- Avoid the charging case being in contact with oil, cosmetics, lotion, other liquid.
- Never submerge the earbuds in water for an extended period, or wear them while participating in water sports, such as swimming, waterskiing, and surfing.
- Water exposure the product is corrosive to heat, such as fire/sun, oxidation, heat negative, or other operation of the product.
- Not use earbuds immediately if you experience a warming sensation.
- Do not use the charging case if removed its output rating. Overload outputs observe stop may result in a risk of fire or injury to persons.
- Do not disassemble the charging case. It is not recommend to fully recall the risk of fire, injury to persons or electric shock.
- Do not use as a hanging case that is damaged or modified.
- Always ask professional technician or a authorized personnel for repair.
- Do not use charging case if it has been dropped or damaged, and do not try to disassemble and make alone level.
- Do not leave earbuds with high volume for long time to avoid damaging to of hearing.
- Turn the volume down on your device before you put the earbuds in, then turn the volume up gradually to your preference.
- For your safety, do not use the earbuds when you are driving or doing other activities with potential danger, and follow applicable laws regarding headphones.

What's in the box

Carefully unpack the carton and confirm that the following parts are included:



Note:
- If any part of the product is damaged, do not use it. Contact the seller or KMOUK customer service.

Product Overview



How to Wear

Check the left and right sides of the earbuds. The charging case and the earbuds have left and right ear labels, with "L" for the left ear and "R" for the right ear.

Adjust the earbuds to fit your ears.

How to Use

Pairing

1. Open the lid of the charging case, keep the earbuds in the charging case. The indicator light will flash white, and the earbuds enter Bluetooth pairing mode.
2. Turn on the Bluetooth function on your device and select "KMOUK KM-HTW001" from the device list.
3. After first time pairing, when you open the lid, the earbuds will automatically connect to the most recently connected device.

Disconnect from Your Device

Place the earbuds in the charging case and close the lid, the Bluetooth connection will automatically terminate.

Connect to New Device

1. Turn off the Bluetooth function on the connected device.
2. Put the earbuds back into the charging case, then open the lid.
3. Press the function button for 3 seconds, the earbuds will enter the Bluetooth pairing mode. The indicator light will flash white.
4. Turn on the Bluetooth function on the new device and select "KMOUK HTW001" from the device list.

Clear Pairing List

1. Put the earbuds back into the charging case and keep the lid open.
2. Press and hold the function button for 10 seconds, the indicator light will flash white 3 times.

Factory Reset

1. Put the earbuds back into the charging case and keep the lid open.
2. Hold the touch control with your finger on the left earbud, and hold the function button for 10 seconds at the same time. Do the same step for the right earbud.
3. Close the lid for 5 seconds and open the lid.

we locate the MIC Logo and ID and the Product name, the Brand ,the Model name on the Color box and on the instructions

Operations and Functions -Left



Operations and Functions -Right



How to Charge

Charge the Earbuds

1. Put the earbuds into the charging case.
2. Close the lid and the earbuds will start charging automatically.

Earbuds Battery Indicator Light

Light Color	Status
Stable green	Battery power is between 20% and 100%
Stable white	Battery power is lower than 20%

Charge the Case

Connect the USB type-C cable to the charging adapter and then plug the cable into the type-C port on the charging case. Plug the charging adapter into an electric socket.
Note: The charging adapter is not included in the package.

Charging Case Battery Power Light

Light Color	Status
Stable white	Battery power is between 20% and 100%
Stable red	Battery power is between 11% and 20%
Flash red	Battery power is lower than 10%

Charging Case Charging Power Light

Light Color	Status
Stable white	Fully charged
Flash white	Charging and the battery is between 51% and 99%
Flash red	Charging and the battery is lower than 50%

How to Clean

Gently wipe off the dirt with a soft, dry cloth or cotton swab.
Note: Do not insert anything into the nozzle hole.

Troubleshooting

1. Can't find "KMOUK KM-HTW001" in the Bluetooth device list.
Make sure the Bluetooth function of the previously paired device.

2. Failed to pair the earbuds with the device.
Bring the earbuds into pairing mode as instructed in the "Mandatory Pairing" section.

3. No sound in the earbuds.
Make sure the volume on your device and set the earbuds as an audio output device. If not work, do the "Factory Reset" section.

4. Can't hear the other person on the phone.
Adjust the call volume on the device. Set the Bluetooth earbuds as an audio output device in the settings on an iPhone (such as an iPhone).

5. Failed to turn on the earbuds.
The earbuds are low battery, charge the earbuds.

6. Poor sound quality/noisy connection interruption/sound delay.
Place the connected device close to the earbuds or remove the obstacles between them.

Note: If the above solutions do not work, contact the seller or KMOUK customer service for further help.

Compliance

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Specification

Bluetooth® Version	Bluetooth 5.2
Noise Cancellation	CVC 8.0
Effective Range	32.8ft
Driver	0.51in dynamic driver
Temperature Range	-18~122°F
Impedance	16Ω
Water Resistance Level	IPX6
Dimensions	2.09×2.09×1.1in
Weight	0.11lb
Battery life	30h
Microphone	4

Customer Service

12-month Warranty Period

Within one year from the date of purchase, we will repair or replace the product free of charge if it does not work properly due to the quality of the product itself.

Contact Us
Mail: support@kmouk.com

Manufacturer
Name: Shenzhen YaFei E-Commerce Co., Ltd
Address: 102, 23 Baili Road, Bantian Street, Longgang District, Shenzhen, China.

FCC ID:2AYP9KM-HTW001

Made in China

210-153443

目次

重要な安全性の注意	20
内容物の確認	21
製品の概要	22
装着方法	23
使用方法	24
操作方法-左	27
操作方法-右	28
充電方法	29
お手入れ方法	30
トラブルシューティング	31
法令順守	32
製品仕様	33
カスタマーサービス	34

重要な安全上の注意

- 安全、健康を考えるため、お使いの製品を理解するためにお使いください。製品をしまうときは、お子様の手の届かない場所に保管してください。
- 幼児の近くでの使用をお勧めしません。3歳以下の子供には不適切な場合があります。
- 本製品には磁石材料が含まれています。お使いの医師にご相談ください。
- 本製品の内部を開けないでください。
- 充電ケースが直接オイル、化粧品、ローション、その他の液体と接触しないようにしてください。
- 長時間、水に浸けたり、水中でのスポーツ（水泳、水上スキー、サーフィンなど）をしないでください。
- 水に触れると、製品が腐食し、火災、発熱、酸化、その他の製品の動作を引き起こす可能性があります。
- 温かさを感じたらすぐにイヤホンを使用しないでください。
- 充電ケースを取り外した場合、定格出力を超えると、アーク放電が生じるため火災の原因となり怪我の原因となります。
- 充電ケースを分解しないでください。火災や感電のリスクがあります。
- 損傷したり改造された充電ケースを使用しないでください。
- 修理は専門技術者または認定された担当者にお任せください。
- 充電ケースを落としたり、損傷したりした場合は、分解しないでください。
- 音量を高くしすぎないでください。聴覚に悪影響を及ぼす可能性があります。
- 安全のため、運転中や潜在的な危険を伴う活動をしているときにイヤホンを使用しないでください。ヘッドホンに関する法律を遵守してください。
- 子供の安全のため、イヤホンを使用する前に、音量を下げてください。

内容物の確認

箱から慎重に開封し、下記の内容物がすべて揃っているかご確認してください。



ご注意:
万一、損傷等により部分の欠損などが発見された場合は、使用せずに、たちにお問い合わせください。お問合せはお申し込みカスタマーサービスまでご連絡ください。

製品の概要



装着方法

イヤホンの左右を確認します。
充電ケースとイヤホンには「L」と「R」のマークがあり、左右をご注意ください。



イヤホンの左右を確認し、耳にフィットするように調整します。

使用方法

ペアリング

1. イヤホンを入れた状態で充電ケースの蓋を閉じ、自動的にペアリングモードに入ります。
2. お使いのデバイスのBluetooth機能をオンにし、デバイスリストから「KMOUK KM-HTW001」を選択します。
3. 初回ペアリング後、蓋を開けるとイヤホンが自動的に最近接続されたデバイスに接続されます。

デバイスとの接続を解除する

充電ケースにイヤホンを入れて蓋を閉めると、Bluetooth接続が自動的に終了します。

新しいデバイスと接続する

1. 接続しているデバイスのBluetooth機能をオフにします。
2. イヤホンを充電ケースに戻し、フタを閉じます。
3. ペアリングボタンを長押し数秒すると、Bluetoothペアリングモードに入り、インジケーターランプが白く点滅します。
4. 新しいデバイスのBluetooth機能をオンにし、デバイスリストから「KMOUK KM-HTW001」を選択します。

ペアリングリストから削除

1. イヤホンを充電ケースに戻し、フタを開けたままにします。
2. ペアリングボタンを約数秒押しすると、インジケーターライトが白く点灯点滅します。

工場出荷時リセット

1. イヤホンを充電ケースに戻し、フタを開けたままにします。
2. 左側のイヤホンのタッチパネルを長押し、同時にペアリングボタン10秒間押し続けます。右側のイヤホンも同様にしてください。
3. 蓋を閉じ開けてから蓋を開けます。

操作方法-左

操作方法-右

充電方法

イヤホンを充電する

1. 片耳ずつ、イヤホンを入れます。
2. フタを閉めると、イヤホンが自動的に充電を開始します。

ランプの色	ステータス
グリーン	電池は20%から100%の間です
ホワイト	電池は25%以下です

ケースを充電する

USBタイプCケーブルを電源アダプターに接続すると、電源ランプが点滅します。ケースが完全に充電されると、電源ランプが白くなります。
ご注意：充電アダプターはパッケージに含まれていません。

ランプの色	ステータス
白	電池は21%から100%の間である
レッド	バッテリーパワーは11%から20%の間
レッド点滅	バッテリーパワーは10%以下

充電ケースの充電状態

ランプの色	ステータス
ホワイト	完全に充電された
ホワイト点滅	充電とバッテリーは51%から99%の間にある
レッド点滅	充電及びバッテリーは1%から50%で

お手入れ方法

汚れが目立ったら、柔らかく乾いた布や綿棒で汚れをやさしくふき取ります。
注意：イヤホンノズルの穴には絶対に物を挿さないでください。

トラブルシューティング

1. Bluetooth デバイス一覧で「KMOUK KM-HTW001」が見つからない。
ペアリングした機能のBluetooth機能を有効にしてから、再ペアリングします。

2. イヤホンをペアリングのペアリングに失敗しました。
「新しいデバイスと接続」の手順に従って、再ペアリングしてください。

3. イヤホンに音が出ない。
お使いのデバイスの音量をチェックし、音量を調整してください。イヤホンを音声出力デバイスに設定してください。音が出ない場合は、工場出荷時リセットをやってください。

4. 電話の相手の声が聞こえない。
お使いの通話音量を調整してください。KMOUK Bluetooth イヤホンを音声出力デバイスに設定してください。

5. 充電ケースのランプが点きない。
イヤホンのバッテリーが低いと、イヤホンを充電する必要があります。

6. 音質が悪い/接続が途切れる/音が遅れる
接続したデバイスを下げるか、障害物を取り除いてください。

ご注意：上記の解決策がうまくいかない場合は、販売者またはKMOUKカスタマーサービスにお問い合わせください。

法令順守

本製品は、電波法（第2項）に基づく周波数帯域幅の使用基準を定め同等に関する規則、および電波法施行規則（以下「技術基準」）に適合しています。技術基準に適合していることを証明する技術基準適合証明（以下「技適」）を取得しています。

本製品はデバイスを、ご利用の国の法令に従って使用、販売、輸出、輸入することができます。本製品を使用する前に、ご利用の国の法令に従って、技適の取得、または認証を取得する必要があるかどうかを確認してください。

この機器は、無線周波数エネルギーを発生、使用、放射することができ、メーカーの指示に従って設置、使用しない場合、無線通信に有害な干渉を引き起こす可能性があります。しかし、特定の設置場所で干渉が発生しないことを保証するものではありません。この機器が有害な干渉を引き起こしていると思われる場合（機器をオフにすることで確認できます）、ユーザーは以下のいずれかの方法で干渉を修正することを推奨します。

- 受信アンテナの向きを変えるか、設置場所を変えてください。
- 機器と受信機の間隔をあけてください。
- 本機を受信機が接続されている回路とは異なる回路のコンセントに接続する。
- 本機の販売者、または、経験豊かなラジオ/テレビ技術者にご相談ください。

この機器は、規則の第15パートに準拠しています。ご使用にあたっては次の2つの条件に従う必要があります：(1) この機器は有害な干渉を引き起こすことはありません、(2) この機器は、意図せず動作を引き起こす干渉を含む、受信した干渉を受け入れなければなりません。

変更または改造による保証がメーカーの承認を受けていない場合、ご使用者は、この機器を操作する権利を失う可能性があります。

製品仕様

Bluetooth® バージョン	Bluetooth 5.2
ノイズキャンセリング	CVC 8.0
有効範囲	10メートル
ドライバー	0.13mm ダイナミックドライバー
温度範囲	-20~50°C
インピーダンス	16Ω
防水性レベル	IPX6
寸法	2.5×5.5×5.5センチ（約）
重量	50g
電池の寿命	30h
マイク	4

カスタマーサービス

12か月の保証期間
ご購入日から1年以内に、製品自体の品質が原因で正常に動作しない場合は、無償で修理または交換いたします

お問い合わせ先
メール：support@kmouk.com

製造元

会社名：Shenzhen YaFei E-Commerce Co., Ltd
住所：102, 23 Baili Road, Bantian Street, Longgang District, Shenzhen, China.

Made in China