105克铜版纸，双折单黑，140x100mm

Tri-Mode RGB Backlit Mechanical Keyboard



User Manual

Email: soft_boom@yahoo.com
Website: https://softboom/

Product list

Mechanical Keyboard×1
USB Receiver×1
Type-C Charging Cable×1
Metal Key Puller×1
Short Instruction×1
User Manual×1

Product Specification

Dimension	315.78mm×127.42mm×23.28mm(L*W*H)
Weight	1.1kg±10%
Connection	USB wired mode, 2.4G wireless mode, Bluetooth
Receiver type	USB Nano Receiver
Battery Capacity	4000mah
Voltage	4.2V
Working Current (without backlight)	70mA
Working Time (without backlight)	57.1hours
Working Current (with the brightest backlight)	120mA
Working Time (with the brightest backlight)	33.6hours
Charging Time	4.5hours
Working Temperature	0~45℃
Standby time	180 days

Instructions

1. Status indicator description

① Caps Lock
The Caps Lock indicator light will turn white when the function is activated.

② Win Lock
Press "Fn+" the keys to lock or unlock the keys function.

③ Low voltage or Charging
When the battery is low, the indicator light flashes red.
When it is charging, the indicator light turns blue.
When it is fully charged, the indicator light turns green.

2.How to connect

Bluetooth Connection

Press "Fn+Q/W/E" keys to enter Bluetooth Mode, meanwhile the indicator light turns white. Then Press "Fn+Q/W/E" keys to select the corresponding channel, meanwhile the indicator light flashes fastly. Press "Fn+F" keys and find "Keyboard-BT5.0/ BT4.2" on your devices to pair, meanwhile the indicator light is normal.
Note: Press "Fn+ Esc" keys twice to escape Bluetooth Mode.

2.4G Connection

Please insert the USB receiver into your computer then press "Fn+R" keys to enter "2.4 G" Mode.

Wired Connection

Please connect your computer and keyboard with the Type-C cable then press "Fn+Esc" keys to switch Wired Mode.

☆ Smart power saving function

a. If the keyboard is not used for 1minutes in wireless mode, the keyboard enters the first stage of power saving mode and the backlight is turned off. Press any key to wake up.
b. If the keyboard is not used for 30 minutes, the keyboard enters the second stage sleep mode, and all lights are turned off. Press any key to wake up.
c. Wired mode: The keyboard will not turn off the light.

FN composite key function

Fn+Esc	Switch the backlight mode, there are 28 kinds of backlight in total.
Fn+F1	Decrease backlight brightness
Fn+F2	Increase backlight brightness
Fn+F3	Decrease backlight speed
Fn+F4	Increase backlight speed
Fn+F5	Turn off/Turn on backlight
Fn+F6	Press the "Fn+Delete" keys, the left side keys turn red. Press again, the composite key function of the left side of the keyboard is unlocked. Press the "Fn+Delete" keys again, the left side keys turn white. The left side keys turn red.
Fn+F7	Press and hold "Fn+Left Shift" for three seconds, the light of the first seven keys will flash and they will switch to the four arrow keys function. Press "Fn+Left Shift" again for three seconds to resume normal key function.
Fn+Space	Function Cycle switching between windows and Windows Pure RGB lighting

Restore factory defaults:
Press "Fn+ Space" for 2 seconds and the keyboard light will flash 3 times.

How to replace the switches on the keyboard

How to upgrade keyboard: You can replace different switches, whether it is a linear or tactile switch, support RGB Pure mechanical switches, and customize your own keyboard!



1. Pull out the switch with a switch puller.
2. Pull out the switch with a switch puller.
3. Confirm the positions of pins and holes
4. Press the switch vertically to the PCB board

FAQ

Q1: What should I do if the keyboard gets delayed or stuck?
A1:
- Please check there is no 2.4GHz device (e.g. router) nearby to interfere with the connection.
- Please check the keyboard has been fully charged.
- Please check there is no full metal case that may block the signal.

Q2: What should I do if the keyboard can not be charged?
A2:
- Please check whether the charging port is connected.
- Please try to replace the charging cable.
- Try to change the USB port, and if the problem can not be solved, please feel free to contact us.

Q3: What should I do if the backlight stops working?
A3:
- Please charge for half an hour and then re-insert the USB.
- Please try to restart the keyboard.

Q4: Where is my USB receiver?
A4:
- The USB receiver is placed on top of the keyboard inside the package, please look for it carefully.
- Please contact us to get the free replacement if you have lost the USB receiver.

Note

The multimedia keys are for Win 8 and Win 10,for other systems, there may be no function for some combined keys.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
•Reorient or relocate the receiving antenna.
-Increase the separation between this equipment and receiver.
-Connect the equipment into an output on a circuit different from that to which the
receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference
(2)This device must accept any interference received, including interference that may cause undesired operation.

Cautions

1) Please fully charge the keyboard when you first receive the product as this helps to maintain the battery life.
2) Please remove the power supply when charging is complete.
3) If the keyboard is not used for a long time, it is recommended to turn off the power switch of the keyboard.
4) Please do not expose this product to water because it may cause short-circuit and damage the product.
5) Please do not drop or hit this product because shocks may damage the components inside.
6) Please do not place this product near the extreme heat or sources of fire.

X. Japanese Information
This device is not to be used in Japan on any of TP1 or TP2 type equipment. The device can be used in another equipment condition in Japan.