Projector AT-M269 Series

User Guide



Due to continuous improvement,actual product may different from the manual,manual is for reference only.

After Sales Email:support@atmwelt.com

1.Safety Notice:

1.1 Please read use manual carefully before you use projector.
1.2 To prevent the projector from overheating and ensure its reliable operation, it is recommended to install the projector in a well-ventilated place. For example, don't place the projector on a messy coffee table, sofa, bed, etc. Do not place the projector in a narrow space with poor air circulation, such as a bookcase or closet.
1.3.Do not use this projector near water or wet places. To reduce the risk of fire and/or electric shock, do not expose this projector to rain or damp.
1.4 Do not install this product near heat sources, such as radiators, heaters, stoves or other heat-generating equipment.
1.5 Use a dry cloth when cleaning.
1.6 Use only the connectors/accessories specified by the manufacturer.
1.7 If this machine is physically damaged or used carelessly, please do not continue to use this machine.Such as the power cord is damaged, liquid spills on the projector, the projector suffers from rain or damp, foreign objects fall into the projector or internal components are loose, etc.
1.8 Do not let objects or liquids enter the projector. Otherwise, it may come into contact with dangerous voltage points and short-circuit components, resulting in fire or electric shock.
1.9 Pay attention to the safety sign on the projector housing.
1.10 This machine should only be repaired by relevant service personnel.
1.11 Before cleaning the product, turn off the power and unplug the power cord from the AC outlet. Wipe the host shell with a soft dry cloth dipped in neutral detergent. If this product is not used for a long time, unplug the power plug from the AC outlet.
1.12 Do not block the slits and openings for ventilation on the equipment.
1.13 Do not use it under the following conditions: extreme hot, cold or humid environment; an area susceptible to a lot of dust and dirt; Near any equipment that generates a strong magnetic field; direct sunlight.
1.14 When using this product, please keep it out of the reach of children and pets to prevent damage caused by the temperature of the device.
1.15 Do not look directly into the lens of the projector when using this projector. Bright light may harm your eyes.

Warning tips:

Please follow all warnings, precautions and recommended maintenance items in this user guide.
1.1 Warning-For children under 18 months, it is forbidden to use this product.Children over 18 months should use this product in the presence of parents or adults to avoid accidents.
1.2 Warning-Do not look directly at the projector lens when the light bulb is on. Bright light may hurt your eyes.
1.3 Warning-To reduce the risk of fire or electric shock, do not expose this projector to rain or damp.
1.4 Warning-Do not open or disassemble this projector to avoid electric shock.
1.5 Warning-Before changing the bulb, please completely cool the unit.
1.6 Warning-When turning off the projector, make sure to finish the heat dissipation process before unplugging the power cord. The projector needs 90 seconds to cool down.
Note:5G band (W52) indoor use only.

FCC Warnings:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.

2.Preparation before Light on

2.1 As following picture,connect the power adapter(AC100~240V).



2.2 As following picture,indicator on projector adapter connected.



3.Power on/Power off

Press" ⏻ "button on projector or remote control to switch on the projector.

4.Remote Control Introduction

5.Language selection

5.1 When you turn on the projector for the first time, you will automatically be prompted for the language option bar. Please select the language according to your needs.

5.2 To change the language, you can reselect the language as shown in the figure below

❶ Press the Menu button of the remote control (as shown in the picture)
❷ The program menu screen appears
❸ Press the right button of the remote control to the third icon (as shown in the picture)
❹ Then press the down button of the remote control to the first line (as shown in the picture) and press the OK button
❺ Return to the language option bar to select the language

6.User Interface

After projector switched on,following UI will appear after 2-5s starting pictures flash.

7.Focus

To make the image clearer, please try to turn the Focusing Ring on the right side of the projector:



8.Zoom function

Manually turn the wheel to adjust the scene that suits you until the picture is clear. You can adjust the picture size at will while the clarity remains unchanged. The adjustment range is 50%-100%.

❶ Press the Menu button of the remote control (as shown in the picture)
❷ The program menu screen appears



❸ Then press the down button of the remote control (as shown in the picture) and press the OK button
❹ A zoomed and zoomout screen will appear at this time

❶ Then press the left and right buttons of the remote control to zoom in and out.
❷ The minimum size can be reduced to 50%

9.Connection

9.1 Connection Introduction



9.2 Overview

Press the "power on"button, it will enter the main interface after the"power on"logo appeared for a few seconds.
Main interface review
Pre-install application.

Local player: Connect the USB disk/ mobile hard disk to play local video
Local player: Connect the USB disk/ mobile hard disk to play local audio
Local player: Connect the USB disk/ mobile hard disk to open local txt file

Screen Cast (Screen Mirror for IOS Device)
MIRROR (Screen Mirror for Android Device)
DLNA (Push Video Link)

Realize Screen Mirroring between projector and iphone, ipad, android phone, android tablet, other electronic devices.

9.3 Local Player

Connect the USB flash disk driver to the projector and open local player with the remote control, then select local disk, USB flash disk driver to open (videos,pictures,musics and all files) select the file you want to open, it will be lights around, then press OK to play, press the return key to exit.

Local Player support format as following:

Support Files Format	Video	MPEG-1MPEG-2, MPEG-4ASP MJPEG, DivX3/4/5/XVID, H. 264 H.265, VC-1, WMV3, RVB9
	Audio	MPEG, Audio Layer, WAV(PCM, ADPCM),FLAC APE, AAC(AAC-LC, AAC+HE), PCM
	Picture	JPEG、PNG、BMP

9.4 Connection

When connecting a signal source to the projector,be sure to:
1. Turn all equipment off before making any connections;
2. Use the correct signal cables for each source;
3. Make sure the cables are firmly inserted.
In the connection illustrations shown below,some cables may not be included with the projector(see standard accessories).They are commercially available from electronics stores.
Connecting with video equipment:

Terminal name	Terminal outward	Function	Picture quality
USB		Local Player	Better
HDMI		Connect HDMI Devices	Best
AV/AUX		DVD Player/Speaker	Better

9.5 USB Media Play

Input the USB disk to the USB interface, if it connect successfully, the icon of USB disk will appears in the upper left corner, then choose the Media icon which you need open your file.(You can see the picture as below as a reference)
If it shows "No Device" connected via HDMI or USB, under normal circumstances, this is caused by poor contact of the connector, please unplug and plug it again, or test it with a new cable. If it still not work, please contact us, we will reply and give you a solution as soon as possible.

9.6 Connecting Devices

HDMI (High-Definition Multimedia Interface), you can use a HDMI cable connect the projector with HDMI devices. (HDMI cable included)
HDMI Devices: Laptop, PC, TV Stick, TV Box, Roku, Amazon Fire TV, Chromecast, Apple TV, PS3,PS4,PS5, X-Box, to HDMI adapter etc.

AV/AUX (Audio & Video/Auxiliary Multimedia Interface) , , you can use a AV cable connect the projector with AV devices. (AV cable included)
AV Devices: VCD player, DVD player, TV Box, Speaker etc
USB (Universal Serial Bus Multimedia Interface), you can insert USB disk or USB mobile hard disk to USB interface to open video, audio, picture files.
USB Devices: USB disk, USB mobile hard disk etc.
Noted: You can't connect your phone with projector USB interface by USB cable directly, you need to buy an extra to HDMI adapter.(Adapter Not Include)..

9.7 Turn on Projector Bluetooth

❶ Press the Menu button of the remote control (as shown in the picture)
❷ The program menu screen appears
❸ Press the right button of the remote control to the 2nd icon (as shown in the picture)
❹ Then press the down button of the remote control to the bottom line (as shown in the picture) and press the OK button
❺ There are two switches, "Off" and "On", select "On" directly.
❻ Bluetooth is turned on, and searching for connected devices
❼ Back to the main page, the page will appear Bluetooth icon (as shown in the picture)

Note: Bluetooth function is ONLY for audio transfer with audio devices, NOT supporting video sync with smartphones and computers.

9.8 Set Projector connect to WIFI

❶ Turn on the projector and select WIFI Settings
❷ Turn on the network
❸ Click wireless on the right
❹ Choose your wireless
❺ Click OK in the password space
❻ Input the password from the soft keyboard and click enter ⏎
❼ Click the Connect button
❽ The WiFi connection is successful

9.9 IOS/Mac Mirror or Android Mirror

Warm Tips: Please connect your mobile phone and projector to the Same WIFI router.

10.Specification Parameter

Item	Description
Imaging Technology	Single LCD Projection Technology
Supported Resolution	1920*1080 pixels (30Hz)
Light	LED
LED Life Time	50,000 hours
Focus Mode	Manual operation
Projection Distance	1.5-4.2M
Projection Size	35-200inches
Projector Ratio	1.4:1
Aspect Ratio	4:3/16:9
Color	White/Black
Consumption	LED：50W; Other：12W
AC Power Supply	AC 100~240V 50/60Hz
System support	Multi-media(Music,Picture,Video,TXT)
Projection Method	Front,Rear,Ceiling cast
Projection Method	Front table,Rear table,Front ceiling,Rear Ceiling

Disclaimer：

Our company reserve the right to make changes to the contents of this instruction manual without any advance notice. Continuous upgrading of the software may bring some differences to the OSD operation menu and the picture of this instruction manual but does not affect the normal operation of the functional operation described in this instruction manual. We are sorry if this brings inconvenience to you, please kindly understand.