尺寸：80x110mm

JYSXHP

JY005

TRUE WIRELESS STEREO HEADSET

1. Introduction

Thank you for purchasing the JY005 True Wireless Stereo earphones with Bluetooth wireless technology. By pairing them with mobile audio devices also enabled with this technology, the earphones offer great audio quality, excellent performance and the freedom of listening to music or taking calls easily everywhere you go.

We encourage you to thoroghly read this quick installation guide to get the most out of this innovative and truly portable wireless audio device.

Main features

- True Wireless Stereo (TWS) earphones
- Built - in HD microphone for taking calls
- Supports single (mono) and dual earphone use (stereo)
- The magnetic charging dock is equipped with a 400mAh battery capable of providing enough energy to last up to 5 recharge cycles of 1.5 hours each
- Each earphone is equipped with a 30mAh lithium battery
- Up to 18 hours of total playback time and approximately 180 hours in standby mode
- The charging dock can fully charge earbuds in about an hour
- The high-grade transparent case and has a streamer light effect

Package content

- Wireless earphone (2)
- Magnetic charging case (1)
- Type C charging cable (1)
- User Manual (1)
- Ear-cup (4)

Product overview



1 Dust-proof mesh

2 Charging case Streamer LED: When opening/closing the lid, the neon gradient light effect will turn off after 20 seconds, the orange light will flash during charging, and the green light will remain on for 3 minutes after being fully charged. When the battery is low, the red light for opening/closing the cover flashes for 10 seconds and then goes out.

3 Charging port : Insert the Type C cable in this jack.

4 Built - in microphone : Picks up your voice to enable hands-free calling and conferencing.

Earphones LED indicator : The LED turns solid red when chrging the earphone. Once the earphones are fully charged the red light will turn off.

5 Power/Multifunction button : Press the multifunction button to power the earphones on and off. Press this button also to start and pause media, and to answer or end an incoming call.

6 Earphone magnetic contacts : Place the left and right earphones properly in the charging case to start receiving charge.

2. Earphone multifunction button with LED streamer:

Multifunction button	
Mode	**Function**
Pairing	Open the charging case, the earphone will be automatically in pairing mode.
Hands-free mode	Press twice to answer and end an incoming call
	Press and hold for about 2 second to reject or ignore and incoming call
Playback mode	Press twice the right/left button to play and pause audio
Volume -	Press the left button
Volume +	Press the right button
Next track	Hold 2 seconds right button / Press 3 times right button to exchange game model
Previous track	Hold 2 seconds left button Voice Assistant for Siri and Google commands Press 3 times left button

LED indicators on earbuds	
Status	**Function**
Charging	The LED turns solid red
Charging complete	The LED turns off
Power On	The LEDs light up in red/blue blinks
Power Off	The LED light solid red 1s , then turn off

LED indicators on earbuds	
Status	**Function**
Pairing mode active	The LED is one earphone will blink red/bule, the other one will blink blue every 3s
Bluetooth wireless pairing	When the device has paired, the LED will turn off in both earphones
Low battery	Voice prompt "Low Battery"

3. Basic operation

3.1. Charging the case and earphones

Note:

- The case and earphones have internal, non-removable,rechargeable batteries. Do not attempt to remove the battery as you may damage the device.
- Although the case and earphones can be charged at the same time, it is recommended to fully charge the case battery before charging the earphones for the first time.

1. To charge the case, plug the supplied USB cable into a power source and the type-C end in the case's port. The case starts charging automatically.
2. Charging the case battery to its full capacity may take about 1 hour.
3. When the battery is fully charged, the LED will off.
4. Proceed to unplug the case from the power source and place the earphones on the sockets of the charging case.
5. Turn on the button of the case to start charging the built - in batteries of the earphone.
6. While the earphones are being charged, the red indicator on each side lights up. When fully charged, the LED will turn off. This process will normally take about an hour.Meanwhile, the charging case will light up and indicate the remaining capacity of the battery.
7. The fully charged buds have power for up to over 5 hours of talking time or up to 180 hours of standby time. However , these times may vary depending on the mobile device used, on the usage profile, and on the calling / listening habits of each individual user.
8. The low battery prompt or a tone will be heard to let you konw that the voltage is below the acceptable level to continue operating properly.

3.2. Turning your earphones on or off

1. Move the earphone from the power case or press and hold the Multifunction button on each one for about 4 seconds. The " Power on " prompt will be heard, and the LED in both the earphones will start bliking red and blue.
2. As both earphones synchronize, a prompt will be heard indicating that he device is connected. Once the device is paired the LEDs on both earphones will turn off.
3. To turn the earphones off, put the earphone back the power case. Or press and hold the Multifunction button on any one for about 4 seconds. The " Power off " prompt will be heard, and the red LED blink briefly on both sides upon shutting off

4. Advanced operation

4. 1. Pairing your earphones with a mobile device

1. Turn both earphones on by removing from the power case or pressing the Left and right earphones will auto paired at any time.
2. Set your Bluetooth phone to " discover " the wireless earphone.
3. Place the phone and earphones within one meter or each other.
4. The left and right earphones will pair automatically. After both earphones have synchronized with each other, the LED light in one of them will turn off and the LED light in the other one will alternatively blink red and blue to indicate that it has entered into the pairing mode.
5. Select the JY005 earphone from the list of newly discovered devices in your phone.
6. Accept by pressing YES or OK on the device. If prompted, enter the passkey 0000 (4 zeros). Your device will confirm when pairing is complete.
7. The " Your device is connected " prompt will be heard when the devices are able to establish the wireless connection,and the LED will turn off.
8. If after 60 seconds the pairing process fails, please repeat steps 1 through 6 as described above.

9. The earphones will automatically go into standby mode after a short period of inactivity to save battery life.
10. You only need to pair the earphones with your phone once, as they will re-pair automatically.
11. The automatic re-pairing feature will allow the earphones to be reconnected after being switched back on or when placed again within wireless range.

4.2.Call management using your wireless earphones

- When there is an incoming call, your phone will ring, accompanied by a tone through your earphones.
- Press twice the Multifunction button on any earphone to pick it up. You may also press the answer button on your cellular phone to receive the incoming communication in your earphones.

Note: Audio will be out of both earphones.

- To end a call , press twice the Multifunction button on any earphone once again.
- To ignore an incoming communication and send the caller to voicemail, press and hold the Multifunction button on any earphone for about two seconds.

4.3. Music playback and voice command using your wireless earphones

- Press twice the Multifunction button on right/left earphone to play and stop audio playback
- When audio is being played or paused, press 3 times the Multifunction button on the left earphone to enable the Voice Assistant for Siri or Google. Press button again to turn it off.
- When audio is being played or paused, press 3 times the Multifunction button on the right earphone to exchange game mode and music mode

5. Proper care

5.1.Troubleshooting

If you cannot connect the earphones to your phone, do as follows:

- Ensure that the earphones are charged, switched on, paired with and connected to your phone.
- Ensure that the Bluetooth feature is activated on your phone.
- Check that the earphones are within 30 feet of your phone and that there are no obstructions between the earphones and the phone, such as walls or other electronic devices.

5.2.Precautions

- Your earphones are powered by a rechargeable battery.The battery can be charged and discharged hundreds of times, but it will eventually wear out. Recharge your battery only with compatible chargers designaged for this device.
- Unplug the USB charger from the source when not in use.
- Parts of the earphones are magnetic. Metallic materials may be attracted to the headset. Do not place credit cards or other magnetic storage media near the headset, because information stored on them may be earsed.
- Do NOT drop, hit or shake the device.
- Do NOT disassemble, repair or modify the earphones yourself.
- Do NOT use harsh chemicals, cleaning solvents, or strong detergents to clean the device.
- Do NOT expose the earphones to excessive heat or to direct sunlight for long periods of time.
- Do NOT store the device in a place with high humidity or dust.

Technical specifications

Device	
Type	True Wireless Stereo earphones with portable charging case
Form Factor	In - ear
Bluetooth version	Ver. 5.3
Frequency response	20Hz - 20KHz
Signal to noise ratio	108±3dB(at 1KHz)
Maximum power output (RMS)	5mW X 2(3mW X 2)
DC input	5V/500mA
Buttons	Power/Multifunction (play/pause,hands free function: answer/reject call, redial,hang up)
Speaker	
Driver unit	Φ10mm，32Ω ±15%
Maximum power output (RMS)	5mW
Frequency	20Hz-20KHz
Impedance	32Ω
Sensitivity	108 ± 3dB
Microphone	
Directivity	Omnidirectional
Signal to noise ratio	42dB
Output impedance	2.2KΩ
Sensitivity	-42dB, ±3dB
Connection type	Bluetooth Ver. 5.3
Wireless RF frequency	100Hz～10kHz
Wireless range	33ft
Battery	
Single headphone battery	30mAh lithium battery per earphone
Charging case battery	400mAh lithium battery
Charging time (case and earphones)	1.5 hours
Run time(case and earphones)	Up to 18 hours
Charging time (earphones)	50 min.
Standby time	180 hours
Charging method	5VDC/500mA
Specifications	
Product dimensions (WxHxD)	Charging case: 60*60*24.5MM
Weight	55g
Charging cable length	30cm
Warranty	One year

* Enjoy up to 4 hours of continuous playback and 15 hours of backup power from the charging case (estimated battery run time depending on usage and volume settings)

RF exposure statement

This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

JYSXHP

The latest product for 2023 is presented to you.
Wishing you a pleasant use!