CAM 720

Outdoor Dual-Lens WIFI Camera

Quick Start Guide

Camera introduction

1. Power on reset.
2. Please insert the camera adapter, press and hold the reset button for 5 seconds to reset the camera until you hear "Di-", continue to wait for "Di-" 2 times, the camera will complete the self-test.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions.

1.This device may not cause harmful interference.

2.This device must accept any interference received,including interference that may cause undesired operation.

Information to User

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Download CAM720 APP from APP store or Google play, or by Scanning the QR code above.

Sign up & Login

Register an account: Click "Register" > enter your email address, set your APP passcode, check the verification code, and wait for the verification to be completed and then jump directly to the APP list.

Note: if you don't want register an account, it can't remote, but you canuse stand alone mode to view the camera. This mode only support Local view.



WiFi connection

Please insert the camera adapter, press and hold the reset button for 5 seconds to reset the camera until you hear "Di-", continue to wait for "Di-" 2 times, the camera will complete the self-test.

1. In the APP: click "+" > select "WiFi connection".
2. Check "Hear the device announce dial", click "Next".
3. Follow the prompts shown in the app (please connect WiFi to JAA-**** and go back to the Cam720 APP).



4. Enter the correct password for the WiFi connection of your phone and click "Next".
5. When the device is connected, pls wait patiently until cameras online",then click the video to view.



Wired Connection

Plug the power supply and Ethernet cable to the router: Pls plug the adapter for the camera, and connect the camera with the Ethenet cable to the router.

Reset the camera: Long-press the reset button about 5-8s until you hearing Prompted, select wired connection to connect it.

NOTE: Pls confirm the cellphone connected the same wifi of the router that camera connected!If the camera has a Network port, it supports wired/WiFi connection,otherwise, pls select wifi connection to connect.

Home
Camera
Device
Add device
Add device
Add device
Add device
Add device
Add device
Add device
Add