All in One Care

ICLO All in One Care

ICLO Home Beauty All-in-one Device is one body device product that allows you to take care of your oral and skin together by replacing the 4 different heads. By the optimized design for oral and beauty care with 4 heads recognition functions, your oral and skin can be clean and healty. Also each head is configured to adjust the sonic wave vibration mode through three step by considering the user.

Sonic Wave | Dental Clinic | 4 heads | Waterproof grade

All in One

Wireless Charging | LED Sterilization | Smart Sensor | Special Pouch

Product Features and Configurations



1. Main Body
2. 3 Charcoal brush heads
3. Hair removal head
   - Not included shaving blades
4. Cleansing Head
5. Peeling head
6. Wireless Charge Sterilization Cradle
7. USB Charging Cable (C-PIN)
8. Special Pouch
9. Manual

• 4 types of head

Brush Head: Charcoalbrush heads help you take care of your gums and teeth healthier with the scientific effects of charcoal (active carbon)toothbrush (whitening, breath odor removal, gloss).

Cleansing Head: Silicone cleansing head is a hypoallergenic silicon that provides soft daily cleansing effect by focusing on black and white heads.

Peeling Head: Peeling head removes dead skin cells, sebum, and waste from the skin, which helps with elastic skin care.

Hair Removal Head: Through hypoallergenic vibration, it is possible to easily shave areas that require hair removal and helps with beauty care.

- The razor blades are not included.
  Recommended model: [Gillette Venus razor blade]

• 4 types of Head 3 levels of customized Sonic wave electricvibration

There are 4 types of sonic wave vibrations (up to 44,000 vibrations per minute), which can be optionally used depending on the health condition of the user's gums and skin condition.
(1. Soft Mode 2. Bold Mode 3. Pulse Mode)

• Wireless charging and Smart UV-C Sterilization by motion sensor

The all-in-one body can only be charged wirelessly in the designated location. With the motion detection sensor function of the cradle, the UV-C sterilization LED is temporarily turned off when the user approaches and is turned on again when the user is out of a certain distance. If you press the power button shortly, you can turn off the blue LED or turn it on.

• IPX 5 Waterproof grade

It is IPX5 waterproof and can be used for cleaning and showering with the flow of water.

- The cradle is not waterproof, so be careful not to touch the water.

How to use



• How to use 4 types of head

Gently push each head against the shaft fixed axis of the main body vertically until to the end.

When removing each head from the main body, grab the main body and head and pull them in opposite directions to separate them.

• Working

Put the head on the shaft fixed axis of the main body and turn on the power by pressing the power button for a short time. You can check the sound wave vibration level for each head through the front LED and adjust the level according to your skin condition.

- When replacing the head, make sure to turn off the power and remove the used head before replacing it.

• Adjust the Vibration Level

You can change 3 level of mode for each head and press power button shortly to change the mode.

• End of Use

After using it, press and hold the power button to turn off the power, and each head has an automatic shutdown.

Brush Head: Automatic OFF after 2 minutes of working
Cleansing Head: Automatic OFF after 5 minutes of working
Peeling Head: Automatic OFF after 3 minutes of working
Hair removing Head: Automatic OFF after 3 minutes of working

How to use Wireless charging and UV-C Sterilization



Usage time, charging time, and remaining battery capacity may vary depending on the actual environment and product usage time.

- For UV-C LED sterilization effect, we recommend the same location as the image

Recharging: The all-in-one body can only be charged wirelessly at the designated location.

Sterilizing: Place the 4 used heads in the direction of the UV - C LED on the side that touches the skin. UV - C LED automatically repeats 30 minutes of operating and 30 minutes later off, sterilizing the 4 heads.

- Be careful not to expose directly to the eyes when operating the UV-C LED.

How to use Sonic wave electric vibration toothbrush

Sonic wave electric vibrations and charcoal effects up to 44,000 times a minute clean the teeth, making the gums and teeth healthier and cleaner.

A) Soft Sonic wave electric vibration : Gently vibrates 21,000 times per minute to reduce strain on teeth, relieve gum pain, and cleanse sensitive teeth.

B) Bold Sonic wave electric vibration : Vibration up to 18,000 times per minute in daily brushing mode to effectively create air bubbles in the mouth and cleanse teeth gaps, gums, etc.

C) Pulse Sonic wave electric vibration : Massage gums with up to 44,000 to 22,000 sonic conversion vibration to remove plaque.



STEP 1
This product consists of 3 brushes and can be used separately for up to 3 people with the number of 1 to 3 dots at the bottom of the back. Please remember the number of dots on your brush and use it.

STEP 2
Attach the brush head to the main shaft.

STEP 3
Moisten the toothbrush cap with running water and apply a small amount of toothpaste.

STEP 4
Press the power button to start brushing. Adjust the vibration level to your preference.

Electric toothbrush Brushing Teeth TIP!!

STEP 5
With the toothbrush cap and gumline at an angle of 45°, slowly guide the brush head between the teeth and brush it.

Brush for 2 minutes in 4 different area for your mouth and brushing 30 seconds for each area is recommended as shown. (Every 30-second, you can hear the beep sound to help you to change the area of your mouth)

STEP 6
Rinse toothbrush cap under running water after brushing.

STEP 7
Remove the brush head after using it and put it on the dedicated cradle.

- Recommended replace period of toothbrush head: We recommend replacing toothbrush head every 3 month.

How to Use Aqua Peeling Machine

It removes old dead skin cells, sebum, and waste with sonic wave microvibration 44,000 times per minute to make your skin look smooth.

- It's more effective if you open your pores with a steam towel.
- Use it only for short time. (Not more than 3 minutes).
  If you use it on one area of your skin for a long time, it may cause pigmentation or skin inflammation.



STEP 1
Align the rear of the filler head with the body stopper protrusion in the same direction.

STEP 2
Attach the Aqua Peeling head to the main shaft.

STEP 3
Moisten cotton with lukewarm or cremated water and apply enough or spray mist.

STEP 4
Press the power button to start skin care. Press the power button shortly to adjust the vibration level according to your skin condition.

- It's good to apply weak level under the eyes and on areas with weak skin.

STEP 5
After use, wash the peeling head under running water and wash the face clean with lukewarm water before finishing.

STEP 6
Remove the peeling head after use and put it on the dedicated cradle.

How to use Sonic wave electric vibration Silicone Cleansing

The soft daily cleansing effect of hygroscopic, hypoallergenic silicone, along with sonic vibration, cleans the pores deep in your reach while maintaining clean and healthy skin with massage effects.

STEP 1
Attach the Silicone Cleansing head to the main shaft.

STEP 2
Apply an appropriate amount of cleansing product to the skin and lightly foam.

STEP 3
Press the power button to start cleansing. After setting the vibration level according to your skin condition, expand it from the center of your face to the outside direction and cleanse it.

- It is recommended to cleanse areas such as under the eyes with low level of vibration.

STEP 4
After use, clean the head under running water and wash the face clean with lukewarm water before finishing.

STEP 5
Remove the silicone head after use and put it on the dedicated cradle.

How to use a hypoallergenic vibration hair removal head

Hypoallergenic vibration allows for convenient hair removal of desired body parts. Install and use Gillette Venus razor blade only.

- Put it on the body area to be shaved with a steam towel to make the hair roots flexible and minimize skin damage.



STEP 1
After purchasing Gillette Venus Shaving Blade, attach it to the hair removal head and push it to the main shaft.

STEP 2
Start the shaving by pressing the power button.If you push in the direction of the hair, you can minimize skin damage.

- Please do not use it on damaged skin.

STEP 3
After shaving, wash the head with running water and wash the area with lukewarm water to finish.

STEP 4
Remove the hair removal head after use and put it on the dedicated cradle.

How to change the shaving razor.
Remove the existing razor blade by pushing the button behind the hair removal head upwards.
Replace a new razor blade that you bought.

Product specification

Electromagnetic compatibility registration

Registration number : R-R-EYS-ICO01
Mutual: ICLO Co.,Ltd
Model Name : ICLO Sonicwave all in one care
Manufacture : ICLO Co.,Ltd.
Address : ICLO Co.,Ltd, 1F 1949-4 Janggi-dong, Gimpo-si, Gyeonggi-do, Republic of Korea
Manufacturing country : Republic of Korea
Developed and designedcountry : Republic of Korea
Manufacturing year / month : see bottom of package.

Quality Display - ICLO Sonicwave all in one care

Product Name : ICLO Sonicwave all in one care system
Application : Sonicwave vibration mouth care and Sonicwavevibration skin care
Operation Specification : 3.7V 600mA, 2.22W (Device) 5V 800mA, 4W (Wireless Cradle)
Supply power : Li - ion 600mAh / 3.7V

Standard Size
Device : 25.9 (W) x 28.0(D) x 132.5(H) (mm)
Cradle : 248.0 (W) x 65.0(D) x 111.0(H)
Brush Head : 19.7 (W) x 19.7(D) x 93.2(H)
Cleansing Head : 44.0 (W) x 41.1(D) x 55.7(H)
Peeling Head : 33.0 (W) x 19.7(D) x 57.3(H)
Hair Removal Head : 21.0 (W) x 20.0(D) x 47.5(H)
Material: PC, ABS, SUS, SILICONE, PS

Product Weight
Device : 78 g Cradle : 212 g
Brush Head : 6.6 g Cleansing Head : 17.7 g
Peeling Head : 6.3 g Hair Removal Head : 4.5 g

Manufacture : ICLO Co.,Ltd, ICLO Co.,Ltd, 1949, Janggi-dong, Gimpo-si, Gyeonggi-do, Republic of Korea
Place of Sale : ICLO Co.,Ltd, 1949, Janggi-dong, Gimpo-si, Gyeonggi-do, Republic of Korea
Homepage : www.icliocorp.com

Precautions for Using device

- Please use after reading the manual.
- Please be careful not to be touched by infants or children.
- When using the product for the first time, the brush head may feel itchy or tingling due to high-speed vibration, but it disappears when the gums are getting used to cleansing.
- Use the brush body (plastic) carefully when using the sonic wave electric toothbrush. (It may cause tooth strain.)
- Do not install third party consumables (brush heads) on top of the main shaft.
- The hair removal head can only be fitted with Gillette Venus razor blades. (Do not install third-party shaving blades.)
  If you have sensitive skin or metal allergies when using a peeling machine head, cleansing head, or shaving head, please test your arm first and use it if there is no problem.
- Never use it if your skin has an injury or problem such as skin trouble or fear of pain.
- Do not place others on the wireless charging cradle except ICLO products. It can cause a failure.
  (Caution: Coin, Metal and different company electric toothbrush)
- Please be careful as you can damage the device by strong shock.
- The cradle is not waterproof, so be careful not to touch the water.
- When sterilizing four types of heads, attach the brush to the specified location. (If you don't, UVC sterilization effect is reduced)
- Do not inspect glowing LEDs directly to the eye.
- If you experience irritation, dizziness, electric shock or heat, stop using immediately.
- If you experience skin or body problems while using it, stop using it immediately. (Please check with doctor and follow the instructions.)
- Do not use near heat-generating machines.
  (The product may be deformed or discolored.)
- Keep it as dry and cool as possible and avoid direct sunlight.
- It takes more than 8 hours to complete the charge after running out of the battery, and it may vary depending on the actual environment of use and the time of use of the product.
- If not used for a long time, charge the battery from time to time (within 1 month) before storing.
- If it breaks down due to the consumer's fault, there is no exchange or refund.
- You can get free after service within a year (warranty period) after purchase.

※ Caution: Do not use PD charger among cradle charger products.
※ 5V 2A or higher adapter is recommended for charging and not recommended adapter Please use the recommended adapter as it may break due to poor charging.
※ Stop using the product, if you feel a severe fever when using the product.

[The Consumer's Fault]
- Failure due to consumer error or careless handling
  (fall, flooding, impact, damage, excessive operation, etc.)
- In the event of a failure due to repair by someone other than the company's service engineer or designated partner's driver
- In the case of a failure due to the intention or negligence of the consumer.
- In case of failure or product damage caused by the use of non-genuine parts or accessories.
- Consumer's simple change of mind.

[Quality Assurance]

Product name : ICLO sonic wave electric All-in-one Care

Warranty period 1 year from the date of purchase

Purchase Date year month day

- Please enter the purchase date. If not listed, it may be invalid.

Customer Information Customer Name :
Customer phone number :

Place of purchase

- **This product has Marine (insurance) manufactured goods liability (PL) insurance.**

If the product is broken, even if you handled by precaution manual within free warranty period, free warranty service will be provided under the warranty regulations, and if it has to be paid warranty service by regulation the consumer needs to pay for the after-service. If you want warranty service, please check the warranty sheet and warranty regulations and contact ICLO Consumer Protection Center.

Official A/S Consumer Center: 070-4147-2804

[Warranty Regulations] The products subject to warranty are the main body and wireless charging sterilization cradle.
[Free Service] Free warranty service is available if a failure occurs during normal use within one year of purchase. This product does not qualify as a free service if it is converted for business use.
[Paid Service] Even during the warranty period, the following cases will be paid.
1. When a fault occurs because of the consumer's careless handling (fall, flooding, damage, or damage after purchasing).
2. When the consumer arbitrarily decomposes and modifies.
3. If it's broken cause by using other components which was not provided or didn't follow the 'Precaution' manual.
4. Consumables (heads) are end of life or lost.
5. If this warranty paper is not presented, if there is no date of purchase in this warranty paper, or if the details are changed arbitrarily.

ICLO User Manual

ICLO 올인원 케어

아이클로 올인원 케어는 하나의 바디 제품으로 4가지 헤드를 통해 구강 케어와 얼굴 케어를 한 번에 느낄 수 있는 편리한 토탈 솔 케어 제품입니다. 구강 케어와 얼굴 케어에 맞는 최적화된 설계와 4가지 헤드 인식 기능으로 헤드마다 사용 방법을 고려한 음파 진동 3단계 모드 조합 구성으로 구강 및 피부를 깨끗이고 건강하게 유지하고 관리해주는 제품입니다.

음파진동 | 치아클리너

4 ONE 4가지 헤드 | UP 5 | 3단 진동 모드

All in One

UV-C 무선충전 | LED 살균

SMART 8 스마트 센서 | 100% 전용 파우치

올인원 케어 구성 및 기능



1. 올인원 본체
2. 치클 브러시 헤드 3개
3. 제모기 헤드
4. 클렌징 헤드
5. 필링기 헤드
6. 무선충전 살균 크레들
7. USB 충전케이블 (C-PIN)
8. 전용 휴대용 파우치
9. 사용설명서

● 4가지 헤드

브러시 헤드: 음파 진동에 자클(활성탄) 첨을모의 과학적인 효과 (미백, 잇 냄새 제거, 혀세정 잇몸과 치아를 더욱 건강하게 관리할 수 있도록 도와줍니다.

클렌징 헤드: 저자극 실리콘으로 첨액 헤드, 화이트 헤드를 깊은 케어 하여 소프트 데일리 클렌징 효과를 제공합니다.

필링기 헤드: 피부의 각질, 피지, 노폐물을 제거해 주어 단독 모는 피부 관리에 도움을 줍니다.

제모기 헤드: 저자극 진동을 통해 제모가 필요한 부위를 손쉽게 제모가 가능하여 미용 관리에 도움을 줍니다.

- 제모 면도날은 별도 구매 제품입니다. 타제품 면도날을 장착하지 마십시오.
- 장착 가능 모델 (올케어 비너스 면도날)

● 4가지 헤드 3단계 맞춤 음파진동

4가지 종류의 음파 진동 (분당 최대 44,000회의 진동) 으로 사용자의 맞춤 건강 상태와 피부 컨디션에 따라 선택적인 사용이 가능합니다.
(1. 소프트 모드 2. 볼 드 모드 3. 헐스 모드)

● 무선 충전 및 동작감지 센서로 스마트한 UV-C 살균 가능



올인원 본체는 내장된 위치에서만 무선 충전이 가능합니다. 크레들의 동작감지 센서 기능으로 사용자가 접근 시 UV - C 살균 LED 가 정시적으로 켜지며 일정 가이를 벗어나면 다시 켜집니다. 전원 버튼을 짧게 누르면 Blue LED만 고고 켜는 것이 가능합니다.

● IPX 5등급 방수

IPX 5등급 방수 기능으로 물의 흐름에 따라 세척, 사워 시에도 사용이 가능합니다.
- 크레들은 방수 기능이 없으므로 물에 젖지 않게 주의해서 바랍니다.

올인원 케어 사용 방법



● 4가지 헤드 장착 및 분리하기

본체의 사프트 고정축에 헤드의 하단 고정 홈을 맞추어 끝까지 밀어 장착합니다.

헤드를 본체에서 빼냄 해 본체와 헤드를 겉고 각각 반대 방향으로 당겨서 분리합니다.

● 작동하기

사용할 헤드를 본체의 사프트 고정 축에 장착하시고 전원 버튼을 짧게 눌러 전원을 켜줍니다. 전면 LED를 통해 헤드 별 음파 진동 단계를 확인 가능하며 본인 피부 상태에 맞게 단계를 조절합니다.

● 진동단계 조절하기

헤드마다 3단계 모드로 변경이 가능하며 작동 후 전원 버튼을 짧게 눌러 원하는 모드로 사용합니다.

● 사용 종료

사용 중 전원 버튼을 길게 누르면 작동이 종료되며 헤드마다 자동 종료 기능이 있습니다.

브러시 헤드: 2분 작동 후 자동 OFF
클렌징 헤드: 5분 작동 후 자동 OFF
필링기 헤드: 3분 작동 후 자동 OFF
제모기 헤드: 3분 작동 후 자동 OFF

무선충전 및 UV - C 살균 사용방법

사용 시간, 충전 시간 및 배터리 잔량은 실제 사용 환경과 제품 사용 시간에 따라 달라질 수 있습니다.



- UV - C LED 살균효과를 위해 이미지와 동일한 위치를 권장드립니다.

충전하기: 올인원 본체는 지정된 위치에서만 무선 충전이 가능합니다

살균하기: 사용하신 4가지 헤드는 피부에 닿은 면이 UV - C LED를 바라보는 방향으로 놓아주십시오. UV - C LED는 30분 동안 켜지고 30분 뒤 꺼집니 자동 반복하며 헤드 4종을 살균합니다.

- UV - C LED 작동 시 눈에 직접적으로 노출이 되지 않도록 주의하시기 바랍니다.

음파진동 브러시 사용방법

분당 최대 44,000회 음파 진동과 자클의 효능이 치아의 아물질을 제거하여 잇몸과 치아를 더욱 건강하고 깨끗하게 만들어 줍니다.

A) 소프트 음파 진동 : 부드럽게 분당 21,000회 진동하여 치아에 무리를 줄이고 잇몸 동증을 완화하며 민감한 치아를 청결히 케어해줍니다.

B) 볼드 음파 진동 : 일상적인 양치 모드로 분당 최대 18,000회 진동 하여 구강 내에 효과적으로 기포를 만들어 내고 치아 등, 잇몸 등을 깨끗이 세정합니다.

C) 헐스 음파 진동 : 최대 44,000회 ~ 22,000회의 음파 변환 진동으로 잇몸을 마사지하며 저서를 제거합니다.



STEP 1
본 제품은 브러시 3개가 구성되어 있으며 잇몸 마다에 1~3개 정 개수로 최대 3단까지 구별하여 사용 가능합니다.
본인이 사용한 브러시의 정 개수를 기억하여 사용 바랍니다.

STEP 2
브러시 헤드를 본체 사프트에 장착하여 줍니다.

STEP 3
잇솔모를 흐르는 물에 적신 다음 소량의 치약을 묻힙니다.

STEP 4
전원 버튼을 눌러 양치를 시작합니다. 기포가 넘쳐 전원 버튼을 짧게 눌러 진동 단계를 조절하여 사용해주세요.

전동칫솔 양치 TIP

STEP 5
칫솔모와 잇몸선의 각도를 45° 각도로 유지한 상태에서 브러시 헤드를 3이 시작로 천천히 위도 하며 칫솔질 해줍니다.



표시된 그림과 같이 30초간 4구역의 2분간 양치질을 권장합니다.
- 30초 단위 구간 변경 신호음 발생.

STEP 6
양치가 끝나면 흐르는 물에 칫솔 모를 헹굽니다.

STEP 7
사용이 끝난 칫솔 헤드를 분리하여 전용 크레들 거점 위치에 장착하여 관리합니다.
- 칫솔모 교체 권장주기: 1달에 한번 칫솔모를 교체하시길 권장드립니다.

음파진동 아쿠아 필링 사용방법

분당 44,000회의 음파 미세 진동으로 묵은 각질과 피지, 노폐물을 제거해 주며 부드러운 피부 결로 가꾸어 줍니다.

- 스팀 타월로 모공을 연 후 사용하시면 더욱더 효과적입니다.
- 사용 시 3분 내외로 짧은 사용을 권장하며 한 부위에 오랫동안 사용 시 색소 침착 및 피부염증을 유발할 수 있습니다.

STEP 1
필링기 헤드 뒷면 돌출 부분과 본체 스토퍼 홈을맞추어 같은 방향으로 맞추어 주십시오.

STEP 2
필링기 헤드를 본체 사프트에 밀어 장착하여 줍니다.

STEP 3
피부에 미온수나 화장수를 충에 적서 충분히 바르거나 마스트를 본사하여 줍니다.

STEP 4
전원 버튼을 눌러 피부 관리를 시작합니다. 본인의 피부 상태에 맞게 전원 버튼을 짧게 눌러 진동 단계를 조절하여 사용해주세요.
- 눈 및 피부가 약한 부분에서는 강하게 장하게 밀질 하는 것이 좋습니다.

STEP 5
사용 후 필링기 헤드는 흐르는 물에 세척해주고 미온수로 깊숙을 깨끗이 씻어낸 뒤, 마무리합니다.

STEP 6
사용이 끝난 필링기 헤드를 분리하여 전용 크레들에 장착하여 관리합니다.

음파진동 실리콘 클렌징 사용방법

음파 진동과 함께 유생적인 저자극 실리콘의 소프트 데일리 클렌징 효과로 손이 닿지 않는 모공 깊숙한 곳까지 세척과 동시에 마사지 효과로 깨끗하고 건강한 피부를 유지할 수 있습니다.

STEP 1
실리콘 클렌징 헤드를 본체 사프트에 밀어 장착하여 줍니다.

STEP 2
피부에 적당량의 클렌징 제품을 도포하고 가볍게 거품을 내주세요.

STEP 3
전원 버튼을 눌러 클렌징을 시작합니다. 본인의 피부 상태에 맞게 진동 단계를 설정 후 얼굴의 중앙 부분부터 바깥 방향으로 넓혀가며 클렌징을 해줍니다.
- 눈 및 피부가 약한 부분에서는 단계를 약하게 하여 클렌징 하는 것이 좋습니다.

STEP 4
사용 후 제품는 흐르는 물에 세척해주고 미온수로 깊숙을 깨끗이 씻어낸 뒤, 마무리 합니다.

STEP 5
사용이 끝난 실리콘 헤드를 분리하여 전용 크레들에 장착하여 관리합니다.

저자극 진동 제모기 사용법

저자극 진동으로 원하는 신체 부위를 편리하게 제모 할 수 있습니다. 질레트 비너스 면도날(기성품)로만 장착하여 사용해 주십시오.

- 스팀 타월로 모공을 연 후 사용하시면 더욱더 효과적입니다.
- 사용 시 3분 내외로 짧은 사용을 권장하며 한 부위에 오랫동안 사용 시 색소 침착 및 피부염증을 유발할 수 있습니다.

STEP 1
질레트 비너스 제모 면도날을 구매 후 제모기 헤드에 장착 후 본체 사프트에 밀어 장착하여 줍니다.

STEP 2
전원 버튼을 눌러 제모를 시작합니다. 모가 난 방향으로 밀어주시면 피부 손상을 최소화할 수 있습니다.
- 살짝가 난 피부에는 사용하지 말아 주십시오.

STEP 3
제모 후 헤드는 흐르는 물에 세척해주고 미온수로 깨끗한 부분을 씻어내어 마무리합니다.

STEP 4
사용이 끝난 제모기 헤드를 분리하여 전용 크레들에 장착하여 관리합니다.

제모기 면도날 교체방법
제모기 헤드 뒤 버튼을 위로 밀어 기존 면도날을 분리해줍니다.
새로 구매한 면도날을 장착합니다.

제품 사양

전자파적합등록필
인증번호 : R-R-EYS-IC001
상 호 : (주) 아이클로
모 델 명 : 아이클로 음파진동 올인원 케어
제 조 자 : (주) 아이클로
주 소 : 경기도 김포시 장기동 1949-4 1층 (주)아이클로
제조국가 : 대한민국
개발국가 : 대한민국
제조년월 : 포장 하단부 참고

품질표시 - 아이클로 음파진동 올인원 케어
아이클로 음파진동 올인원 케어 시스템
품 도 : 음파진동 구강케어 및 음파진동 피부케어
중작사양 : 3.7V 600mA, 2.22W (Device)
5V 800mA, 4W (Wireless Cradle)
공급전원 : Li - ion 600mAh / 3.7V

규 격
본 체 : 25.9 (W) x 28.0(D) x 132.5(H) (mm)
크 래 들 : 248.0 (W) x 65.0(D) x 11.1(H)
브러시 헤드 : 19.7 (W) x 19.7(D) x 93.2(H)
클렌징 헤드 : 44.0 (W) x 41.1(D) x 55.7(H)
필링기 헤드 : 33.0 (W) x 19.7(D) x 57.3(H)
제모기 헤드 : 21.0 (W) x 20.0(D) x 47.5(H)
재 질 : PC, ABS, SUS, SILICONE, PS

제품무게
올인원 본체 : 78.0 g 크 래 들 : 212.0 g
브러시 헤드 : 6.6 g 클렌징 헤드 : 17.7 g
필링기 헤드 : 6.9 g 제모기 헤드 : 4.5g

제 조 처 : (주) 아이클로
경기도 김포시 장기동 1949-4 1층 (주)아이클로
판 매 처 : (주) 아이클로
경기도 김포시 장기동 1949-4 1층 (주)아이클로
홈페이지 : www.iclocorp.com

사용시 주의사항

- 사용상명세를 반드시 읽어보시고, 정확한 사용 방법을 숙지하신 후 사용하십시오.
- 영유아나 어린이 손에 닿지 않게 주의해 주시기 바랍니다.
- 제품을 처음 사용 시 브러시헤드가 고속 동작으로 인해 잇몸이 가볍거나 얼얼한 느낌을 받을 수 있으나 있음이 세정에 적응되면 사라집니다.
- 음파 진동 브러시 사용 시 몸체(플라스틱) 부분이 차이에 부딪힘시 깊게 사용하실 때입니다. (치아에 무리가 갈 수 있습니다.)
- 본체 사프트에 타사 소모품 (브러시 헤드) 을 장착시켜 사용하지 마십시오.
- 제모기 헤드는 " **질레트 비너스 면도날** " 만 장착할 수 있습니다. (타사 제모 면도날 제품을 장착하지 마십시오.)
- 필링기 헤드, 클렌징 헤드, 제모기 헤드 사용 시 피부가 예민하거나, 금속 알레르기가 있을 경우 팔꿈치테스트 한 후에 이상이 없을 시 사용해 주시길 바랍니다.
- 피부에 부상이나 상처가 있는 경우에는 절대 사용하지 마십시오. (피부트러블, 통증을 느낄 우려)
- 무선 충전 크레들 아이클로로 제품 외에는 올려놓지 마십시오. 고장에 원인이 될 수 있습니다. (주의: 동전, 금속물 및 타사 전동칫솔)
- 강한 충격은 제품에 손상이 갈 수 있으니 주의하시기 바랍니다.
- 크레들은 방수 기능이 없으므로 물에 젖지 않도록 주의하시기 바랍니다.
- 4종 헤드 살균 시 브러시는 지정된 위치에 장착하여주십시오. (UV - C LED 살균효과가 감소합니다.)
- 크레들의 살균 동작 시 UV - C LED를 눈에 직접 조사하지 마십시오.
- 고장, 손상이 있는 상태로 사용하지 마십시오. (피부트러블, 통증을 느낄 우려)
- 자극, 이물질, 전기충격이나 얼굴을 느끼는 경우 즉시 사용을 중지하십시오.
- 사용 중 피부나 신체에 이상을 느끼는 경우 즉시 사용을 중지해 주십시오. (건문의와 상담 후 지시를 따라 주십시오.)
- 열기구와 가까운 곳에서 사용하지 마십시오. (제품이 변형, 변색 될 수 있습니다.)
- 가급적 건조, 시원한 곳에 보관하여 주시고 직사광선은 피해주십시오.
- 배터리 방전 후 충전 완료까지 최대2만 이상 소요되며 실제 사용환경과 제품 사용 시간에 따라 달라질 수 있습니다.
- 장기간 사용하지 않을 경우, 수시로(1개월 이내) 배터리 충전을 한 후 보관하십시오.
- 소비자의 과실로 고장이 난 경우, 교환이나 환불이 불가합니다.
- 구매 후 1년(보증기간) 이내에 무상서비스를 받으실 수 있습니다

※ 제품 사용시 발열이 심하게느껴질 경우 제품 사용을 중지하십시오.

※ 충전 시 5V 2A 이상의 어댑터 사용을 권장합니다.

※ 권장 어댑터가 아닐 시 (예:PD 어댑터) 충전 불량으로 고장 날 수 있으니 권장 어댑터를 사용 바랍니다.

※ UV-C 살균효과로 인해 크레들에 장시간 장착된 헤드 및 본체가 변색될수 있으며, 이제품 무료보단.

[소비자과실]

- 소비자의 잘못 또는 취급 부주의로 인한 고장 (낙하, 침수, 충격, 파손, 무리한 동작 등)
- 당사의 서비스 기사 및 지정 협력사 기사가 아닌 다른 사람이 수리해서 고장이 발생한 경우
- 소비자의 고의 또는 과실로 인한 고장인 경우
- 권품 이외의 부품이나 부속을 사용에 의한 고장이나 제품 파손의 경우
- 소비자의 단순변심

올인원케어 FCC ID

이 장치는 FCC 규칙 제15부를 준수합니다. 운영은 다음 두 가지 조건에 따라 진행됩니다: (1) 이 장치는 유해한 간섭을 초래해서는 안 되며
(2) 이 장치는 수신된 모든 간섭, 불필요한 작동을 초래할 수 있는 간섭을 포함하여 수용 해야 합니다.

이 장비는 FCC 규칙 제15부에 따라 등급 B 디지털 장치의 제한을 준수하는 것으로 테스트 되었습니다. 이 한계는 주거 시설에서 유해한 간섭으로부터 합리적인 보호를 제공 하도록 설계되었습니다. 이 장비는 무선 주파수 에너지를 생성하며, 사용 및 방출할 수 있는 단기, 그리고 설치 및 사용 지침에 따르지 않으면 무선 통신에 유해한 간섭을 일으킬 수 있습니다. 그러나 특정 설치에서 간섭이 발생하지 않을 것을 보장할 수는 없습니다. 한약 이 장비가 무선 또는 텔레비전 수신에 유해한 간섭을 초래하는 경우, 사용자는 다음 중 하나 이상의 조치를 시도하여 간섭을 수정하는 것이 권장됩니 F1.

- 수신 안테나의 방향을 변경하거나 이동합니다.
- 장비와 수신기 사이의 간격을 늘립니다.
- 장비를 수신기가 연결된 회로와 다른 회로의 콘센트에 연결합니다.
- 판매사 또는 경험 있는 라디오/TV 기술자에게 도움을 요청합니다.

규정 준수에 책임이 있는 당사자가 명시적으로 승인하지 않은 변경 또는 수정은 사용자의 장비 운영 권한을 무효화 시킬 수 있습니다. 이 장치는 라디에이터와 사용자의 몸 사이에 최소 20cm 간격을 유지하고 설치 및 작동되어야 합니다.

FCC ID: 2BBTE-ICLO001
Grante Code: 2BBTE
Applicant FRN: [0033904491]

All in one care FCC ID

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful inteference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device should be installed and operated with minimum 20 cm between the radiator and your body.

FCC ID: 2BBTE-ICLO001
Grante Code: 2BBTE
Applicant FRN: [0033904491]

아이클로 정품보증

[품질 보증서]

상 품 명 :	아이클로 음파진동 올인원 케어
보증기간 :	구입일로부터 1년
구 입 일 :	년 월 일

- 반드시 구입 일자를 기재해 주십시오. 기재되지 않은 경우 무효가 될 수도 있습니다.

고객정보 고객 성명 :

고객 전화번호 :

구 입 처 :

공식 A/S 소비자센터 : 070-4147-2804

- 해상(보험) 제조물 배상 책임(PL)보험 가입
보증기간 내에 사용설명서 등 주의사항에 따라 정상적으로 사용한 상태에서 고장이 난 경우에는 보증 규정에 의해 무료로 A/S 해드리며 보증 규정의 유상 서비스에 해당하는 경우에는 유료로 A/S 해드립니다. A/S를 원하실 경우 보증서와 보증규정 내용을 확인한 후, ㈜ 아이클로 소비자 보호 센터로 연락하여 주십시오.

[보증규정]
보증 대상물은 제품 본체와 무선 충전 살균 크레들입니다.

[무상서비스]
구입 후 1년 [보증기간] 이내에 정상적인 사용상태에서 발생한 고장의 경우 무상 A/S 서비스를 받을 수 있습니다. 이 제품을 영업 용도로 전환하여 사용 할 경우에는 무상 서비스에 해당하지 않습니다.

[유상서비스]
보증기간 중이더라도 다음의 경우는 유상서비스가 됩니다.
1. 소비자의 취급 부주의 (구입 후 낙하, 침수, 파손, 손상) 으로 고장이 발생한 경우
2. 소비자가 임의로 분해, 개조한 경우
3. 본 상품에서 제공한 소모품 외의 부품을 사용하거나, "주의사항"을 지키지 않아 고장 난 경우
4. 소모품(헤드)의 수명이 다하거나 분실한 경우
5. 본 보증서를 제시하지 않거나, 본 보증서에 구입날짜 기재가 없는 경우 또는 내용을 임의로 변경한 경우