G121 挂耳式无线蓝牙耳机

1. 产品结构



产品参数:	
产品型号	G121
蓝牙版本	5.3
耳机续电量	300mAH
耳机电池	35mAh
传输长度	10 米
音乐时间	约 4 小时
充电接口	TYPE-c
充电时间	约 1.5 小时

2.蓝牙配对

1.打开充电仓，L/R 耳机自动进入蓝牙配对模式，等待连接。
2.打开手机上的蓝牙，搜索设备名 G121，点击进入连接。
(语音提示：蓝牙已连接)

3.使用方法

1.双一只手按住耳朵，把耳钩放在耳朵上。

2.当转调整耳机到合适位置，上下移动直到耳机完全贴合耳朵配戴。

3.注意区分 L/R 的佩戴位置，如果佩戴反向佩戴不上去。

待连接状态 耳机底灯即红灯交替闪烁

4.操作列表：

功能名称 The name of the function	操作方式及状态 Operation mode and status	指示灯状态 Indicator status	提示音 prompt
耳机连接 Connect	耳机进入配对模式后，操作手机搜索连接耳机，第二次连接，耳机会自动回连设备	无	连接已连接
挂断电话 Hang up the phone	通话状态 按住单机 L/R 耳机	无	
拒接来电 Reject Call	来电状态 按住 L/R 耳机长按 2s	无	
接电话铃 Answer Call	通话状态 按住单机 L/R 耳机	无	
加音量	长按右边耳机		连续大音量提示音，达音量最大
减音量	长按左边耳机		
下曲 Next Song	双击右边耳机进入下一曲	无	
上曲 Previous Song	双击左边耳机进入上一曲	无	
音乐播放/暂停 Play/Pause	单击任何一边耳机。	无	
低电量	请使用耳机充电指示灯红灯 3.4V	红灯 3 秒闪烁 1 次	电量不足
电量显示 show	耳机连接成功后长按 3S 直接查看设备手机/电脑电量显示	无	
关机 Power Off	放入充电仓盖上盖关机 。 1. 耳机在未连接状态下 5 分钟无动静连接自关机。 2. 耳机与连接设备距离过远，耳机进入回连配对状态，5 分钟无动静自关。 3. 耳机电量电压低于 3.1V，自动关机	无	关机
开机 Power On	打开充电仓盖子自动开机。	无	开机
语音助手 Voice Assistant	三击任意边耳机	无	

注意事项：

请遵守以下注意事项以免导致伤害造成财产损失。长时间使用高音量会刺激耳膜，可能会导致听力减弱等恶性影响。为了更好的保护耳部听力，请注意勿让音量过高的情况。根据连接本机蓝牙设备的不同，通话时可能会出现噪声现象，请随时注意保持适 当的音量。提高音量时请逐渐进行，突然加高音量可能会损伤耳部。

如在使用本机时出现灼烫感等症状，请尽快停止使用并向问题主，或联系维修中心或购买时的販售店进行咨询。

1.请不要将耳 机本体置于后裤兜内以免坐下时产生挤压，出现变形或其他故障。

2.请不要在飞机机舱内使用本机，无线电波可能影响可能引发 误操作造成事故。

3.请不要在医疗器械附近使用本机，无线电波等影响可能引发心脏起搏器或其他医疗用电子设备出现故障。

4.请不要在拥挤的车厢内等嘈杂的场所或医疗机构的室内使用本机。请不要在自动门、火灾报警器等自动投刺设备附近使用。当 线电波等影响可能引发误操作造成事故。

免费维修政策：

1.如果产品在保修期内正常使用出现故障，我们将提供本千丽超市免费维修。

2.此又件可重新投发请要费保管，但出现以下情况，本店在保修期内发生故障，以下情况出由收取费用。

(1)因果没有出示保修卡 (2) 如果无法确认购买日期 (3)因果产品超过保修时间 ，发生故障并提出维修需求

(4)因同时保修并保修卡内的注意事项非正常使用 (5) 其他原因造成设备的故障或损坏、或由于维修或改装不当造成

的故障或损坏 (6)因火灾、地震、闪灾、水灾、雷 击或其他外界灾害，污染、盐害、电压异常等造成的故障或损坏 (7)

更换磨损或易损零件，更换耗零件

3.只使用海制盒零件或耗代零件进行维修。此外，维修更换的旧零件和残灯也会弗处理。

因故障无法使用本产品所造成的损失，我们将不予赔偿。

产品保修：

保修条款:

本产品自购买日起，享有一年的保修期限。

保修的产品在这期间凭本保修凭证及有效销售凭证，符合下列条款时即可保修。

1.您的设备必须按照产品使用说明书正确使用;

2.本保修书不适用于人为、意外火灾、外力挤压、坠落等)或者自然灾害(地震、台风、雷电等)所致的故障或损坏等;

3.本保修书遗失或不再补发，请妥善保存。

产品名称:	
型号:	
购买时间:	
姓名:	
联系电话:	
购买地点:	
经销商名称及地址:	

请将此凭证妥善保存，若因您设备需要保修服务，请联系您所购入设备的经销商。

警告语如下：

警告：

该设备符合FCC规则第15部分。操作需满足以下两个条件：

（1）本设备不得产生有害干扰，并且（2）本设备必须接受接收到的任何干扰，

包括可能导致不希望的操作的干扰。

未经合规责任方明确批准的更改或修改可能导致用户操作设备的权限失效。

附注：本设备已经过测试，符合B类数字设备的限制，根据FCC规则第15部分。

这些限值旨在对住宅安装中的有害干扰提供合理的保护。本设备产生、

使用并能辐射射频能量，如果不按照说明书安装和使用，

可能会对无线电通信造成有害干扰。然而。不能保证在特定的安装中不会发生干扰。

如果本设备确实对无线电或电视接收造成有害干扰（可通过开关设备来确定），

则鼓励用户尝试通过以下一种或多种措施来纠正干扰：

–调整接收天线的方向或位置。

–增加设备与接收器之间的距离

–将设备连接到与接收器连接的电路不同的插座上。

–请咨询经销商或有经验的无线电/电视技术人员以获得帮助

附注：本设备及其天线不得与任何其他天线或发射器一起放置或操作

该设备已被评估，以满足一般的射频暴露要求。该装置

可在便携式曝光条件下不受限制地使用。

G121 hanging ear wirelessbluetooth headset

1. Product structure



Product parameters:	
Product model	G121
Bluetooth version	5.3
Charging cover battery capacity	300mAH
Headphone battery	35mAh
Transmission radius	10 meters
Music time	About 4 hours
Charging interface	TYPE-C
Charging time	Approx. 1.5 hours

2. Bluetooth pairing

1. Open the charging case, L/R earbuds will automatically enter Bluetooth pairing mode, wait for connection.
2. Turn on Bluetooth on your phone, search for the device name G121, click to enter the connection,
(Voice prompt: Bluetooth is connected)

3. How to use

1. Hold the earphone with one hand and hang the earphone on the ear.

2. Rotate to adjust the position of the earphone horn, moving up and down until the earphone fits perfectly into the contour of the ear.
3. Pay attention to distinguish the wearing position of L/R, if you take it backwards, you can't wear it.

To be connected state: the headset is followed by a blue lightfled lights alternate flashes

4. Operation list:

The name of the function	Operation mode and status	Indicator status	prompt
Connect	After the headset enters pairing mode, operate the mobile phone and other devices to connect	not	Bluetooth is connected
Hang up the phone	Call status: Click L/R headset at any point	not	
Reject Call	Incoming call status: Any L/R headset press and hold 2s	not	
Answer Call	Call status: Click L/R headset at any point	not	
Increase the volume	Press and hold the right earbud		Press to a maximum volume, Prompt to "Volume is maximum"
Reduce the volume	Press and hold the left earbud		
Next Song	Double-click the right earbud to enter the next song	not	
Previous Song	Double-click the left earbud to enter the previous song	not	
Play/Pause	Click on either side of the headset,	not	
Low battery	Indicates that the headphone battery voltage has fallen below 3.4V	The red light flashes 1 time in 5 seconds	Low battery
show	After the headset is successfully connected, it supports IOS system and some Android hardwhichcine battery level display	not	
Power Off	Turn off the system after putting in the charging case cover. 1. The headset is not connected to the device for 5 minutes in the pairing modeAfter shutdown. 2. The distance between the headset and the connected device is too far, and the headset enters the back connectionPairing mode, the device connection for 5 minutes, shutdown 3. The headset battery voltage is as low as 3.1V, and it will automatically shut down.	not	Shutdown.
Power On	Open the lid of the charging compartment to automatically turn on.	not	Boot
Voice Assistant	Triple tap any side of the headset	not	

Notes:

Please observe the following precautions to avoid injury and property dam age. Prolonged use of high volumes can irritate the ears and may cause evils such as hearing loss
Sexual impact. In order to better protect the ear hearing, please pay attenti on to prevent excessive volume. Depending on the Bluetooth device conne cted to the unit, it is possible when making a call
Howling may occur, so please keep the volume appropriate. Raise the volu me gradually, suddenly increasing the volume may damage the ear.
If you experience symptoms such as skin allergies when using this unit, discontinue use as soon as possible and ask a doctor, or contact a repair center or the store where you purchased it
Inquire.
1. Please do not place the earphone body in the back trouser pocket to avoid squeezing, deformation or other malfunctions when sitting down.
2. Please do not use this unit in the cabin of the aircraft, radio waves and other influences may cause misoperation and cause accidents.
3. Please do not use this unit near medical devices, radio waves and other effects may cause malfunction of pacemakers or other medical electronic devices.
4. Do not use this unit in noisy places such as crowded carriages or ind oors at medical institutions. Please do not use automatic control devices such as automatic doors], fire alarms, etc
For nearby use. Influences such as radio waves may cause misoperation and cause accidents.

Free Repair Policy:

1. If the product fails during normal use during the warranty period, we will repair it free of charge according to this manual.
2. This document can be reissued Please keep it safe, if the following cases occur, even if there is a failure during the warranty period, the following cases will be charged.
(1) If the warranty card is not presented (2) If the purchase date cannot be confirmed (3) If the product exceeds the warranty time and the failure occurs, and a repair request is made
(4) Misuse (normal use in accordance with the precautions in the instruction manual) (5) Failure or damage of the equipment caused by other reasons, or due to improper maintenance or modification
(6) Failure or damage caused by fire, earthquake, wind disaster, flood, lightning strike or other natural disasters, pollution, salt damage, abnormal voltage, etc. (7) Replace worn or vulnerable parts, replace dirty parts
3. Remanufactured parts or replacement parts can be used for repair.
In addition, repair replacement of old parts and we will dispose of them properly. We will not compensate for the damage caused by the inability to use this product due to failure.

Product Warranty:

Warranty terms:
This product is covered by a one-year warranty from the date of purchase.
The warranty product can be guaranteed when it meets the following terms with this warranty certificate and valid sales certificate when it is sent for repair.
1. Your equipment must be used correctly in accordance with the product instruction manual.
2. This warranty card is not applicable to faults or damage caused by man-made accidents (fire, external extrusion, fall, etc.) or natural disasters (earthquake, typhoon, lightning, etc.);
3. This warranty card will not be reissued after it is lost, please keep it properly with the sales voucher.

Product Name:	
Model:	
Time of purchase:	
Name:	
Contact number:	
Where to buy:	
Dealer Name and Address:	

Please keep this voucher safe, if your device requires warranty service, please contact the dealer of your purchased device.

The warnings are as follows:

Warning:
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However. there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
--Consult the dealer or an experienced radio/TV technician for help
NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter
The device has been evaluated to meet general RF exposure requirement.
The device
can be used in portable exposure condition without restriction.