i31说明书 做折页

材料：108克铜版纸+单黑双面印刷+过光油 成品尺寸：75*90mm

75mm

90mm

KING LUCKY



WIRELESS OPEN-EAR HEADSETS

USER MANUAL

I Packing List

Charging Case*1 User Manual*1

Charging Cable*1 Headset*2

II Product Specifications

1 Charging Case Specifications

Input:DC 5V=1A

Charging Port: Type-C

Charging Case Capacity:400 mAh

Standby Time:120 Days

Charging Time: about 2 hours

1 Charging Case Specifications

BT Name: i31Pro

BT Version: 5.3

Sound Channel: Dual Channel

Battery Capacity:80mAh

Communication Distance: ≤10m (unobstructed)

Frequency Range:20Hz=20KHz

Playing Time:10=11 Hours

Charging Time: about 2 hours

Supported Protocols: A2DP1.3/AVCTP1.4/AVDTP1.3/AVRCP1.5/HFP1.5/SPP1.0/SMP/L2CAP4.2

III Appearance Description



IV Product Function Operations:

Charging Indicator Lights	
Charging the charging case	The charging case may have indicator lights that display the battery level or charging progress
Charging case fully charged	Battery level indicator lights fully lit.

Headsets Function Tips	
Function	Operation Instructions
Connect To Phone	Open the Bluetooth settings page on your phone and search for the BT device named i31Pro.
Voice Assistant	To activate the voice assistant function, long-press the left touch area (L) of the headsets for 2 seconds.
Play/Pause	During an incoming call, double-tap the left or right touch area (L/R) of the headsets to answer the call.
Answer Call	During an incoming call, double-tap the left or right touch area (L/R) of the headsets to answer the call.
Reject Call	During an incoming call, long-press the left or right touch area (L/R) of the headsets for 2 seconds to reject the call.
End Call	During a call, double-tap the left or right touch area (L/R) of the headsets to end the current call.
Previous/Next Track	Triple-tap the left touch area (L) of the headsets to go to the previous track and triple-tap the right touch area of the headsets to go to the next track.
Switch Between Chinese And English Voice Prompts	Five-tap the left or right touch area(L/R)of the headsets to switch languages.
Game Mode	To enter game mode, long-press the right touch area (R) of the headsets for 2 seconds to switch.
Volume Up/Down	To increase the volume, single-tap the right touch area (R) of the headsets. To decrease the volume, single-tap the left touch area (L) of the headsets (only applicable to some phones).
Display Battery Level	The phone will display the battery level of the headsets (requires phone compatibility).
Disconnect	When you put the headsets into the charging case, the connection with the phone will be disconnected. When you take the headsets out of the charging case, they will automatically reconnect to the phone.
Low Battery Reminder	When the earphone battery is low, there will be a low battery reminder sound.

Lights Indicator	
When you place the headsets in the charging case,	the built-in indicator lights will provide you with a visual representation of the battery level.
When the headsets are being charged	the lights on the headsets are always-on, when they are fully charged, the lights will be off

V Important Notes

1. Do not use corrosive cleaning agents to clean this product.
2. Keep this product away from heat sources or open flames, such as stoves.
3. Avoid prolonged exposure of this product to direct sunlight.
4. Do not dispose of this product in fire to prevent explosions.
5. Do not attempt to disassemble or modify this product as it does not contain any user-serviceable parts.
6. Do not use this product in the rain.
7. If you do not plan to use this product for an extended period of time, please store it in a dry environment. It is also recommended to charge the earphones at least once a month to prolong their lifespan and protect them from extreme temperatures and dust.

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's

authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different
from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.