ROKFORM®

10K Wireless Magnetic Power Bank Manual

REVISED 2/25/25

Pantones

- Cool Grey 1c
- Orange 21c
- Black
- White

OPERATION MANUAL - ACTUAL SIZE

FOLD LINES

ROKFORM®
BEYOND PROTECTION

10K Wireless Magnetic Power Bank

Operation Manual



1. Aluminum Stand
2. USB-C IN/OUT Port
3. LED Indicator Lights
4. Power Button

Wireless Phone Charging

Place the 10K Wireless Magnetic Power Bank on the back of your MagSafe compatible phone. The power bank will automatically start charging.



Wired Phone Charging

Connect a USB-C charging cable to the 10K Wireless Magnetic Power Bank and your phone. Double press the power button to turn off the power bank.



Charging the Magnetic Power Bank

To recharge the 10K Wireless Magnetic Power Bank, use the included USB-C cable and connect it to the power bank. Connect the other end to a USB-C power adapter (not included).



Charging Precautions

- Wireless charging is more convenient but limited to current wireless charging technology. Wireless charging speed will be slower than wired charging.
- High temperatures will decrease wireless charging speed and limit power, which is a physical phenomena for all chargers.
- Both the phone case and the distance between phone and charger will affect charging speed, which is decreased by the thickness of the case.

Safety Precautions

- Store this product in a cool dry place.
- Do not store this product in high temperatures or a humid environment.
- The operating temperature should be between 32°F and 126°F (0°C and 52°C).
- Tampering may result in a fire or risk of personal injury.
- Do not expose this product to heat or fire.
- Do not use harmful chemicals or detergents to clean this product.
- Improper use, dropping, or excessive force cause damage to this product.

Compatible Devices

Compatible devices for magnetic wireless charging:
iPhone 12/13/14/15/16 series and above models.

Specifications

Model:	339201-10K
USB-C IN/OUT:	Yes
Wireless Output:	Up to 15W
Capacity:	10,000 mAh
Dimensions:	103.0 x 69.6 x 18.5 mm

FRONT SIDE

FCC ID: 2BFSK-10000MAH

FCC STATEMENT:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from the that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The magnetic suction function is only for adjusting the charging position of the mobile phone.

RF Warning Statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Changes or modifications to this product not authorized by ROKFORM could void the electromagnetic compatibility (EMC) and wireless compliance and negate your authority to operate the product. This product has demonstrated EMC compliance under conditions that included the use of compliant peripheral devices and shielded cables between system components. It is important that you use compliant peripheral devices and shielded cables between system components to reduce the possibility of causing interference to radios, television sets, and other electronic devices.

Responsible party contact:

Rokform, LLC
16180 Scientific
Irvine, CA 92618
USA
1-855-765-3676

This appliance is safeguarded by double insulation and does not require a safety connection to electrical earth (ground).

Recycle electrical waste in an approved electrical waste recycling center. Check the internet for a recycling center in your area or you can call us at 855-765-3676 and we will help you find one.

This product complies with the US Department of Energy's Level VI energy efficiency regulation.

Do not expose this product to heat or flame, do not burn or melt.

This product is for indoor use only.

This product complies with the European radio interference requirements.

Do not throw in trash or landfill, please bring to an approved electronic waste recycling center.

This device complies with part 15 of the FCC Rules. (See FCC statement on this form)

This product is back by a 2-year warranty. For more information on our warranty policy please see the following page:

https://www.rokform.com/pages/warranty

Limited Warranty for Item #339201-10K
10K Wireless Magnetic Power Bank

WE WARRANT THAT, DURING THE WARRANTY PERIOD (AS DEFINED BELOW), THE 10K WIRELESS MAGNETIC POWER BANK #339201-10K, WILL BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP UNDER NORMAL USE. THIS LIMITED WARRANTY IS PROVIDED TO THE ORIGINAL END PURCHASER FROM THE COMPANY OR A COMPANY AUTHORIZED RESELLER. THIS WARRANTY IS NON-TRANS-FERABLE AND NO RETURNS WILL BE ACCEPTED FROM ANYONE OTHER THAN THE ORIGINAL END PURCHASER.

EXCEPT AS EXPRESSLY SET FORTH ABOVE IN THIS LIMITED WARRANTY, THE COMPANY MAKES NO OTHER EXPRESS OR IMPLIED WARRANTIES TO THE EXTENT PERMITTED BY LAW AND SPECIFICALLY DISCLAIMS AND EXCLUDES ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS, MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IF SUCH DISCLAIMER OF ANY IMPLIED WARRANTY IS NOT PERMITTED BY LAW, THE DURATION OF ANY SUCH IMPLIED WARRANTIES IS LIMITED TO THE WARRANTY PERIOD SET FORTH HEREIN. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES OR LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY MAY LAST. SO SUCH LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM JURISDICTION TO JURISDICTION.

OUR RESPONSIBILITY FOR DEFECTIVE PRODUCTS IS LIMITED TO REPAIR OR REPLACEMENT AS SET FORTH IN THIS WARRANTY STATEMENT.

OUR RESPONSIBILITY FOR DEFECTIVE PRODUCTS IS LIMITED TO REPAIR OR REPLACEMENT AS SET FORTH IN THIS WARRANTY STATEMENT.

(a) Who May Use This Warranty?

This limited warranty extends only to the original purchaser from the WWW.ROKFORM.COM Website or a Company authorized reseller. It does not extend to any subsequent or other owner or transferee of the product or any transferee or other beneficiary of the service.

(b) What Does This Warranty Cover?

This limited warranty covers, during the Warranty Period (as defined below), defects in materials and workmanship.

(c) What Does This Warranty Not Cover?

This limited warranty does not cover any damages due to:
(i) transportation;
(ii) storage;
(iii) improper use;
(iv) failure to follow the product instructions or to perform any preventive maintenance;
(v) modifications;
(vi) combination or use with any products, materials, processes, systems or other matter not provided or authorized in writing by the Company;
(vii) unauthorized repair;
(viii) normal wear and tear; or
(ix) external causes such as accidents, abuse, or other actions or events beyond our reasonable control.

This limited warranty does not apply to:
(i) cosmetic damages; or
(ii) any products not produced by the Company, even if bundled with the Company's products.

(d) What is the Period of Coverage?

This limited warranty starts on the date of your purchase and lasts for TWO YEARS (the "Warranty Period"). The Warranty Period is not extended if we repair or replace a warranted product or re-perform a warranted service. We may change the availability of this limited warranty at our discretion, but any changes will not be retroactive.

(e) What Are Your Remedies Under This Warranty?

With respect to any defective product during the Warranty Period, we will, in our sole discretion, either repair or replace such product (or the defective part) with new or refurbished parts free of charge.

(f) How Do You Obtain Warranty Service?

Please send the following information to info@rokform.com:
- COPY OF PROOF OF PURCHASE
- SHIPPING ADDRESS and FULL NAME PLEASE TYPE
  SHIPPING INFORMATION
- PHOTO OF DAMAGED ITEM